




## Contents

<b>1. Introduction</b>	<b>3</b>
Approvals	3
Symbols	3
Abbreviations	4
Definitions	4
<b>2. How to Programme</b>	<b>11</b>
The Graphical and Numerical Local Control Panels	11
How to Programme on the Graphical LCP	11
The LCD-Display	11
Display Mode	14
Display Mode - Selection of Read-Outs	14
Parameter Set-Up	16
Quick Menu Key Functions	16
Main Menu Mode	19
Parameter Selection	19
Infinitely Variable Change of Numeric Data Value	21
Read-out and Programming of Indexed Parameters	21
How to Programme on the Numerical Local Control Panel	22
Local Control Keys	23
Initialisation to Default Settings	24
Parameters: Operation and Display	26
Parameters: Load and Motor	39
Parameters: Brakes	55
Parameters: Reference/Ramps	61
Parameters: Limits/Warnings	74
Parameters: Digital In/Out	80
Parameters: Analog In/Out	94
Parameters: Controllers	101
Parameters: Communications and Options	105
Parameters: Profibus	110
Parameters: DeviceNet CAN Fieldbus	119
Parameters: Smart Logic Control	126
Parameters: Special Functions	142
Parameters: Drive Information	150
Parameters: Data Read-outs	157
Parameters: Encoder Input	164
Parameter Lists	167
<b>3. Troubleshooting</b>	<b>193</b>

Warnings/Alarm Messages	193
<b>Index</b>	<b>200</b>

# 1. Introduction

**FC 300**  
**Programming Guide**  
**Software version: 4.8x**

This Programming Guide can be used for all FC 300 frequency converters with software version 4.8x.  
 The software version number can be seen from parameter 15-43.

## 1.1.1. Approvals





## 1.1.2. Symbols

Symbols used in this guide.



**NB!**  
 Indicates something to be noted by the reader.



Indicates a general warning.



Indicates a high-voltage warning.

\*

Indicates default setting

1.1.3. Abbreviations

1

Alternating current	AC
American wire gauge	AWG
Ampere/AMP	A
Automatic Motor Adaptation	AMA
Current limit	I <sub>LIM</sub>
Degrees Celsius	°C
Direct current	DC
Drive Dependent	D-TYPE
Electro Magnetic Compatibility	EMC
Electronic Thermal Relay	ETR
drive	FC
Gram	g
Hertz	Hz
Kilohertz	kHz
Local Control Panel	LCP
Meter	m
Millihenry Inductance	mH
Milliampere	mA
Millisecond	ms
Minute	min
Motion Control Tool	MCT
Nanofarad	nF
Newton Meters	Nm
Nominal motor current	I <sub>M,N</sub>
Nominal motor frequency	f <sub>M,N</sub>
Nominal motor power	P <sub>M,N</sub>
Nominal motor voltage	U <sub>M,N</sub>
Parameter	par.
Protective Extra Low Voltage	PELV
Printed Circuit Board	PCB
Rated Inverter Output Current	I <sub>INV</sub>
Revolutions Per Minute	RPM
Second	s
Torque limit	T <sub>LIM</sub>
Volts	V

1.1.4. Definitions

**Frequency converter:**

D-TYPE

Size and type of the connected frequency converter (dependencies).

I<sub>VLT,MAX</sub>

The maximum output current.

I<sub>VLT,N</sub>

The rated output current supplied by the frequency converter.

U<sub>VLT,MAX</sub>

The maximum output voltage.

**Input:**

Control command

You can start and stop the connected motor by means of LCP and the digital inputs.

Functions are divided into two groups.

Functions in group 1 have higher priority than functions in group 2.

**Motor:**

f<sub>JOG</sub>

The motor frequency when the jog function is activated (via digital terminals).

f<sub>M</sub>

The motor frequency.

f<sub>MAX</sub>

The maximum motor frequency.

f<sub>MIN</sub>

The minimum motor frequency.

Group 1	Reset, Coasting stop, Reset and Coasting stop, Quick-stop, DC braking, Stop and the "Off" key.
Group 2	Start, Pulse start, Reversing, Start reversing, Jog and Freeze output

$f_{M,N}$ 

The rated motor frequency (nameplate data).

 $I_M$ 

The motor current.

 $I_{M,N}$ 

The rated motor current (nameplate data).

M-TYPE

Size and type of the connected motor (dependencies).

 $n_{M,N}$ 

The rated motor speed (nameplate data).

 $P_{M,N}$ 

The rated motor power (nameplate data).

 $T_{M,N}$ 


The rated torque (motor).

 $U_M$ 

The instantaneous motor voltage.

 $U_{M,N}$ 

The rated motor voltage (nameplate data).

Break-away torque $\eta_{VLT}$ 

The efficiency of the frequency converter is defined as the ratio between the power output and the power input.

Start-disable command

A stop command belonging to the group 1 control commands - see this group.

Stop command

See Control commands.

**References:**Analog Reference

A signal transmitted to the analog inputs 53 or 54, can be voltage or current.

Binary Reference

A signal transmitted to the serial communication port.

Preset Reference

A defined preset reference to be set from -100% to +100% of the reference range. Selection of eight preset references via the digital terminals.

Pulse Reference

A pulse frequency signal transmitted to the digital inputs (terminal 29 or 33).

Ref<sub>MAX</sub>

Determines the relationship between the reference input at 100% full scale value (typically 10 V, 20mA) and the resulting reference. The maximum reference value set in par. 3-03.

Ref<sub>MIN</sub>

Determines the relationship between the reference input at 0% value (typically 0V, 0mA, 4mA) and the resulting reference. The minimum reference value set in par. 3-02.

#### **Miscellaneous:**

##### Analog Inputs

The analog inputs are used for controlling various functions of the frequency converter.

There are two types of analog inputs:

Current input, 0-20 mA and 4-20 mA

Voltage input, 0-10 V DC (FC 301)

Voltage input, -10 - +10 V DC (FC 302).

##### Analog Outputs

The analog outputs can supply a signal of 0-20 mA, 4-20 mA.

##### Automatic Motor Adaptation, AMA

AMA algorithm determines the electrical parameters for the connected motor at standstill.

##### Brake Resistor

The brake resistor is a module capable of absorbing the brake power generated in regenerative braking. This regenerative braking power increases the intermediate circuit voltage and a brake chopper ensures that the power is transmitted to the brake resistor.

##### CT Characteristics

Constant torque characteristics used for all applications such as conveyor belts, displacement pumps and cranes.

##### Digital Inputs

The digital inputs can be used for controlling various functions of the frequency converter.

##### Digital Outputs

The frequency converter features two Solid State outputs that can supply a 24 V DC (max. 40 mA) signal.

##### DSP

Digital Signal Processor.

##### ETR

Electronic Thermal Relay is a thermal load calculation based on present load and time. Its purpose is to estimate the motor temperature.

##### Hiperface®

Hiperface® is a registered trademark by Stegmann.

##### Initialising

If initialising is carried out (par. 14-22), the frequency converter returns to the default setting.

##### Intermittent Duty Cycle

An intermittent duty rating refers to a sequence of duty cycles. Each cycle consists of an on-load and an off-load period. The operation can be either periodic duty or non-periodic duty.

##### LCP

The Local Control Panel (LCP) makes up a complete interface for control and programming of the frequency converter. The control panel is detachable and can be installed up to 3 metres from the frequency converter, i.e. in a front panel by means of the installation kit option.

##### lsb

Least significant bit.

##### msb

Most significant bit.

##### MCM

Short for Mille Circular Mil, an American measuring unit for cable cross-section. 1 MCM = 0.5067 mm<sup>2</sup>.

##### On-line/Off-line Parameters

Changes to on-line parameters are activated immediately after the data value is changed. Changes to off-line parameters are not activated until you enter [OK] on the LCP.

##### Process PID

The PID regulator maintains the desired speed, pressure, temperature, etc. by adjusting the output frequency to match the varying load.

##### Pulse Input/Incremental Encoder

An external, digital pulse transmitter used for feeding back information on motor speed. The encoder is used in applications where great accuracy in speed control is required.

##### RCD

Residual Current Device.

Set-up

You can save parameter settings in four Set-ups. Change between the four parameter Set-ups and edit one Set-up, while another Set-up is active.

SFAVM

Switching pattern called Stator Flux oriented Asynchronous Vector Modulation (par. 14-00).

Slip Compensation

The frequency converter compensates for the motor slip by giving the frequency a supplement that follows the measured motor load keeping the motor speed almost constant..

Smart Logic Control (SLC)

The SLC is a sequence of user defined actions executed when the associated user defined events are evaluated as true by the SLC. (Parameter group 13-xx).

FC Standard Bus

Includes RS 485 bus with FC protocol or MC protocol. See parameter 8-30.

Thermistor:

A temperature-dependent resistor placed where the temperature is to be monitored (frequency converter or motor).

Trip

A state entered in fault situations, e.g. if the frequency converter is subject to an over-temperature or when the frequency converter is protecting the motor, process or mechanism. Restart is prevented until the cause of the fault has disappeared and the trip state is cancelled by activating reset or, in some cases, by being programmed to reset automatically. Trip may not be used for personal safety.

Trip Locked

A state entered in fault situations when the frequency converter is protecting itself and requiring physical intervention, e.g. if the frequency converter is subject to a short circuit on the output. A locked trip can only be cancelled by cutting off mains, removing the cause of the fault, and reconnecting the frequency converter. Restart is prevented until the trip state is cancelled by activating reset or, in some cases, by being programmed to reset automatically. Trip may not be used for personal safety.

VT Characteristics

Variable torque characteristics used for pumps and fans.

VVCplus

If compared with standard voltage/frequency ratio control, Voltage Vector Control (VVC<sup>plus</sup>) improves the dynamics and the stability, both when the speed reference is changed and in relation to the load torque.

60° AVM

Switching pattern called 60°Asynchronous Vector Modulation (par. 14-00).

Power Factor

The power factor is the relation between I<sub>1</sub> and I<sub>RMS</sub>.

$$Power\ factor = \frac{\sqrt{3} \times U \times I_1 \cos\varphi}{\sqrt{3} \times U \times I_{RMS}}$$

The power factor for 3-phase control:

$$= \frac{I_1 \times \cos\varphi}{I_{RMS}} = \frac{I_1}{I_{RMS}} \text{ since } \cos\varphi = 1$$

The power factor indicates to which extent the frequency converter imposes a load on the mains supply.

$$I_{RMS} = \sqrt{I_1^2 + I_5^2 + I_7^2 + \dots + I_n^2}$$

The lower the power factor, the higher the I<sub>RMS</sub> for the same kW performance.

In addition, a high power factor indicates that the different harmonic currents are low.

The frequency converters' built-in DC coils produce a high power factor, which minimizes the imposed load on the mains supply.




The voltage of the frequency converter is dangerous whenever connected to mains. Incorrect installation of the motor, frequency converter or fieldbus may cause damage to the equipment, serious personal injury or death. Consequently, the instructions in this manual, as well as national and local rules and safety regulations, must be complied with.

**Safety Regulations**

1. The mains supply to the frequency converter must be disconnected whenever repair work is to be carried out. Check that the mains supply has been disconnected and that the necessary time has elapsed before removing motor and mains supply plugs.
2. The [OFF] button on the control panel of the frequency converter does not disconnect the mains supply and consequently it must not be used as a safety switch.
3. The equipment must be properly earthed, the user must be protected against supply voltage and the motor must be protected against overload in accordance with applicable national and local regulations.
4. The earth leakage current exceeds 3.5 mA.
5. Protection against motor overload is not included in the factory setting. If this function is desired, set par. *1-90 Motor Thermal Protection* to data value ETR trip 1 [4] or data value ETR warning 1 [3].
6. Do not remove the plugs for the motor and mains supply while the frequency converter is connected to mains. Check that the mains supply has been disconnected and that the necessary time has elapsed before removing motor and mains plugs.
7. Please note that the frequency converter has more voltage sources than L1, L2 and L3, when load sharing (linking of DC intermediate circuit) or external 24 V DC are installed. Check that all voltage sources have been disconnected and that the necessary time has elapsed before commencing repair work.


**Warning against unintended start**

1. The motor can be brought to a stop by means of digital commands, bus commands, references or a local stop, while the frequency converter is connected to mains. If personal safety considerations (e.g. risk of personal injury caused by contact with moving machine parts following an unintentional start) make it necessary to ensure that no unintended start occurs, these stop functions are not sufficient. In such cases the mains supply must be disconnected or the *Safe Stop* function must be activated.
2. The motor may start while setting the parameters. If this means that personal safety may be compromised (e.g. personal injury caused by contact with moving machine parts), motor starting must be prevented, for instance by use of the *Safe Stop* function or secure disconnection of the motor connection.
3. A motor that has been stopped with the mains supply connected, may start if faults occur in the electronics of the frequency converter, through temporary overload or if a fault in the power supply grid or motor connection is remedied. If unintended start must be prevented for personal safety reasons (e.g. risk of injury caused by contact with moving machine parts), the normal stop functions of the frequency converter are not sufficient. In such cases the mains supply must be disconnected or the *Safe Stop* function must be activated.



**NB!**  
When using the *Safe Stop* function, always follow the instructions in the *Safe Stop* section.

4. Control signals from, or internally within, the frequency converter may in rare cases be activated in error, be delayed or fail to occur entirely. When used in situations where safety is critical, e.g. when controlling the electromagnetic brake function of a hoist application, these control signals must not be relied on exclusively.



Touching the electrical parts may be fatal - even after the equipment has been disconnected from mains.

Also make sure that other voltage inputs have been disconnected, such as external 24 V DC, load sharing (linkage of DC intermediate circuit), as well as the motor connection for kinetic back up.

Systems where frequency converters are installed must, if necessary, be equipped with additional monitoring and protective devices according to the valid safety regulations, e.g. law on mechanical tools, regulations for the prevention of accidents etc. Modifications on the frequency converters by means of the operating software are allowed.

Hoisting applications:

FC functions for controlling mechanical brakes cannot be considered as a primary safety circuit. There must always be a redundancy for controlling external brakes.

**Protection Mode**

Once a hardware limit on motor current or dc-link voltage is exceeded the drive will enter "Protection mode". "Protection mode" means a change of the PWM modulation strategy and a low switching frequency to minimize losses. This continues 10 sec after the last fault and increases the reliability and the robustness of the drive while re-establishing full control of the motor.



In hoist applications "Protection mode" is not usable because the drive will usually not be able to leave this mode again and therefore it will extend the time before activating the brake – which is not recommendable.

The "Protection mode" can be disabled by setting parameter 14-26 "Trip Delay at Inverter Fault" to zero which means that the drive will trip immediately if one of the hardware limits is exceeded.

**NB!**

It is recommended to disable protection mode in hoisting applications (par. 14-26 = 0)



## 2. How to Programme

### 2.1. The Graphical and Numerical Local Control Panels

The easiest programming of the frequency converter is performed by the Graphical Local Control Panel (LCP 102). It is necessary to consult the frequency converter Design Guide, when using the Numeric Local Control Panel (LCP 101).

#### 2.1.1. How to Programme on the Graphical LCP

The following instructions are valid for the graphical LCP (LCP 102):


The control panel is divided into four functional groups:

1. Graphical display with Status lines.
2. Menu keys and indicator lights - changing parameters and switching between display functions.
3. Navigation keys and indicator lights (LEDs).
4. Operation keys and indicator lights (LEDs).

All data is displayed in a graphical LCP display, which can show up to five items of operating data while displaying [Status].

Display lines:

- a. **Status line:** Status messages displaying icons and graphic.1
- b. **Line 1-2:** Operator data lines displaying data defined or chosen by the user. By pressing the [Status] key, up to one extra line can be added.1
- c. **Status line:** Status messages displaying text.1




#### 2.1.2. The LCD-Display

The LCD-display has back light and a total of 6 alpha-numeric lines. The display lines show the direction of rotation (arrow), the chosen Set-up as well as the programming Set-up. The display is divided into 3 sections:

**Top section** shows up to 2 measurements in normal operating status.

The top line in the **Middle section** shows up to 5 measurements with related unit, regardless of status (except in the case of alarm/warning).

**Bottom section** always shows the state of the frequency converter in Status mode.



The Active Set-up (selected as the Active Set-up in par. 0-10) is shown. When programming another Set-up than the Active Set-up, the number of the programmed Set-up appears to the right.

### Display Contrast Adjustment

Press [status] and [▲] for darker display

Press [status] and [▼] for brighter display

Most parameter set-ups can be changed immediately via the control panel, unless a password has been created via par. 0-60 *Main Menu Password* or via par. 0-65 *Quick Menu Password*.

### Indicator lights (LEDs):

If certain threshold values are exceeded, the alarm and/or warning LED lights up. A status and alarm text appear on the control panel.


The ON LED is activated when the frequency converter receives mains voltage or via a DC bus terminal or 24 V external supply. At the same time, the back light is on.

- Green LED/On: Control section is working.
- Yellow LED/Warn.: Indicates a warning.
- Flashing Red LED/Alarm: Indicates an alarm.



### LCP keys

The control keys are divided into functions. The keys below the display and indicator lamps are used for parameter Set-up, including choice of display indication during normal operation.



[Status] indicates the status of the frequency converter and/or the motor. You can choose between 3 different readouts by pressing the [Status] key: 5 line readouts, 4 line readouts or Smart Logic Control.

Use [Status] for selecting the mode of display or for changing back to Display mode from either the Quick Menu mode, the Main Menu mode or Alarm mode. Also use the [Status] key to toggle single or double read-out mode.

[Quick Menu] allows quick access to different Quick Menus such as:

- My Personal Menu
- Quick Set-up
- Changes Made
- Loggings

Use [Quick Menu] for programming the parameters belonging to the Quick Menu. It is possible to switch directly between Quick Menu mode and Main Menu mode.

[Main Menu] is used for programming all parameters.

It is possible to switch directly between Main Menu mode and Quick Menu mode.

Parameter shortcut can be carried out by pressing down the [Main Menu] key for 3 seconds. The parameter shortcut allows direct access to any parameter.

[Alarm Log] displays an Alarm list of the five latest alarms (numbered A1-A5). To obtain additional details about an alarm, use the arrow keys to manoeuvre to the alarm number and press [OK]. You will now receive information about the condition of your frequency converter right before entering the alarm mode.

[Back] takes you to the previous step or layer in the navigation structure.

[Cancel] annuls your last change or command as long as the display has not been changed.

[Info] supplies information about a command, parameter, or function in any display window. [Info] provides detailed information whenever help is needed.

Exit info mode by pressing either [Info], [Back], or [Cancel].




**Navigation Keys**

The four navigation arrows are used to navigate between the different choices available in [Quick Menu], [Main Menu] and [Alarm Log]. Use the keys to move the cursor.

[OK] is used for choosing a parameter marked by the cursor and for enabling the change of a parameter.

**Local Control Key** for local control are found at the bottom of the control panel.



[Hand On] enables control of the frequency converter via the LCP. [Hand on] also starts the motor, and it is now possible to enter the motor speed data by means of the arrow keys. The key can be selected as Enable [1] or Disable [0] via par. 0-40 [Hand on] key on LCP.

External stop signals activated by means of control signals or a serial bus will override a "start" command via the LCP.

The following control signals will still be active when [Hand on] is activated:

- [Hand on] - [Off] - [Auto on]
- Reset
- Coasting stop inverse
- Reversing
- Set-up select bit 0- Set-up select bit 1
- Stop command from serial communication
- Quick stop
- DC brake

[Off] stops the connected motor. The key can be selected as Enable [1] or Disable [0] via par. 0-41 [Off] key on LCP. If no external stop function is selected and the [Off] key is inactive the motor can be stopped by disconnecting the voltage.

[Auto On] enables the frequency converter to be controlled via the control terminals and/or serial communication. When a start signal is applied on the control terminals and/or the bus, the frequency converter will start. The key can be selected as Enable [1] or Disable [0] via par. 0-42 [Auto on] key on LCP.


**NB!**  
An active HAND-OFF-AUTO signal via the digital inputs has higher priority than the control keys [Hand on] – [Auto on].

[Reset] is used for resetting the frequency converter after an alarm (trip). It can be selected as *Enable* [1] or *Disable* [0] via par. 0-43 *Reset Keys on LCP*.

The **parameter shortcut** can be carried out by holding down the [Main Menu] key for 3 seconds. The parameter shortcut allows direct access to any parameter.

### 2.1.3. Quick Transfer of Parameter Settings between Multiple Frequency Converters

Once the set-up of a frequency converter is complete, we recommend that you store the data in the LCP or on a PC via MCT 10 Set-up Software Tool.



#### Data storage in LCP:

1. Go to par. 0-50 *LCP Copy*
2. Press the [OK] key
3. Select "All to LCP"
4. Press the [OK] key

All parameter settings are now stored in the LCP indicated by the progress bar. When 100% is reached, press [OK].

You can now connect the LCP to another frequency converter and copy the parameter settings to this frequency converter as well.

#### Data transfer from LCP to frequency converter:

1. Go to par. 0-50 *LCP Copy*
2. Press the [OK] key
3. Select "All from LCP"
4. Press the [OK] key

The parameter settings stored in the LCP are now transferred to the frequency converter indicated by the progress bar. When 100% is reached, press [OK].

### 2.1.4. Display Mode

In normal operation, up to 5 different operating variables can be indicated continuously in the middle section: 1.1, 1.2, and 1.3 as well as 2 and 3.

### 2.1.5. Display Mode - Selection of Read-Outs

It is possible to toggle between three status read-out screens by pressing the [Status] key.

Operating variables with different formatting are shown in each status screen - see below.

The table shows the measurements you can link to each of the operating variables. Define the links via par. 0-20, 0-21, 0-22, 0-23, and 0-24.

Each readout parameter selected in par. 0-20 to par. 0-24 has its own scale and digits after a possible decimal point. By larger numeric value of a parameter fewer digits are displayed after the decimal point.

Ex.: Current readout  
5.25 A; 15.2 A 105 A.


Operating variable:	Unit:
Par. 16-00 Control Word	hex
Par. 16-01 Reference	[unit]
Par. 16-02 Reference	%
Par. 16-03 Status Word	hex
Par. 16-05 Main Actual Value	%
Par. 16-10 Power	[kW]
Par. 16-11 Power	[HP]
Par. 16-12 Motor Voltage	[V]
Par. 16-13 Frequency	[Hz]
Par. 16-14 Motor Current	[A]
Par. 16-16 Torque	Nm
Par. 16-17 Speed	[RPM]
Par. 16-18 Motor Thermal	%
Par. 16-20 Motor Angle	
Par. 16-30 DC Link Voltage	V
Par. 16-32 Brake Energy / s	kW
Par. 16-33 Brake Energy / 2 min	kW
Par. 16-34 Heatsink Temp.	C
Par. 16-35 Inverter Thermal	%
Par. 16-36 Inv. Nom. Current	A
Par. 16-37 Inv. Max. Current	A
Par. 16-38 SL Control State	
Par. 16-39 Control Card Temp.	C
Par. 16-40 Logging Buffer Full	
Par. 16-50 External Reference	
Par. 16-51 Pulse Reference	
Par. 16-52 Feedback	[Unit]
Par. 16-53 Digi Pot Reference	
Par. 16-60 Digital Input	bin
Par. 16-61 Terminal 53 Switch Setting	V
Par. 16-62 Analog Input 53	
Par. 16-63 Terminal 54 Switch Setting	V
Par. 16-64 Analog Input 54	
Par. 16-65 Analog Output 42	[mA]
Par. 16-66 Digital Output	[bin]
Par. 16-67 Freq. Input #29	[Hz]
Par. 16-68 Freq. Input #33	[Hz]
Par. 16-69 Pulse Output #27	[Hz]
Par. 16-70 Pulse Output #29	[Hz]
Par. 16-71 Relay Output	
Par. 16-72 Counter A	
Par. 16-73 Counter B	
Par. 16-80 Fieldbus CTW	hex
Par. 16-82 Fieldbus REF 1	hex
Par. 16-84 Comm. Option STW	hex
Par. 16-85 FC Port CTW 1	hex
Par. 16-86 FC Port REF 1	hex
Par. 16-90 Alarm Word	
Par. 16-92 Warning Word	
Par. 16-94 Ext. Status Word	

**Status screen I:**

This read-out state is standard after start-up or initialization.

Use [INFO] to obtain information about the measurement links to the displayed operating variables (1.1, 1.2, 1.3, 2 and 3).


See the operating variables shown in the screen in this illustration.



**Status screen II:**


See the operating variables (1.1, 1.2, 1.3 and 2) shown in the screen in this illustration.

In the example, Speed, Motor current, Motor power and Frequency are selected as variables in the first and second.



**Status screen III:**

This state displays the event and action of the Smart Logic Control. For further information, see section *Smart Logic Control*.



**2.1.6. Parameter Set-Up**

The frequency converter can be used for practically all assignments, which is why the number of parameters is quite large. The frequency converter offers a choice between two programming modes - a Main Menu and a Quick Menu mode.


The former provides access to all parameters. The latter takes the user through a few parameters making it possible to start operating the frequency converter.

Regardless of the mode of programming, you can change a parameter both in the Main Menu mode and in the Quick Menu mode.

**2.1.7. Quick Menu Key Functions**

Pressing [Quick Menus] The list indicates the different areas contained in the Quick menu.

Select *My Personal Menu* to display the chosen personal parameters. These parameters are selected in par. 0-25 *Personal Menu*. Up to 20 different parameters can be added in this menu.



Select *Quick setup* to go through a limited amount of parameters to get the motor running almost optimally. The default setting for the other parameters considers the desired control functions and the configuration of signal inputs/outputs (control terminals).

The selection of parameter is effected by means of the arrow keys. The parameters in the following table are accessible.



Parameter	Designation	Setting
0-01	Language	
1-20	Motor Power	[kW]
1-22	Motor Voltage	[V]
1-23	Motor Frequency	[Hz]
1-24	Motor Current	[A]
1-25	Motor Nominal Speed	[rpm]
5-12	Terminal 27 Digital Input	[0] No function*
1-29	Automatic Motor Adaptation (AMA)	[1] Enable complete AMA
3-02	Min Reference	[rpm]
3-03	Max Reference	[rpm]
3-41	Ramp 1 Ramp-up Time	[sec]
3-42	Ramp 1 Ramp-down Time	[sec]
3-13	Reference Site	

\* If terminal 27 is set to "no function", no connection to +24 V on terminal 27 is necessary.

Select *Changes made* to get information about:

- the last 10 changes. Use the [▲] [▼] navigation keys to scroll between the last 10 changed parameters.
- the changes made since default setting.

Select *Loggings* to get information about the display line read-outs. The information is shown as graphs.

Only display parameters selected in par. 0-20 and par. 0-24 can be viewed. It is possible to store up to 120 samples in the memory for later reference.

### 2.1.8. Initial Commissioning

The easiest way of carrying out the initial commissioning is by using the Quick Menu button and follow the quick set-up procedure using LCP 102 (read table from left to right):


2

Press			
		Q2 Quick Menu	
0-01 Language		Set language	
1-20 Motor power		Set Motor nameplate power	
1-22 Motor voltage		Set Nameplate voltage	
1-23 Motor frequency		Set Nameplate frequency	
1-24 Motor current		Set Nameplate current	
1-25 Motor nominal speed		Set Nameplate speed in RPM	
5-12 Terminal 27 Digital Input		If terminal default is <i>Coast inverse</i> it is possible to change this setting to <i>No function</i> . No connection to terminal 27 is then needed for running AMA	
1-29 Automatic Motor Adaptation		Set desired AMA function. Enable complete AMA is recommended	
3-02 Minimum reference		Set the minimum speed of the motor shaft	
3-03 Maximum reference		Set the maximum speed of the motor shaft	
3-41 Ramp1 up time		Set the ramping up time with reference to nominal motor speed (set in par. 1-25)	
3-42 Ramp1 down time		Set the ramping down time with reference to nominal motor speed (set in par. 1-25)	
3-13 Reference site		Set the site from where the reference must work	

### 2.1.9. Main Menu Mode

Start the Main Menu mode by pressing the [Main Menu] key. The read-out shown to the right appears on the display.

The middle and bottom sections on the display show a list of parameter groups which can be chosen by toggling the up and down buttons.



Each parameter has a name and number which remain the same regardless of the programming mode. In the Main Menu mode, the parameters are divided into groups. The first digit of the parameter number (from the left) indicates the parameter group number.

All parameters can be changed in the Main Menu. However, depending on the choice of configuration (par. 1-00), some parameters can be "missing". E.g. open loop hides all the PID parameters, and other enabled options make more parameter groups visible.

### 2.1.10. Parameter Selection


In the Main menu mode, the parameters are divided into groups. You select a parameter group by means of the navigation keys.

The following parameter groups are accessible:

Group no.	Parameter group:
0	Operation/Display
1	Load/Motor
2	Brakes
3	References/Ramps
4	Limits/Warnings
5	Digital In/Out
6	Analog In/Out
7	Controls
8	Comm. and Options
9	Profibus
10	CAN Fieldbus
11	Reserved Com. 1
12	Reserved Com. 2
13	Smart Logic
14	Special Functions
15	Drive Information
16	Data Readouts
17	Motor Feedb. Option

After selecting a parameter group, choose a parameter by means of the navigation keys.

The middle section on the display shows the parameter number and name as well as the selected parameter value.




### 2.1.11. Changing Data

The procedure for changing data is the same whether you select a parameter in the Quick menu or the Main menu mode. Press [OK] to change the selected parameter.

The procedure for changing data depends on whether the selected parameter represents a numerical data value or a text value.


### 2.1.12. Changing a Text Value

If the selected parameter is a text value, change the text value by means of the [▲] [▼] navigation keys.  
 The up key increases the value, and the down key decreases the value.  
 Place the cursor on the value you want to save and press [OK].




### 2.1.13. Changing a Group of Numeric Data Values

If the chosen parameter represents a numeric data value, change the chosen data value by means of the [◀] [▶] navigation keys as well as the [▲] [▼] navigation keys. Use the [◀] [▶] navigation keys to move the cursor horizontally.




Use the [▲] [▼] navigation keys to change the data value. The up key enlarges the data value, and the down key reduces the data value. Place the cursor on the value you want to save and press [OK].



### 2.1.14. Infinitely Variable Change of Numeric Data Value

If the chosen parameter represents a numeric data value, select a digit by means of the [◀] [▶] navigation keys.



Change the selected digit infinitely variably by means of the [▲] [▼] navigation keys.

The chosen digit is indicated by the cursor. Place the cursor on the digit you want to save and press [OK].



### 2.1.15. Changing a Data Value, Step-by-Step

Certain parameters can be changed step by step or infinitely varying. This applies to *Motor Power* (par. 1-20), *Motor Voltage* (par. 1-22) and *Motor Frequency* (par. 1-23).

The parameters are changed both as a group of numeric data values and as numeric data values infinitely varying.

### 2.1.16. Read-out and Programming of Indexed Parameters

Parameters are indexed when placed in a rolling stack.

Par. 15-30 to 15-32 contain a fault log which can be read out. Choose a parameter, press [OK], and use the [▲] [▼] navigation keys to scroll through the value log.

Use par. 3-10 as another example:

Choose the parameter, press [OK], and use the [▲] [▼] navigation keys to scroll through the indexed values. To change the parameter value, select the indexed value and press [OK]. Change the value by using the [▲] [▼] keys. Press [OK] to accept the new setting. Press [CANCEL] to abort. Press [Back] to leave the parameter.

### 2.1.17. How to Programme on the Numerical Local Control Panel

The following instructions are valid for the Numerical LCP (LCP 101).  
The control panel is divided into four functional groups:

1. Numerical display.
2. Menu keys and indicator lights - changing parameters and switching between display functions.
3. Navigation keys and indicator lights (LEDs).
4. Operation keys and indicator lights (LEDs).

**Display line:**

**Status line:** Status messages displaying icons and numeric value.

**Indicator lights (LEDs):**

- Green LED/On: Indicates if control section is on.
- Yellow LED/Wrn.: Indicates a warning.
- Flashing red LED/Alarm: Indicates an alarm.

**LCP keys**

[Menu] Select one of the following modes:




- Status
- Quick Setup
- Main Menu

**Status Mode:** Displays the status of the frequency converter or the motor.

If an alarm occurs the NLCP automatically switches to status mode.

A number of alarms can be displayed.

**NB!**  
Parameter copy is not possible with LCP 101 Numerical Local Control Panel.



Main Menu/ Quick Setup is used for programming all parameters or only the parameters in the Quick Meny (see also description of the LCP 102 earlier in this chapter).

The parameter values can be changed using the [▲] [▼] keys when the value is flashing.

Select Main Menu by pressing [Menu] key a number of times.

Select the parameter group [xx-\_\_] and press [OK]

Select the parameter [\_\_-xx] and press [OK]

If the parameter is an array parameter select the array number and press [OK]

Select the wanted data value and press [OK]

Parameters with functional choices display values such as [1], [2], etc.

For a description of the different choices, see the individual description of the parameters in the *Parameter Selection* section




[Back] for stepping backwards

Arrow [▲] [▼] keys are used for manoeuvring between commands and within parameters.

### 2.1.18. Local Control Keys

Keys for local control are found at the bottom of the control panel.



[Hand on] enables control of the frequency converter via the LCP. [Hand on] also starts the motor and it is now possible to enter the motor speed data by means of the arrow keys. The key can be selected as Enable [1] og Disable [0] via par. 0-40 *[Hand on] Key on LCP.*

External stop signals activated by means of control signals or a serial bus will override a 'start' command via the LCP.

The following control signals will still be active when [Hand on] is activated:

- [Hand on] - [Off] - [Auto on]
- Reset
- Coasting stop inverse
- Reversing
- Set-up select lsb - Set-up select msb
- Stop command from serial communication
- Quick stop
- DC brake

[Off] stops the connected motor. The key can be selected as Enable [1] or Disable [0] via par. 0-41 *[Off] Key on LCP.*

If no external stop function is selected and the [Off] key is inactive the motor can be stopped by disconnecting the voltage.

[Auto on] enables the frequency converter to be controlled via the control terminals and/or serial communication. When a start signal is applied on the control terminals and/or the bus, the frequency converter will start. The key can be selected as Enable [1] or Disable [0] via par. 0-42 *[Auto on] Key on LCP.*

**NB!**  
An active HAND-OFF-AUTO signal via the digital inputs has higher priority than the control keys [Hand on] [Auto on].

[Reset] is used for resetting the frequency converter after an alarm (trip). It can be selected as Enable [1] or Disable [0] via par. 0-43 *Reset Keys on LCP*.

### 2.1.19. Initialisation to Default Settings

Initialise the frequency converter to default settings in two ways:

Recommended initialisation (via par. 14-22)

1. Select par. 14-22
2. Press [OK]
3. Select "Initialisation"
4. Press [OK]
5. Cut off the mains supply and wait until the display turns off.
6. Reconnect the mains supply - the frequency converter is now reset.

Par. 14-22 initialises all except:

14-50	<i>RFI 1</i>
8-30	<i>Protocol</i>
8-31	<i>Address</i>
8-32	<i>Baud Rate</i>
8-35	<i>Minimum Response Delay</i>
8-36	<i>Max Response Delay</i>
8-37	<i>Max Inter-char Delay</i>
15-00 to 15-05	<i>Operating data</i>
15-20 to 15-22	<i>Historic log</i>
15-30 to 15-32	<i>Fault log</i>

Manual initialisation

1. Disconnect from mains and wait until the display turns off.
- 2a. Press [Status] - [Main Menu] - [OK] at the same time while power up for LCP 102, Graphical Display
- 2b. Press [Menu] while power up for LCP 101, Numerical Display
3. Release the keys after 5 s.
4. The frequency converter is now programmed according to default settings.

This parameter initialises all except:

15-00	<i>Operating Hours</i>
15-03	<i>Power-up's</i>
15-04	<i>Over temp's</i>
15-05	<i>Over volt's</i>



**NB!**

When you carry out manual initialisation, you also reset serial communication, RFI filter settings (par. 14-50) and fault log settings.



## 2.2. Parameter Selection

Parameters for FC 300 are grouped into various parameter groups for easy selection of the correct parameters for optimized operation of the frequency converter.

0-xx Operation and Display parameters

- Basic Settings, set-up handling
- Display and Local Control Panel parameters for choosing readouts, setting up selections and copying functions

1-xx Load and Motor parameters includes all load and motor related parameters

2-xx Brake parameters

- DC brake
- Dynamic brake (Resistor brake)
- Mechanical brake
- Over Voltage Control

3-xx References and ramping parameters includes DigiPot function

4-xx Limits Warnings; setting of limits and warning parameters

5-xx Digital inputs and outputs includes relay controls

6-xx Analog inputs and outputs

7-xx Controls; Setting parameters for speed and process controls

8-xx Communication and option parameters for setting of FC RS485 and FC USB port parameters.

9-xx Profibus parameters

10-xx DeviceNet and CAN Fieldbus parameters

13-xx Smart Logic Control parameters

14-xx Special function parameters

15-xx Drive information parameters

16-xx Read out parameters

17-xx Encoder Option parameters

## 2.3. Parameters: Operation and Display

### 2.3.1. 0-\*\*\* Operation / Display

Parameters related to the fundamental functions of the frequency converter, function of the LCP buttons and configuration of the LCP display.

### 2.3.2. 0-0\* Basic Settings

Parameter group for basic frequency converter settings.

#### 0-01 Language

##### Option:

##### Function:

Defines the language to be used in the display.

The frequency converter can be delivered with 4 different language packages. English and German are included in all packages. English cannot be erased or manipulated.

[0] *	English	Part of Language packages 1 - 4
[1]	German	Part of Language packages 1 - 4
[2]	French	Part of Language package 1
[3]	Danish	Part of Language package 1
[4]	Spanish	Part of Language package 1
[5]	Italian	Part of Language package 1
[6]	Swedish	Part of Language package 1
[7]	Dutch	Part of Language package 1
[10]	Chinese	Language package 2
[20]	Finnish	Part of Language package 1
[22]	English US	Part of Language package 4
[27]	Greek	Part of Language package 4
[28]	Portuguese	Part of Language package 4
[36]	Slovenian	Part of Language package 3
[39]	Korean	Part of Language package 2
[40]	Japanese	Part of Language package 2
[41]	Turkish	Part of Language package 4
[42]	Traditional Chinese	Part of Language package 2
[43]	Bulgarian	Part of Language package 3
[44]	Serbian	Part of Language package 3
[45]	Romanian	Part of Language package 3
[46]	Hungarian	Part of Language package 3
[47]	Czech	Part of Language package 3
[48]	Polish	Part of Language package 4
[49]	Russian	Part of Language package 3
[50]	Thai	Part of Language package 2
[51]	Bahasa Indonesian	Part of Language package 2

#### 0-02 Motor Speed Unit

##### Option:

##### Function:

This parameter cannot be adjusted while the motor is running.

The display showing depends on settings in parameter 0-02 and 0-03. The default setting of parameters 0-02 and 0-03 depends on which region of the world the frequency converter is supplied to, but can be re-programmed as required.

**NB!**

Changing the *Motor Speed Unit* will reset certain parameters to their initial value. It is recommended to select the motor speed unit first, before modifying other parameters.

[0]	RPM	Selects display of motor speed variables and parameters (i.e. references, feedbacks and limits) in terms of motor speed (RPM).
[1] *	Hz	Selects display of motor speed variables and parameters (i.e. references, feedbacks and limits) in terms of output frequency to the motor (Hz).

### 0-03 Regional Settings

**Option:****Function:**

[0] *	International	Sets par.1-20 <i>Motor Power</i> units to kW and the default value of par. 1-23 <i>Motor Frequency</i> to 50 Hz.
[1]	US	Sets par.1-21 <i>Motor Power</i> units to HP and the default value of par. 1-23 <i>Motor Frequency</i> to 60 Hz.

This parameter cannot be adjusted while the motor is running.

### 0-04 Operating State at Power-up (Hand)

**Option:****Function:**

Select the operating mode upon reconnection of the frequency converter to mains voltage after power down in Hand (local) operation mode.

[0]	Resume	Restarts the frequency converter maintaining the same local reference and the same start/stop settings (applied by [START/STOP]) as before the frequency converter was powered down.
[1] *	Forced stop, ref=old	Restarts the frequency converter with a saved local reference, after mains voltage reappears and after pressing [START].
[2]	Forced stop, ref = 0	Resets the local reference to 0 upon restarting the frequency converter.

### 2.3.3. 0-1\* Set-up Operations

Define and control the individual parameter setups.

The frequency converter has four parameter setups that can be programmed independently of each other. This makes the frequency converter very flexible and able to solve advanced control functionality problems, often saving the cost of external control equipment. For example these can be used to program the frequency converter to operate according to one control scheme in one setup (e.g. motor 1 for horizontal movement) and another control scheme in another setup (e.g. motor 2 for vertical movement). Alternatively they can be used by an OEM machine builder to identically program all their factory fitted frequency converters for different machine types within a range to have the same parameters and then during production/commissioning simply select a specific setup depending on which machine the frequency converter is installed on.

The active setup (i.e. the setup in which the frequency converter is currently operating) can be selected in parameter 0-10 and is displayed in the LCP. Using Multi set-up it is possible to switch between setups with the frequency converter running or stopped, via digital input or serial communication commands. If it is necessary to change setups whilst running, ensure parameter 0-12 is programmed as required. Using parameter 0-11 it is possible to edit parameters within any of the setups whilst continuing the frequency converter operation in its Active Setup which can be a different setup to that being edited. Using parameter 0-51 it is possible to copy parameter settings between the setups to enable quicker commissioning if similar parameter settings are required in different setups.

### 0-10 Active Set-up

**Option:****Function:**

Select the set-up to control the frequency converter functions.

[0]	Factory setup	Cannot be changed. It contains the Danfoss data set, and can be used as a data source when returning the other set-ups to a known state.
[1] *	Set-up 1	<i>Set-up 1</i> [1] to <i>Set-up 4</i> [4] are the four separate parameter set-ups within which all parameters can be programmed.
[2]	Set-up 2	
[3]	Set-up 3	
[4]	Set-up 4	

- [9] Multi set-up Remote selection of set-ups using digital inputs and the serial communication port. This set-up uses the settings from par. 0-12 'This option linked to'. Stop the frequency converter before making changes to open- and closed loop functions

Use par. 0-51 *Set-up copy* to copy a set-up to one or all other set-ups. Stop the frequency converter before switching between set-ups where parameters marked 'not changeable during operation' have different values. To avoid conflicting settings of the same parameter within two different set-ups, link the set-ups together using par. 0-12 *This set-up linked to*. Parameters which are 'not changeable during operation' are marked FALSE in the parameter lists in the section *Parameter Lists*.


### 0-11 Edit Set-up

**Option:**

**Function:**

Select the set-up to be edited (i.e. programmed) during operation; either the active set-up or one of the inactive set-ups.

[0]	Factory setup	Cannot be edited but it is useful as a data source to return the other set-ups to a known state.
[1] *	Set-up 1	<i>Set-up 1</i> [1] to <i>Set-up 4</i> [4] can be edited freely during operation, independently of the active set-up.
[2]	Set-up 2	
[3]	Set-up 3	
[4]	Set-up 4	
[9]	Active Set-up	Can also be edited during operation. Edit the chosen set-up from a range of sources: LCP, FC RS485, FC USB or up to five fieldbus sites.



### 0-12 This Set-up Linked to

**Option:**

**Function:**


To enable conflict-free changes from one set-up to another during operation, link set-ups containing parameters which are not changeable during operation. The link will ensure synchronising of the 'not changeable during operation' parameter values when moving from one set-up to another during operation. 'Not changeable during operation' parameters can be identified by the label FALSE in the parameter lists in the section *Parameter Lists*.

The par. 0-12 link set-up feature is used by Multi set-up in par. 0-10 *Active Set-up*. Multi set-up is used to move from one set-up to another during operation (i.e. while the motor is running).

Example:


Use Multi set-up to shift from Set-up 1 to Set-up 2 whilst the motor is running. Programme in Set-up 1 first, then ensure that Set-up 1 and Set-up 2 are synchronised (or 'linked'). Synchronisation can be performed in two ways:

1. Change the edit set-up to *Set-up 2* [2] in par. 0-11 *Edit Set-up* and set par. 0-12 *This Set-up Linked to* to *Set-up 1* [1]. This will start the linking (synchronising) process.



OR

2. While still in Set-up 1, copy Set-up 1 to Set-up 2. Then set par. 0-12 to *Set-up 2* [2]. This will start the linking process.



After the link is complete, par. 0-13 *Readout: Linked Set-ups* will read {1,2} to indicate that all 'not changeable during operation' parameters are now the same in Set-up 1 and Set-up 2. If there are changes to a 'not changeable during operation' parameter, e.g. par 1-30 *Stator Resistance (R<sub>s</sub>)*, in Set-up 2, they will also be changed automatically in Set-up 1. A switch between Set-up 1 and Set-up 2 during operation is now possible.

[0] *	Not linked
[1]	Set-up 1
[2]	Set-up 2
[3]	Set-up 3
[4]	Set-up 4

**0-13 Readout: Linked Set-ups**

Array [5]

0\* [0 - 255] View a list of all the set-ups linked by means of par. 0-12 *This Set-up Linked to*. The parameter has one index for each parameter set-up. The parameter value displayed for each index represents which setups are linked to that parameter setup.

Index	LCP value
0	{0}
1	{1,2}
2	{1,2}
3	{3}
4	{4}

Table 2.1: Example: Set-up 1 and Set-up 2 are linked

**0-14 Readout: Edit Set-ups / Channe**

**Range:** 0\* [0 - FFF.FFF.FFF] **Function:** View the setting of par. 0-11 *Edit Set-up* for each of the four different communication channels. When the number is displayed in hex, as it is in the LCP, each number represents one channel. Numbers 1-4 represent a set-up number; 'F' means factory setting; and 'A' means active set-up. The channels are, from right to left: LCP, FC-bus, USB, HPFB1-5. Example: The number AAAAAA21h means that the FC bus selected Set-up 2 in par. 0-11, the LCP selected Set-up 1 and all others used the active set-up.

**2.3.4. 0-2\* LCP Display**

Define the variables displayed in the Graphical Local Control Panel.

**NB!**  
Please refer to parameters 0-37, 0-38 and 0-39 for information on how to write display texts

Select a variable for display in line 1, left position.		
[0]	None	No display value selected.
[953]	Profibus Warning Word	
[1005]	Readout Transmit Error Counter	
[1006]	Readout Receive Error Counter	
[1007]	Readout Bus Off Counter	
[1013]	Warning Parameter	
[1501]	Running Hours	
[1502]	kWh Counter	
[1600]	Control Word	Present control word
[1601]	Reference [Unit]	Total reference (sum of digital/analog/preset/bus/freeze ref./catch up and slow-down) in selected unit.
[1602]	Reference %	Total reference (sum of digital/analog/preset/bus/freeze ref./catch up and slow-down) in percent.
[1603]	Status Word	Present status word.
[1605]	Main Actual Value [%]	One or more warnings in a Hex code.
[1609]	Custom Readout	

[1610]	Power [kW]	Actual power consumed by the motor in kW.
[1611]	Power [hp]	Actual power consumed by the motor in HP.
[1612]	Motor Voltage	Voltage supplied to the motor.
[1613]	Frequency	Motor frequency, i.e. the output frequency from the frequency converter in Hz
[1614]	Motor Current	Phase current of the motor measured as effective value.
[1615]	Frequency [%]	Motor frequency, i.e. the output frequency from the frequency converter in percent.
[1616]	Torque	Present motor load as a percentage of the rated motor torque.
[1617] *	Speed [RPM]	Speed in RPM (revolutions per minute) i.e. the motor shaft speed in closed loop.
[1618]	Motor Thermal	Thermal load on the motor, calculated by the ETR function.
[1619]	KTY Sensor Temperature	
[1620]	Motor Angle	
[1621]	Phase Angle	
[1622]	Torque %	
[1630]	DC Link Voltage	Intermediate circuit voltage in the frequency converter.
[1632]	BrakeEnergy/s	Present brake power transferred to an external brake resistor. Stated as an instantaneous value.
[1633]	BrakeEnergy/2 min	Brake power transferred to an external brake resistor. The mean power is calculated continuously for the most recent 120 seconds.
[1634]	Heatsink Temp.	Present heat sink temperature of the frequency converter. The cut-out limit is $95 \pm 5$ °C; cutting back in occurs at $70 \pm 5$ °C.
[1635]	Inverter Thermal	Percentage load of the inverters.
[1636]	Inv. Nom. Current	Nominal current of the frequency converter.
[1637]	Inv. Max. Current	Maximum current of the frequency converter.
[1638]	SL Control State	State of the event executed by the control.
[1639]	Control Card Temp.	Temperature of the control card.
[1650]	External Reference	Sum of the external reference as a percentage, i.e. the sum of analog/pulse/bus.
[1651]	Pulse Reference	Frequency in Hz connected to the digital inputs (18, 19 or 32, 33).
[1652]	Feedback [Unit]	Reference value from programmed digital input(s).
[1653]	Digi Pot Reference	
[1660]	Digital Input	Signal states form the 6 digital terminals (18, 19, 27, 29, 32 and 33). Input 18 corresponds to the bit at the far left. Signal low = 0; Signal high = 1.
[1661]	Terminal 53 Switch Setting	Setting of input terminal 54. Current = 0; Voltage = 1.
[1662]	Analog Input 53	Actual value at input 53 either as a reference or protection value.
[1663]	Terminal 54 Switch Setting	Setting of input terminal 54. Current = 0; Voltage = 1.
[1664]	Analog Input 54	Actual value at input 54 either as reference or protection value.
[1665]	Analog Output 42 [mA]	Actual value at output 42 in mA. Use par. 6-50 to select the value to be shown.
[1666]	Digital Output [bin]	Binary value of all digital outputs.
[1667]	Freq. Input #29 [Hz]	Actual value of the frequency applied at terminal 29 as an impulse input.
[1668]	Freq. Input #33 [Hz]	Actual value of the frequency applied at terminal 33 as an impulse input.
[1669]	Pulse Output #27 [Hz]	Actual value of impulses applied to terminal 27 in digital output mode.
[1670]	Pulse Output #29 [Hz]	Actual value of impulses applied to terminal 29 in digital output mode.
[1671]	Relay Output [bin]	
[1672]	Counter A	
[1673]	Counter B	
[1674]	Prec. Stop Counter	

[1680]	Fieldbus CTW 1	Control word (CTW) received from the Bus Master.
[1682]	Fieldbus REF 1	Main reference value sent with control word from the Bus Master.
[1684]	Comm. Option STW	Extended fieldbus communication option status word.
[1685]	FC Port CTW 1	Control word (CTW) received from the Bus Master.
[1686]	FC Port REF 1	Status word (STW) sent to the Bus Master.
[1690]	Alarm Word	One or more alarms in a Hex code.
[1691]	Alarm Word 2	One or more alarms in a Hex code.
[1692]	Warning Word	One or more warnings in a Hex code.
[1693]	Warning Word 2	One or more warnings in a Hex code.
[1694]	Ext. Status Word	One or more status conditions in a Hex code.
[1695]	Ext. Status Word 2	One or more status conditions in a Hex code.
[3401]	PCD 1 Write to MCO	
[3402]	PCD 2 Write to MCO	
[3403]	PCD 3 Write to MCO	
[3404]	PCD 4 Write to MCO	
[3405]	PCD 5 Write to MCO	
[3406]	PCD 6 Write to MCO	
[3407]	PCD 7 Write to MCO	
[3408]	PCD 8 Write to MCO	
[3409]	PCD 9 Write to MCO	
[3410]	PCD 10 Write to MCO	
[3421]	PCD 1 Read from MCO	
[3422]	PCD 2 Read from MCO	
[3423]	PCD 3 Read from MCO	
[3424]	PCD 4 Read from MCO	
[3425]	PCD 5 Read from MCO	
[3426]	PCD 6 Read from MCO	
[3427]	PCD 7 Read from MCO	
[3428]	PCD 8 Read from MCO	
[3429]	PCD 9 Read from MCO	
[3430]	PCD 10 Read from MCO	
[3440]	Digital Inputs	
[3441]	Digital Outputs	
[3450]	Actual Position	
[3451]	Commanded Position	
[3452]	Actual Master Position	
[3453]	Slave Index Position	
[3454]	Master Index Position	
[3455]	Curve Position	
[3456]	Track Error	
[3457]	Synchronizing Error	
[3458]	Actual Velocity	
[3459]	Actual Master Velocity	
[3460]	Synchronizing Status	
[3461]	Axis Status	
[3462]	Program Status	
[9913]	Idle Time	



[9914] Paramdb Requests in Queue

[1675] Analog input X30/11

[1676] Analog input X30/12

[1677] Analog output X30/8 mA

### 0-20 Display Line 1.1 Small

**Option:**

[1617] \* Speed [RPM]

**Function:**

Select a variable for display in line 1, middle position. The options are the same as listed for par. 0-2\*.

### 0-21 Display Line 1.2 Small

**Option:**

[1614] \* Motor Current [A]

**Function:**

Select a variable for display in line 1, middle position. The options are the same as listed for par. 0-2\*.

### 0-22 Display Line 1.3 Small

**Option:**

[1610] \* Power [kW]

**Function:**

Select a variable for display in line 1, right position. The options are the same as listed for par. 0-2\*.

### 0-23 Display Line 2 Large

**Option:**

[1613] \* Frequency [Hz]

**Function:**

Select a variable for display in line 2. The options are the same as those listed for par. 0-2\*.

### 0-24 Display Line 3 Large

**Option:**

[1502] \* Counter [kWh]

**Function:**

Select a variable for display in line 2.

The options are the same as those listed for par. 0-20 *Display Line 1.1 Small*.

### 0-25 My Personal Menu

Array [50]

[0 - 9999]

Define up to 50 parameters to appear in the Q1 Personal Menu, accessible via the [Quick Menu] key on the LCP. The parameters will be displayed in the Q1 Personal Menu in the order they are programmed into this array parameter. Delete parameters by setting the value to '0000'.

For example, this can be used to provide quick, simple access to just one or up to 50 parameters which require changing on a regular basis (e.g. for plant maintenance reasons) or by an OEM to enable simple commissioning of their equipment.


#### 2.3.5. LCP Custom Readout, Par. 0-3\*

It is possible to customize the display elements for various purposes: \*Custom Readout. Value proportional to speed (Linear, squared or cubed depending on unit selected in par. 0-30 *Custom Readout Unit*) \*Display Text. Text string stored in a parameter.

##### Custom Readout

The calculated value to be displayed is based on settings in par. 0-30, *Custom Readout Unit*, par. 0-31 *Custom Readout Min Value*, (linear only), par. 0-32, *Custom Readout Max Value*, par. 4-13/4-14, *Motor Speed High Limit* and actual speed.

2



The relation will depend on the type of unit selected in par.0-30, Custom Readout Unit:

Unit Type	Speed Relation
Dimensionless	Linear
Speed	
Flow, volume	
Flow, mass	
Velocity	
Length	
Temperature	
Pressure	Quadratic
Power	Cubic

**0-30 Custom Readout Unit**

**Option:**

**Function:**

It is possible to program a value to be shown in the display of the LCP. The value will have a linear, squared or cubed relation to speed. This relation will depend on the unit selected (see table above). The actual calculated value can be read in *Custom Readout*, par. 16-09, and/or shown in the display by selecting Custom Readout [16-09] in par. 0-20 – 0-24, Display Line X.X Small (large).

Dimensionless:	
[0] *	None
[1]	%
[5]	PPM
Speed:	
[10]	1/min
[11]	RPM
[12]	Pulse/s
Flow, volume:	
[20]	l/s
[21]	l/min
[22]	l/h
[23]	m <sup>3</sup> /s
[24]	m <sup>3</sup> /min
[25]	m <sup>3</sup> /h

	Flow, mass:
[30]	kg/s
[31]	kg/min
[32]	kg/h
[33]	ton/min
[34]	ton/h
	Velocity:
[40]	m/s
[41]	m/min
	Length:
[45]	m
	Temperature:
[60]	° C
	Pressure:
[70]	mbar
[71]	bar
[72]	Pa
[73]	kPa
[74]	m WG
	Power:
[80]	kW
	Flow, volume:
[120]	GPM
[121]	gal/s
[122]	gal/min
[123]	gal/h
[124]	CFM
[125]	ft <sup>3</sup> /s
[126]	ft <sup>3</sup> /min
[127]	ft <sup>3</sup> /h
	Flow, mass:
[130]	lb/s
[131]	lb/min
[132]	lb/h
	Velocity:
[140]	ft/s
[141]	ft/min
	Length:
[145]	ft
	Temperature:
[160]	° F
	Pressure:
[170]	psi
[171]	lb/in <sup>2</sup>
[170]	in WG
[173]	ft WG
	Power:

[180] HP

**0-31 Custom Readout Min Value****Range:**

0.00 [0 - par. 0 - 32]

**Function:**

This parameter sets the min. value of the custom defined readout (occurs at zero speed). Only possible to set different from 0 is when selecting a linear unit in *Custom Readout Unit*, par. 0-30. For Quadratic and Cubic units the minimum value will be 0.

**0-32 Custom Readout Max Value****Range:**

100.00\* [Par. 0-31 - 999999.99 ]

**Function:**

This parameter sets the max value to be shown when the speed of the motor has reached the set value for *Motor Speed High Limit*, (par.4-13/4-14).

**2.3.6. LCP Keypad, 0-4\***

Enable, disable and password protect individual keys on the LCP keypad.

**0-40 [Hand on] Key on LCP****Option:**

[0] Disabled

**Function:**

No function

[1] \* Enabled

[Hand on] Key enabled

[2] Password

Avoid unauthorized start in Hand mode. If par. 0-40 is included in the My Personal Menu, then define the password in *par. 0-65 Personal Menu Password*. Otherwise define the password in *par. 0-60 Main Menu Password*.

**0-41 [Off] Key on LCP****Option:**

[0] Disabled

**Function:**

Avoids accidental stop of the frequency converter.

[1] \* Enabled

[2] Password

Avoids unauthorised stop. If par. 0-41 is included in the Quick Menu, then define the password in par. 0-65 *Quick Menu Password*.

**0-42 [Auto on] Key on LCP****Option:**

[0] Disabled

**Function:**

avoid accidental start of the frequency converter in Auto mode.

[1] \* Enabled

[2] Password

Avoids unauthorised start in Auto mode. If par. 0-42 is included in the Quick Menu, then define the password in par. 0-65 *Quick Menu Password*.

**0-43 [Reset] Key on LCP****Option:**

[0] Disabled

**Function:**

Avoids accidental alarm reset.

[1] \* Enabled

[2] Password

Avoids unauthorised resetting. If par. 0-43 is included in the Quick Menu, then define the password in par. 0-65 *Quick Menu Password*.

### 2.3.7. 0-5\* Copy / Save

Copy parameter settings between set-ups and to/from the LCP.

#### 0-50 LCP Copy

Option:	Function:
[0] * No copy	
[1] All to LCP	Copies all parameters in all set-ups from the frequency converter memory to the LCP memory.
[2] All from LCP	Copies all parameters in all set-ups from the LCP memory to the frequency converter memory.
[3] Size indep. from LCP	copy only the parameters that are independent of the motor size. The latter selection can be used to programme several frequency converters with the same function without disturbing motor data.
[4] File from MCO to LCP	
[5] File from LCP to MCO	

This parameter cannot be adjusted while the motor is running.

#### 0-51 Set-up Copy

Option:	Function:
[0] * No copy	No function
[1] Copy to set-up 1	Copies all parameters in the present edit set-up (defined in par. 0-11 <i>Edit Set-up</i> ) to Set-up 1.
[2] Copy to set-up 2	Copies all parameters in the present edit set-up (defined in par. 0-11 <i>Edit Set-up</i> ) to Set-up 2.
[3] Copy to set-up 3	Copies all parameters in the present edit set-up (defined in par. 0-11 <i>Edit Set-up</i> ) to Set-up 3.
[4] Copy to set-up 4	Copies all parameters in the present edit set-up (defined in par. 0-11 <i>Edit Set-up</i> ) to Set-up 4.
[9] Copy to all	Copies the parameters in the present set-up over to each of the set-ups 1 to 4.

### 2.3.8. 0-6\* Password

Define password access to menus.

#### 0-60 Main Menu Password

Option:	Function:
[100] * -9999 - 9999	Define the password for access to the Main Menu via the [Main Menu] key. If par. 0-61 <i>Access to Main Menu w/o Password</i> is set to <i>Full access</i> [0], this parameter will be ignored.

#### 0-61 Access to Main Menu w/o Password

Option:	Function:
[0] * Full access	Disables password defined in par. 0-60 <i>Main Menu Password</i> .
[1] Read only	Prevent unauthorized editing of Main Menu parameters.
[2] No access	Prevent unauthorized viewing and editing of Main Menu parameters.
[3] Bus: Read only	Read only functions for parameters on fieldbus and/ or FC standard bus.
[4] Bus: No access	No access to parameters is allowed via fieldbus and/ or FC standard bus.
[5] All: Read only	Read only function for parameters on LCP, fieldbus or FC standard bus.
[6] All: No access	No access from LCP, fieldbus or FC standard bus is allowed.

If *Full access* [0] is selected then parameters 0-60, 0-65 and 0-66 will be ignored.

#### 0-65 Quick Menu Password

Range:	Function:
200* [-9999 - 9999]	Define the password for access to the Quick Menu via the [Quick Menu] key. If par. 0-66 <i>Access to Quick Menu w/o Password</i> is set to <i>Full access</i> [0], this parameter will be ignored.

### 0-66 Access to Quick Menu w/o Password

Option:	Function:
[0] * Full access	Disables the password defined in par. 0-65 <i>Quick Menu Password</i> .
[1] Read only	Prevents unauthorised editing of Quick Menu parameters.
[2] No access	Prevents unauthorised viewing and editing of Quick Menu parameters.
[3] Bus: Read only	Read only functions for parameters on fieldbus and/ or FC standard bus.
[4] Bus: No access	No access to parameters is allowed via fieldbus and/ or FC standard bus.
[5] All: Read only	read only function for parameters on LCP, fieldbus or FC standard bus.
[6] All: No access	No access from LCP, fieldbus or FC standard bus is allowed.

If par. 0-61 *Access to Main Menu w/o Password* is set to *Full access* [0] then this parameter will be ignored.

### 0-67 Bus Password Access

Range:	Function:
0* [0 - 9999]	Writing to this parameter enables users to unlock the frequency converter from bus/ MCT10

## 2.4. Parameters: Load and Motor

### 2.4.1. 1-0\* General Settings

Define whether the frequency converter operates in speed mode or torque mode; and whether the internal PID control should be active or not.

#### 1-00 Configuration Mode

Option:	Function:
[0] Speed open loop	Select the application control principle to be used when a Remote Reference (i.e. via analog input or fieldbus) is active. A Remote Reference can only be active when par. 3-13 <i>Reference Site</i> is set to [0] or [1]. Enables speed control (without feedback signal from motor) with automatic slip compensation for almost constant speed at varying loads. Compensations are active but can be disabled in the Load/Motor par. group 1-0*.
[1] Speed closed loop	Enables encoder feedback from motor. Obtain full holding torque at 0 RPM. For increased speed accuracy, provide a feedback signal and set the speed PID control.
[2] Torque	Connects the encoder speed feedback signal to the encoder input. Only possible with "Flux with motor feedback" option, par. 1-01 <i>Motor control principle</i> .
[3] Process	Enables the use of process control in the frequency converter. The process control parameters are set in par. groups 7-2* and 7-3*.

#### 1-01 Motor Control Principle

Option:	Function:
[0] U/f	Select which motor control principle to employ. special motor mode, for parallel connected motors in special motor applications. When U/f is selected the characteristic of the control principle can be edited in par. 1-55 and 1-56.
[1] VVCplus	Voltage Vector Control principle suitable for most applications. The main benefit of VVC <sup>plus</sup> operation is that it uses a robust motor model.
[2] Flux sensorless (FC 302 only)	Flux Vector control without encoder feedback, for simple installation and robustness against sudden load changes.
[3] Flux w/ motor feedback (FC 302 only)	very high accuracy speed and torque control, suitable for the most demanding applications.

The best shaft performance is normally achieved using either of the two Flux Vector control modes *Flux sensorless* [2] and *Flux with encoder feedback* [3].

This parameter cannot be adjusted while the motor is running.

#### 1-02 Flux Motor Feedback Source

Option:	Function:
[1] * 24 V encoder	Select the interface at which to receive feedback from the motor. A and B channel encoder, which can be connected to the digital input terminals 32/33 only. Terminals 32/33 must be programmed to <i>No operation</i> .
[2] MCB 102	Encoder module option which can be configured in par. group 17-1* This parameter appears in FC 302 only.
[3] MCB 103	Optional resolver interface module which can be configured in parameter group 17-5*
[4] MCO 305 encoder 1	Encoder interface 1 of the optional programmable motion controller MCO 305.
[5] MCO 305 encoder 2	encoder interface 2 of the optional programmable motion controller MCO 305.

This parameter cannot be adjusted while the motor is running.

### 1-03 Torque Characteristics

**Option:**
**Function:**

Select the torque characteristic required.  
VT and AEO are both energy saving operations.

[0] *	Constant torque	Motor shaft output provides constant torque under variable speed control.
[1]	Variable torque	Motor shaft output provides variable torque under variable speed control. Set the variable torque level in par. 14-40 <i>VT Level</i> .
[2]	Auto energy optim.	Automatically optimises energy consumption by minimising magnetisation and frequency via par. 14-41 <i>AEO Minimum Magnetisation</i> and par. 14-42 <i>Minimum AEO Frequency</i> .

This parameter cannot be adjusted while the motor is running.

### 1-04 Overload Mode

**Option:**
**Function:**

[0] \* High torque Allows up to 160% over torque.

[1] Normal torque For oversized motor - allows up to 110% over torque.

This parameter cannot be adjusted while the motor is running.

### 1-05 Local Mode Configuration

**Option:**
**Function:**

Select which application configuration mode (par. 1-00), i.e. application control principle, to use when a Local (LCP) Reference is active. A Local Reference can be active only when par. 3-13 *Reference Site* is set to [0] or [2]. By default the local reference is active in Hand Mode only.

[0]	Speed open loop
[1]	Speed closed loop
[2] *	As mode par. 1-00

#### 2.4.2. 1-1\* Motor selection

Parameter group for setting general motor data.

This parameter group cannot be adjusted while the motor is running.

### 1-10 Motor Construction

**Option:**
**Function:**

Select the motor construction type.

[0] *	Asynchronous	For asynchronous motors.
[1]	PM, non salient SPM (FC 302 only)	For permanent magnet (PM) motors. Note that PM motors are divided into two groups, with either surface mounted (non salient) or interior (salient) magnets.

Motor construction can either be asynchronous or permanent magnet (PM) motor.

#### 2.4.3. 1-2\* Motor Data

Parameter group 1-2\* comprises input data from the nameplate on the connected motor.

Parameters in parameter group 1-2\* cannot be adjusted while the motor is running.



**NB!**  
Changing the value of these parameters affects the setting of other parameters.

**1-20 Motor Power**

**Range:**  
Size related\* [0.09 - 1200 kW]

**Function:**  
Enter the nominal motor power in kW according to the motor nameplate data. The default value corresponds to the nominal rated output of the unit.  
This parameter cannot be adjusted while the motor is running. This parameter is visible in LCP if par. 0-03 is *International* [0].

**NB!**  
Four sizes down, one size up from nominal VLT rating.

**1-21 Motor Power [HP]**

**Range:**  
Size related\* [0.09 - 500 HP]

**Function:**  
Enter the nominal motor power in HP according to the motor nameplate data. The default value corresponds to the nominal rated output of the unit. This parameter is visible in LCP if par. 0-03 is *US* [1]

**1-22 Motor Voltage**

**Range:**  
Size related\* [10 - 1000 V]

**Function:**  
Enter the nominal motor voltage according to the motor nameplate data. The default value corresponds to the nominal rated output of the unit.

**1-23 Motor Frequency**

**Option:**

**Function:**  
Min - Max motor frequency: 20 - 1000 Hz.  
Select the motor frequency value from the motor nameplate data. If a value different from 50 Hz or 60 Hz is selected, it is necessary to adapt the load independent settings in par. 1-50 to 1-53. For 87 Hz operation with 230/400 V motors, set the nameplate data for 230 V/50 Hz. Adapt par. 4-13 *Motor Speed High Limit [RPM]* and par. 3-03 *Maximum Reference* to the 87 Hz application.

[50] *	50 Hz when parameter 0-03 = international
[60]	60 Hz when parameter 0-03 = US

**1-24 Motor Current**

**Option:**  
[Motor type dependent.]

**Function:**  
Enter the nominal motor current value from the motor nameplate data. The data are used for calculating torque, motor protection etc.

**1-25 Motor Nominal Speed**

**Range:**  
Size related\* [10 - 60000 RPM]

**Function:**  
Enter the nominal motor speed value from the motor nameplate data. The data are used for calculating motor compensations.

**1-26 Motor Cont. Rated Torque**

**Range:**  
Size related [1.0 - 10000.0 Nm]

**Function:**  
Enter the value from the motor nameplate data. The default value corresponds to the nominal rated output. This parameter is available when par. 1-10 *Motor Construction* is set to *PM, non salient SPM* [1], i.e. the parameter is valid for PM and non-salient SPM motors only.

### 1-29 Automatic Motor Adaptation (AMA)

#### Option:

#### Function:

The AMA function optimises dynamic motor performance by automatically optimising the advanced motor parameters (par. 1-30 to par. 1-35) at motor standstill.

Activate the AMA function by pressing [Hand on] after selecting [1] or [2]. See also the section *Automatic Motor Adaptation* in the Design Guide. After a normal sequence, the display will read: "Press [OK] to finish AMA". After pressing the [OK] key the frequency converter is ready for operation.

This parameter cannot be adjusted while the motor is running.

[0] *	OFF	
[1]	Enable complete AMA	Performs AMA of the stator resistance $R_s$ , the rotor resistance $R_r$ , the stator leakage reactance $X_{l1}$ , the rotor leakage reactance $X_{l2}$ and the main reactance $X_h$ . Select this option if an LC filter is used between the frequency converter and the motor. <b>FC 301:</b> The Complete AMA does not include $X_h$ measurement for FC 301. Instead, the $X_h$ value is determined from the motor database. Par. 1-35 <i>Main Reactance (<math>X_h</math>)</i> may be adjusted to obtain optimal start performance.
[2]	Enable reduced AMA	Performs a reduced AMA of the stator resistance $R_s$ in the system only.

#### Note:

- For the best adaptation of the frequency converter, run AMA on a cold motor.
- AMA cannot be performed while the motor is running.
- AMA cannot be performed on permanent magnet motors.



#### NB!

It is important to set motor par. 1-2\* Motor Data correctly, since these form part of the AMA algorithm. An AMA must be performed to achieve optimum dynamic motor performance. It may take up to 10 min, depending on the power rating of the motor.



#### NB!

Avoid generating external torque during AMA.



#### NB!

If one of the settings in par. 1-2\* Motor Data is changed, par. 1-30 to 1-39, the advanced motor parameters, will return to default setting.



#### NB!

AMA will work problem-free on 1 motor size down, typically work on 2 motor sizes down, rarely work on 3 sizes down and never work on 4 sizes down. Please keep in mind that the accuracy of the measured motor data will be poorer when you operate on motors smaller than nominal VLT size.

#### 2.4.4. 1-3\* Adv. Motor Data

Parameters for advanced motor data. The motor data in par. 1-30 - par. 1-39 must match the relevant motor in order to run the motor optimally. The default settings are figures based on common motor parameter values from standard motors. If the motor parameters are not set correctly, a malfunction of the frequency converter system may occur. If the motor data is not known, running an AMA (Automatic Motor Adaptation) is recommended. See the *Automatic Motor Adaptation* section in the Design Guide. The AMA sequence will adjust all motor parameters except the moment of inertia of the rotor and the iron loss resistance (par. 1-36).

Parameters 1-3\* and 1-4\* cannot be adjusted while the motor is running.




Illustration 2.1: Motor equivalent diagram for an asynchronous motor

**1-30 Stator Resistance (Rs)**

**Range:**

Size related [Ohm]

**Function:**

Set the stator resistance value. Enter the value from a motor data sheet or perform an AMA on a cold motor.

**1-31 Rotor Resistance (Rr)**

**Range:**

Size related [Ohm]

**Function:**

Fine-tuning R<sub>r</sub> will improve shaft performance. Set the rotor resistance value using one of these methods:

1. Run an AMA on a cold motor. The frequency converter will measure the value from the motor. All compensations are reset to 100%.
2. Enter the R<sub>r</sub> value manually. Obtain the value from the motor supplier.
3. Use the R<sub>r</sub> default setting. The frequency converter establishes the setting on the basis of the motor nameplate data.

**1-33 Stator Leakage Reactance (X1)**

**Range:**

Size related [Ohm]

**Function:**

Set the stator leakage reactance of the motor using one of these methods:

1. Run an AMA on a cold motor. The frequency converter will measure the value from the motor.
2. Enter the X<sub>1</sub> value manually. Obtain the value from the motor supplier.
3. Use the X<sub>1</sub> default setting. The frequency converter establishes the setting on the basis of the motor name plate data.

**1-34 Rotor Leakage Reactance (X2)**

**Option:**

[Size related] Ohm

**Function:**

Set the rotor leakage reactance of the motor using one of these methods:

1. Run an AMA on a cold motor. The frequency converter will measure the value from the motor.
2. Enter the X<sub>2</sub> value manually. Obtain the value from the motor supplier.
3. Use the X<sub>2</sub> default setting. The frequency converter establishes the setting on the basis of the motor name plate data.

**1-35 Main Reactance (Xh)**

**Option:**

[Size related] Ohm

**Function:**

Set the main reactance of the motor using one of these methods:

1. Run an AMA on a cold motor. The frequency converter will measure the value from the motor.
2. Enter the X<sub>h</sub> value manually. Obtain the value from the motor supplier.
3. Use the X<sub>h</sub> default setting. The frequency converter establishes the setting on the basis of the motor name plate data.

### 1-36 Iron Loss Resistance ( $R_{Fe}$ )

**Range:**Size related [1 - 10.000  $\Omega$ ]**Function:**Enter the equivalent iron loss resistance ( $R_{Fe}$ ) value to compensate for iron loss in the motor.The  $R_{Fe}$  value cannot be found by performing an AMA.The  $R_{Fe}$  value is especially important in torque control applications. If  $R_{Fe}$  is unknown, leave par. 1-36 on default setting.

### 1-37 d-axis Inductance ( $L_d$ )

**Range:**

0.0mH [0.0 - 1000.0 mH]

**Function:**

Enter the value of the d-axis inductance. Obtain the value from the permanent magnet motor data sheet.

This parameter is only active when par. 1-10 *Motor construction* has the value *PM, non-salient SPM* [1] (Permanent Magnet Motor).

This parameter is available for FC 302 only.

### 1-39 Motor Poles

**Option:**

[4] \*

Depends on motor type

**Function:**

Value 2 - 100 poles

Enter the number of motor poles.

Poles	$\sim n_n @ 50 \text{ Hz}$	$\sim n_n @ 60 \text{ Hz}$
2	2700 - 2880	3250 - 3460
4	1350 - 1450	1625 - 1730
6	700 - 960	840 - 1153

The table shows the number of poles for normal speed ranges of various motor types. Define motors designed for other frequencies separately. The motor pole value is always an even number, because it refers to the total number of poles, not pairs of poles. The frequency converter creates the initial setting of par. 1-39 based on par. 1-23 *Motor Frequency* and par. 1-25 *Motor Nominal Speed*.

### 1-40 Back EMF at 1000 RPM

**Range:**

500 V\* [10 - 9000 V]

**Function:**Set the nominal back EMF for the motor when running at 1000 RPM. This parameter is only active when par. 1-10 *Motor construction* is set to *PM motor* [1] (Permanent Magnet Motor).

This parameter is available for FC 302 only.

**NB!**

When using PM motors, it is recommended to use brake resistors.

### 1-41 Motor Angle Offset

**Range:**

0\* [-32768 - 32768]

**Function:**Enter the correct offset angle between the PM motor and the index position (single-turn) of the attached encoder or resolver. The value range of 0 - 32768 corresponds to 0 - 2 \* pi (radians). To obtain the offset angle value: After frequency converter start-up apply DC-hold and enter the value of par. 16-20 *Motor Angle* into this parameter.This parameter is only active when par. 1-10 *Motor construction* is set to *PM, non-salient SPM* [1] (Permanent Magnet Motor).


#### 2.4.5. 1-5\* Load Indep. Setting

Parameters for setting the load-independent motor settings.

**1-50 Motor Magnetisation at Zero Speed**

**Range:**  
100% [0 - 300 %]

**Function:**  
Use this par. along with par. 1-51 *Min Speed Normal Magnetising [RPM]* to obtain a different thermal load on the motor when running at low speed.  
Enter a value which is a percentage of the rated magnetizing current. If the setting is too low, the torque on the motor shaft may be reduced.



**1-51 Min Speed Normal Magnetising [RPM]**

**Range:**  
15 RPM\* [10 - 300 RPM]

**Function:**  
Set the required speed for normal magnetising current. If the speed is set lower than the motor slip speed, par. 1-50 *Motor Magnetisation at Zero Speed* and par. 1-51 are of no significance.  
Use this par. along with par. 1-50. See drawing for par. 1-50.

**1-52 Min Speed Normal Magnetising [Hz]**

**Option:**  
[Size related] 0 - 250 Hz

**Function:**  
Set the required frequency for normal magnetising current. If the frequency is set lower than the motor slip frequency, par. 1-50 *Motor Magnetisation at Zero Speed* is inactive.  
Use this par. along with par. 1-50. See drawing for par. 1-50.

**1-53 Model Shift Frequency**

**Range:**  
Size related [4.0 - 50.0 Hz]

**Function:**  
**Flux Model shift**  
Enter the frequency value for shift between two models for determining motor speed. Choose the value based on settings in par. 1-00 *Configuration Mode* and par. 1-01 *Motor Control Principle*. There are two options: shift between Flux model 1 and Flux model 2; or shift between Variable Current mode and Flux model 2. This parameter is available for FC 302 only.  
This parameter cannot be adjusted while the motor is running.  
**Flux Model 1 – Flux model 2**  
This model is used when par. 1-00 is set to *Speed closed loop* [1] or *Torque* [2] and par. 1-01 is set to *Flux w/ motor feedback* [3]. With this parameter it is possible to make an adjustment of the shifting point where FC 302 changes between Flux model 1 and Flux model 2, which is useful in some sensitive speed and torque control applications.




Illustration 2.2: Par. 1-00 = [1] Speed closed loop or [2] Torque and par. 1-01 = [3] Flux w/motor feedback

**Variable Current - Flux model - Sensorless**

This model is used when par. 1-00 is set to *Speed open loop* [0] and par. 1-01 is set to *Flux sensorless* [2].

In speed open loop in flux mode, the speed is determined from the current measurement.

Below  $f_{norm} \times 0.1$ , the frequency converter runs on a Variable Current model. Above  $f_{norm} \times 0.125$  the frequency converter runs on a Flux model.




Illustration 2.3: Par. 1-00 = [0] Speed open loop, Par. 1-01 = [2] Flux sensorless

**1-55 U/f Characteristic - U**

**Range:**

Size related [0.0 - max. motor voltage]

**Function:**

Enter the voltage at each frequency point to manually form a U/f characteristic matching the motor. The frequency points are defined in par. 1-56 *U/f Characteristic - F*. This parameter is an array parameter [0-5] and is only accessible when par. 1-01 *Motor Control Principle* is set to *U/f*[0].


**1-56 U/f Characteristic - F**

**Range:**

Size related\* [0.0 - max. motor frequency]

**Function:**

Enter the frequency points to manually form a U/f-characteristic matching the motor. The voltage at each point is defined in par. 1-55 *U/f Characteristic - U*. This parameter is an array parameter [0-5] and is only accessible when par. 1-01 *Motor Control Principle* is set to *U/f*[0].



**2.4.6. 1-6\* Load Depend. Setting**

Parameters for adjusting the load-dependent motor settings.

**1-60 Low Speed Load Compensation**


**Range:**

100%\* [0 - 300%]

**Function:**

Enter the % value to compensate voltage in relation to load when the motor is running at low speed and obtain the optimum U/f characteristic. The motor size determines the frequency range within which this parameter is active.

Motor size	Change over
0.25 kW - 7.5 kW	< 10 Hz



**1-61 High Speed Load Compensation**

**Range:** 100%\* [0 - 300%]  
**Function:** Enter the % value to compensate voltage in relation to load when the motor is running at high speed and obtain the optimum U/f characteristic. The motor size determines the frequency range within which this parameter is active.

Motor size	Change-over
0.25 kW - 7.5 kW	> 10 Hz

**1-62 Slip Compensation**

**Range:** 100%\* [-500 - 500 %]  
**Function:** Enter the % value for slip compensation, to compensate for tolerances in the value of  $n_{M,N}$ . Slip compensation is calculated automatically, i.e. on the basis of the rated motor speed  $n_{M,N}$ . This function is not active when par. 1-00 *Configuration Mode* is set to *Speed closed loop*[1] or *Torque*[2] Torque control with speed feedback or when par. 1-01 *Motor Control Principle* is set to *U/f*[0] special motor mode.

**1-63 Slip Compensation Time Constant**

**Range:** 0.10s\* [0.05 - 5.00 s]  
**Function:** Enter the slip compensation reaction speed. A high value results in slow reaction, and a low value results in quick reaction. If low-frequency resonance problems arise, use a longer time setting.

**1-64 Resonance Dampening**

**Range:** 100%\* [0 - 500 %]  
**Function:** Enter the resonance dampening value. Set par. 1-64 and par. 1-65 *Resonance Dampening Time Constant* to help eliminate high-frequency resonance problems. To reduce resonance oscillation, increase the value of par. 1-64.

**1-65 Resonance Dampening Time Constant**

**Range:** 5 msec.\* [5 - 50 msec.]  
**Function:** Set par. 1-64 *Resonance Dampening* and par. 1-65 to help eliminate high-frequency resonance problems. Enter the time constant that provides the best dampening.

**1-66 Min. Current at Low Speed**

**Range:** 100%\* [0 - 200%]  
**Function:** Enter the minimum motor current at low speed, see par. 1-53 *Model Shift Frequency*. Increasing this current improves motor torque at low speed. Par. 1-66 is enabled when par. 1-00 *Configuration Mode* = *Speed open loop* [0] only. The frequency converter runs with constant current through motor for speeds below 10 Hz.

For speeds above 10 Hz, the motor flux model in the frequency converter controls the motor. Par. 4-16 *Torque Limit Motor Mode* and / or par. 4-17 *Torque Limit Generator Mode* automatically adjust par. 1-66. The parameter with the highest value adjusts par. 1-66. The current setting in par. 1-66 is composed of the torque generating current and the magnetizing current.

Example: Set par. 4-16 *Torque Limit for Motor Mode* to 100% and set par. 4-17 *Torque Limit for Generating Mode* to 60%. Par. 1-66 automatically adjusts to about 127%, depending on the motor size.

This parameter is available for FC 302 only.

### 1-67 Load Type

**Option:**

[0] \* Passive load

**Function:**

For conveyers, fan and pump applications.

[1] Active Load

For hoisting applications. When *Active Load* [1] is selected, set par. 1-66 Min. Current at Low Speed to a level which corresponds to maximum torque.

This parameter is available for FC 302 only.

### 1-68 Minimum Inertia

**Range:**

0.0048\* [0.0001 - Par. 1-69]

**Function:**

Enter the minimum moment of inertia of the mechanical system. Par. 1-68 and par. 1-69 *Maximum Inertia* are used for pre-adjustment of the Proportional Gain in the speed control, see par. 7-02 *Speed PID Proportional Gain*.

This parameter is available for FC 302 only.

This parameter cannot be adjusted while motor is running.

### 1-69 Maximum Inertia

**Range:**

0.0048\* [0 - 0.4800]

**Function:**

Enter the maximum moment of inertia of the mechanical system. Par. 1-68 *Minimum Inertia* and par. 1-69 are used for pre-adjustment of the Proportional Gain in the speed control, see par. 7-02 *Speed PID Proportional Gain*.

This parameter is available for FC 302 only.

This parameter cannot be adjusted while motor is running.

## 2.4.7. 1-7\* Start Adjustments

Parameters for setting special motor start features.

### 1-71 Start Delay

**Range:**

0.0s\* [0.0 - 10.0 s]

**Function:**

This parameter refers to the start function selected in par. 1-72 *Start Function*. Enter the time delay required before commencing acceleration.

### 1-72 Start Function

**Option:**

[0] DC hold/ delay time

**Function:**

Select the start function during start delay. This parameter is linked to par. 1-71 *Start Delay*.

[1] DC Brake/delay time

Energizes motor with a DC holding current (par. 2-00) during the start delay time.

[2] \* Coast/delay time

Releases shaft coasted converter during the start delay time (inverter off).

[3] Start speed/ current clockwise operation

Only possible with VVC+.

Connect the function described in par. 1-74 *Start Speed (RPM)* and par. 1-76 *Start Current* in the start delay time.

Regardless of the value applied by the reference signal, the output speed applies the setting of the start speed in par. 1-74 or par. 1-75 and the output current corresponds to the setting of the start current in par. 1-76 *Start*



*Current.* This function is typically used in hoisting applications without counterweight and especially in applications with a Cone-motor, where the start is clockwise, followed by rotation in the reference direction.

[4]	Horizontal operation	Only possible with VVC+. For obtaining the function described in par. 1-74 and par. 1-76 during the start delay time. The motor rotates in the reference direction. If the reference signal equals zero (0), par. 1-74 <i>Start speed (RPM)</i> is ignored and the output speed equals zero (0). The output current corresponds to the setting of the start current in par. 1-76 <i>Start current</i> .
[5]	VVC <sup>plus</sup> / Flux clockwise	for the function described in par. 1-74 only ( <i>Start speed in the start delay time</i> ). The start current is calculated automatically. This function uses the start speed in the start delay time only. Regardless of the value set by the reference signal, the output speed equals the setting of the start speed in par. 1-74. <i>Start speed/current clockwise</i> [3] and <i>VVCplus/Flux clockwise</i> [5] are typically used in hoisting applications. <i>Start speed/current in reference direction</i> [4] is particularly used in applications with counterweight and horizontal movement.
[6]	Hoist Mech. Brake Rel	For utilizing mechanical brake control functions, par. 2-24 to 2-28. This parameter is only active when par. 1-01 is set to [3] <i>Flux w/ motor feedback (FC 302 only)</i> .

**1-73 Flying Start [RPM]**

**Option:**

**Function:**

This function makes it possible to catch a motor which is spinning freely due to a mains drop-out.

[0] *	Off	No function
[1]	On	Enables the frequency converter to "catch" and control a spinning motor. When par. 1-73 is enabled par. 1-71 <i>Start Delay</i> and 1-72 <i>Start Function</i> have no function.

This parameter cannot be adjusted while motor is running.

**NB!**  
This function is not recommended for hoisting applications.

**1-74 Start Speed [RPM]**

**Range:**

0 RPM\* [0 - 600 RPM]

**Function:**

Set the motor start speed. After the start signal the motor output speed leaps to the set value. This parameter can be used for hoist applications (cone rotor motors). Set the start function in par. 1-72 *Start Function* to [3], [4] or [5], and set a start delay time in par. 1-71 *Start Delay*. A reference signal must be present.

**1-75 Start Speed [Hz]**

**Range:**

0 Hz\* [0 - 500 Hz]

**Function:**

Set the motor start speed. After the start signal the motor output speed leaps to the set value. This parameter can be used for hoist applications (cone rotor motors). Set the start function in par. 1-72 *Start Function* to [3], [4] or [5], and set a start delay time in par. 1-71 *Start Delay*. A reference signal must be present.

**1-76 Start Current**

**Range:**

0.00 A\* [0.00 - par. 1-24]

**Function:**

Some motors, such as cone rotor motors, need extra current/starting speed (boost) to disengage the mechanical brake. Adjust par. 1-74 *Start Speed [RPM]* and par. 1-76 to get this boost. Set the required current value to disengage the mechanical brake. Set par. 1-72 *Start Function* to [3] or [4], and set a start delay time in par. 1-71 *Start Delay*. A reference signal must be present.

**2.4.8. 1-8\* Stop Adjustments**

Parameters for setting special stop features for the motor.

### 1-80 Function at Stop

**Option:**
**Function:**

Select the frequency converter function after a stop command or after the speed is ramped down to the settings in par. 1-81 *Min Speed for Function at Stop [RPM]*.

[0] *	Coast	Leaves motor in free mode.
[1]	DC hold	Energizes motor with a DC holding current (see par. 2-00).
[2]	Motor check	Checks if a motor has been connected.
[3]	Pre-magnetizing	Builds up a magnetic field while the motor is stopped. The motor can now produce a quick torque build-up at start.
[4]	DC Voltage U0	

### 1-81 Min Speed for Function at Stop [RPM]

**Range:**
**Function:**

3 RPM\* [0 - 600 RPM]

Set the speed at which to activate par. 1-80 *Function at stop*.

### 1-82 Min Speed for Function at Stop [Hz]

**Range:**
**Function:**

0.0 Hz\* [0.0 - 500 Hz]

Set the output frequency at which to activate par. 1-80 *Function at stop*.

### 1-83 Precise Stop Function

**Option:**
**Function:**

[0] *	Precise ramp stop	Achieves high repetitive precision at the stopping point.
[1]	Counter stop with reset	Runs the frequency converter from receipt of a pulse start signal until the number of pulses programmed by the user in par. 1-84 <i>Precise Stop Counter Value</i> has been received at input terminal 29 or input terminal 33. An internal stop signal will activate the normal ramp down time (par. 3-42, 3-52, 3-62 or 3-72). The counter function is activated (starts timing) at the edge of the start signal (when it changes from stop to start). After each precise stop the number of pulses counted during ramp down 0 rpm is reset.
[2]	Counter stop without reset	Same as [1] but the number of pulses counted during ramp down to 0 rpm is deducted from the counter value in par. 1-84.
[3]	Speed compensated stop	Stops at precisely the same point, regardless of the present speed, the stop signal is delayed internally when the present speed is lower than the maximum speed (set in par. 4-19).
[4]	Speed compensated counter stop with reset	Same as [3] but after each precise stop the number of pulses counted during ramp down 0 rpm is reset.
[5]	Speed compensated counter stop without reset	Same as [3] but the number of pulses counted during ramp down to 0 rpm is deducted from the counter value in par. 1-84.

This parameter cannot be adjusted while the motor is running.

### 1-84 Precise Stop

**Range:**
**Function:**

100000\* [0 - 99999999]

Enter the counter value to be used in the integrated precise stop function, par. 1-83. The maximum permissible frequency at terminal 29 or 33 is 110 kHz.

### 1-85 Precise Stop Speed Compensation Delay

**Range:**
**Function:**

10 ms\* [1-100 ms]


Enter the delay time for sensors, PLCs, etc. for use in par. 1-83 *Precise Stop Function*. In speed compensated stop mode, the delay time at different frequencies has a major influence on the stop function.

### 2.4.9. 1-9\* Motor Temperature

Parameters for setting the temperature protection features for the motor.

#### 1-90 Motor Thermal Protection

Option:	Function:
	The frequency converter determines the motor temperature for motor protection in two different ways: <ul style="list-style-type: none"> <li>Via a thermistor sensor connected to one of the analog or digital inputs (par. 1-93 <i>Thermistor Source</i>).</li> <li>Via calculation (ETR = Electronic Terminal Relay) of the thermal load, based on the actual load and time. The calculated thermal load is compared with the rated motor current <math>I_{M,N}</math> and the rated motor frequency <math>f_{M,N}</math>. The calculations estimate the need for a lower load at lower speed due to less cooling from the fan incorporated in the motor.</li> </ul>
[0] *	No protection Continuously overloaded motor, when no warning or trip of the frequency converter is required.
[1]	Thermistor warning Activates a warning when the connected thermistor or KTY-sensor in the motor reacts in the event of motor over-temperature.
[2]	Thermistor trip Stops (trips) frequency converter when connected thermistor in motor reacts in the event of motor over-temperature. The thermistor cut-out value must be > 3 kΩ. Integrate a thermistor (PTC sensor) in the motor for winding protection.
[3]	ETR warning 1
[4]	ETR trip 1
[5]	ETR warning 2
[6]	ETR trip 2
[7]	ETR warning 3
[8]	ETR trip 3
[9]	ETR warning 4
[10]	ETR trip 4



Motor protection can be implemented using a range of techniques: PTC or KTY sensor (see also section *KTY Sensor Connection*) in motor windings; mechanical thermal switch (Klixon type); or Electronic Thermal Relay (ETR).

Using a digital input and 24 V as power supply:


Example: The frequency converter trips when the motor temperature is too high

Parameter set-up:

Set Par. 1-90 *Motor Thermal Protection* to *Thermistor Trip* [2]

Set Par. 1-93 *Thermistor Source* to *Digital Input* [6]

2




Using a digital input and 10 V as power supply:

Example: The frequency converter trips when the motor temperature is too high.

Parameter set-up:

Set Par. 1-90 *Motor Thermal Protection* to *Thermistor Trip* [2]

Set Par. 1-93 *Thermistor Source* to *Digital Input* [6]




Using an analog input and 10 V as power supply:

Example: The frequency converter trips when the motor temperature is too high.

Parameter set-up:

Set Par. 1-90 *Motor Thermal Protection* to *Thermistor Trip* [2]


Set Par. 1-93 *Thermistor Source* to *Analog Input 54* [2]



Input	Supply Voltage	Threshold
Digital/analog	Volt	Cut-out Values
Digital	24 V	<math>6.6\text{ k}\Omega</math> - <math>10.8\text{ k}\Omega</math>
Digital	10 V	<math>800\ \Omega</math> - <math>2.7\text{ k}\Omega</math>
Analog	10 V	<math>3.0\text{ k}\Omega</math> - <math>3.0\text{ k}\Omega</math>


**NB!**  
Check that the chosen supply voltage follows the specification of the used thermistor element.

Select *ETR Warning 1-4*, to activate a warning on the display when the motor is overloaded.  
 Select *ETR Trip 1-4* to trip the frequency converter when the motor is overloaded.  
 Programme a warning signal via one of the digital outputs. The signal appears in the event of a warning and if the frequency converter trips (thermal warning).  
 ETR (Electronic Terminal Relay) functions 1-4 will calculate the load when the set-up where they were selected is active. For example ETR starts calculating when setup 3 is selected. For the North American market: The ETR functions provide class 20 motor overload protection in accordance with NEC.



**1-91 Motor External Fan**

Option:	Function:
[0] * No	No external fan is required, i.e. the motor is derated at low speed.
[1] Yes	Applies an external motor fan (external ventilation), so no derating of the motor is required at low speed. The graph below is followed if the motor current is lower than nominal motor current (see par. 1-24). If the motor current exceeds nominal current, the operation time still decreases as if no fan were installed.



**1-93 Thermistor Source**

Select the input to which the thermistor (PTC sensor) should be connected. An analog input option [1] or [2] cannot be selected if the analog input is already in use as a reference source (selected in *par. 3-15 Reference 1 Source*, *par. 3-16 Reference 2 Source* or *par. 3-17 Reference 3 Source*).

[0] *	None
[1]	Analog input 53
[2]	Analog input 54
[3]	Digital input 18
[4]	Digital input 19
[5]	Digital input 32
[6]	Digital input 33

This parameter cannot be adjusted while the motor is running.



**NB!**

Digital inputs should be set to "No operation" - see *par. 5-1\* Digital Inputs*.

**2.4.10. KTY Sensor Connection**


(FC 302 only)

KTY sensors are used especially in Permanent Magnet Servo Motors (PM motors) for dynamic adjusting of motor parameters as stator resistance (*par. 1-30*) for PM motors and also rotor resistance (*par. 1-31*) for asynchronous motors, depending on winding temperature. The calculation is:

$$R_s = R_{s_{20^\circ C}} \times (1 + \alpha_{cu} \times \Delta T) [\Omega] \text{ where } \alpha_{cu} = 0.00393$$

KTY sensors can be used for motor protecting (*par 1-97*).

FC 302 can handle three types of KTY sensors, defined in *par 1-95*. The actual sensor temperature can be read out from *par 16-19*.



**NB!**

If the temperature of the motor is utilized through a thermistor or KTY sensor the PELV is not complied with in case of short circuits between motor windings and sensor. In order to comply with PELV the sensor must be extra isolated.

**1-95 KTY Sensor Type**

**Option:**

**Function:**

Select the used type of KTY sensor:

- KTY Sensor type 1: 1Kohm at 100 degrees C
- KTY Sensor type 2: 1Kohm at 25 degrees C
- KTY Sensor type 3: 2Kohm at 25 degrees C

*This parameter only applies for FC 302.*

- [0] \* KTY Sensor 1
- [1] KTY Sensor 2
- [2] KTY Sensor 3

**1-96 KTY Thermistor Source**

**Option:**

**Function:**

Selecting analog input terminal 54 to be used as KTY sensor input. Terminal 54 cannot be selected as KTY source if otherwise used as reference (see par. 3-15 to 3-17).

*This parameter only applies for FC 302.*

**NB!**  
Connection of KTY-sensor between term. 54 and 55 (GND). See picture in section *KTY Sensor Connection*.

- [0] \* None
- [2] Analog input 54

**1-97 KTY Threshold level**

**Range:**

80° C [-40 - 140° C]

**Function:**

Select the KTY sensor threshold level for motor thermal protection. *This parameter only applies for FC 302.*

## 2.5. Parameters: Brakes

### 2.5.1. 2-\*\* Brakes

Parameter group for setting brake features in the frequency converter.

### 2.5.2. 2-0\* DC-Brakes

Parameter group for configuring the DC brake and DC hold functions.

**2-00 DC Hold Current**

**Range:**

50 %\* [0 - 160%]

**Function:**

Enter a value for holding current as a percentage of the rated motor current  $I_{M,N}$  set in par. 1-24 Motor Current. 100% DC holding current corresponds to  $I_{M,N}$ .

This parameter holds the motor function (holding torque) or pre-heats the motor.

This parameter is active if *DC hold* is selected in par. 1-72 *Start Function* [0] or par. 1-80 *Function at Stop* [1].

**NB!**  
The maximum value depends on the rated motor current.

**NB!**  
Avoid 100 % current for too long. It may damage the motor.

**2-01 DC Brake Current****Range:**

50%\* [0 - 1000 %]

**Function:**

Enter a value for current as a percentage of the rated motor current  $I_{M,N}$ , see par. 1-24 *Motor Current*. 100% DC braking current corresponds to  $I_{M,N}$ .

DC brake current is applied on a stop command, when the speed is lower than the limit set in par. 2-03 *DC Brake Cut In Speed*, when the DC Brake Inverse function is active; or via the serial communication port. The braking current is active during the time period set in par. 2-02 *DC Braking Time*.

**NB!**

The maximum value depends on the rated motor current.

**NB!**

Avoid 100 % current for too long. It may damage the motor.

**2-02 DC Braking Time****Range:**

10.0s.\* [0.0 - 60.0 s.]

**Function:**

Set the duration of the DC braking current set in par. 2-01, once activated.

**2-03 DC Brake Cut In Speed [RPM]****Range:**

0 RPM\* [0 - par. 4 -13]

**Function:**

Set the DC brake cut-in speed for activation of the DC braking current set in par. 2-01, upon a stop command.

**2-04 DC Brake Cut In Speed [Hz]****Option:**

[0 RPM]\* 0 - par. 4 -14

**Function:**

Set the DC brake cut-in speed for activation of the DC braking current set in par. 2-01, upon a stop command.

**2.5.3. 2-1\* Brake Energy Funct.**

Parameter group for selecting dynamic braking parameters.

**2-10 Brake Function****Option:**

[0] Off

**Function:**

No brake resistor is installed.

[1] Resistor brake

A brake resistor is incorporated in the system, for dissipation of surplus brake energy as heat. Connecting a brake resistor allows a higher DC link voltage during braking (generating operation). The Resistor brake function is only active in frequency converters with an integral dynamic brake.

[2] AC brake

**2-11 Brake Resistor (ohm)****Range:**

Size related [Ohm]

**Function:**

Set the brake resistor value in Ohms. This value is used for monitoring the power to the brake resistor in par. 2-13 *Brake Power Monitoring*. This parameter is only active in frequency converters with an integral dynamic brake.

**2-12 Brake Power****Range:**

kW\* [0.001 - Size related]

**Function:**

Set the monitoring limit of the brake power transmitted to the resistor.

The monitoring limit is a product of the maximum duty cycle (120 sec.) and the maximum power of the brake resistor at that duty cycle. See the formula below.



For 200 - 240 V units:	$P_{resistor} = \frac{390^2 \times dutytime}{R \times 120}$
For 380 - 480 V units	$P_{resistor} = \frac{778^2 \times dutytime}{R \times 120}$
For 380 - 500 V units	$P_{resistor} = \frac{810^2 \times dutytime}{R \times 120}$
For 575 - 600 V units	$P_{resistor} = \frac{943^2 \times dutytime}{R \times 120}$

This parameter is only active in frequency converters with an integral dynamic brake.

### 2-13 Brake Power Monitoring

**Option:**

**Function:**

This parameter is only active in frequency converters with an integral dynamic brake.

This parameter enables monitoring of the power to the brake resistor. The power is calculated on the basis of the resistance (par. 2-11 *Brake Resistor (Ohm)*), the DC link voltage, and the resistor duty time.

[0] *	Off	No brake power monitoring required.
[1]	Warning	Activates a warning on the display when the power transmitted over 120 s exceeds 100% of the monitoring limit (par. 2-12 <i>Brake Power Limit (kW)</i> ). The warning disappears when the transmitted power falls below 80% of the monitoring limit.
[2]	Trip	Trips frequency converter and displays an alarm when the calculated power exceeds 100% of the monitoring limit.
[3]	Warning and Trip	Activates both of the above, including warning, trip and alarm.

If power monitoring is set to *Off*[0] or *Warning*[1], the brake function remains active, even if the monitoring limit is exceeded. This may lead to thermal overload of the resistor. It is also possible to generate a warning via a relay/digital outputs. The measuring accuracy of the power monitoring depends on the accuracy of the resistance of the resistor (better than ± 20%).

### 2-15 Brake Check

**Option:**

**Function:**

Select type of test and monitoring function to check the connection to the brake resistor, or whether a brake resistor is present, and then display a warning or an alarm in the event of a fault.

**NB!**  
The brake resistor disconnection function is tested during power-up. However the brake IGBT test is performed when there is no braking. A warning or trip disconnects the brake function.

The testing sequence is as follows:

1. The DC link ripple amplitude is measured for 300 ms without braking.
2. The DC link ripple amplitude is measured for 300 ms with the brake turned on.
3. If the DC link ripple amplitude while braking is lower than the DC link ripple amplitude before braking + 1 %: *Brake check failed, return a warning or alarm.*
4. If the DC link ripple amplitude while braking is higher than the DC link ripple amplitude before braking + 1 %: *Brake check OK.*

[0] *	Off	Monitors brake resistor and brake IGBT for a short-circuit during operation. If a short-circuit occurs, a warning appears.
[1]	Warning	Monitors brake resistor and brake IGBT for a short-circuit, and runs a test for brake resistor disconnection during power-up.
[2]	Trip	Monitors for a short-circuit or disconnection of the brake resistor, or a short-circuit of the brake IGBT. If a fault occurs, the frequency converter cuts out while displaying an alarm (trip locked).
[3]	Stop and Trip	Monitors for a short-circuit or disconnection of the brake resistor, or a short-circuit of the brake IGBT. If a fault occurs, the frequency converter ramps down to coast and then trips. A trip lock alarm is displayed.

[4]	AC brake	Monitors for a short-circuit or disconnection of the brake resistor, or a short-circuit of the brake IGBT. If a fault occurs, the frequency converter performs a controlled ramp down. This option is available for FC 302 only.
-----	----------	--

**NB!**

NB!: Remove a warning arising in connection with *Off*[0] or *Warning* [1] by cycling the mains supply. The fault must be corrected first. For *Off*[0] or *Warning* [1], the frequency converter keeps running even if a fault is located.

This parameter is only active in frequency converters with an integral dynamic brake.

### 2-16 AC Brake Max. Current

**Range:**

100%\* [0 - 1000%]

**Function:**

Enter the maximum permissible current when using AC brake to avoid overheating of motor windings. The AC brake function is available in Flux mode only (FC 302 only).

### 2-17 Over-voltage Control

**Option:****Function:**

Over-voltage control (OVC) reduces the risk of the frequency converter tripping due to an over voltage on the DC link caused by generative power from the load.

[0] *	Disabled	No OVC required.
[1]	Enabled (not at stop)	Activates OVC except when using a stop signal to stop the frequency converter.
[2]	Enabled	Activates OVC.

**NB!**

OVC must not be enabled in hoisting applications.


#### 2.5.4. 2-2\* Mechanical Brake

Parameters for controlling operation of an electro-magnetic (mechanical) brake, typically required in hoisting applications.

To control a mechanical brake, a relay output (relay 01 or relay 02) or a programmed digital output (terminal 27 or 29) is required. Normally this output must be closed during periods when the frequency converter is unable to 'hold' the motor, e.g. due to an excessive load. Select *Mechanical Brake Control* [32] for applications with an electro-magnetic brake in par. 5-40 *Function Relay*, par. 5-30 *Terminal 27 Digital Output*, or par. 5-31 *Terminal 29 Digital Output*. When selecting *Mechanical brake control* [32], the mechanical brake is closed from start up until the output current is above the level selected in par. 2-20 *Release Brake Current*. During stop, the mechanical brake activates when the speed falls below the level specified in par. 2-21 *Activate Brake Speed [RPM]*. If the frequency converter enters an alarm condition or an over-current or over-voltage situation, the mechanical brake immediately cuts in. This is also the case during safe stop.

**NB!**

Protection mode and trip delay features (par. 14-25 and 14-26) may delay the activation of the mechanical brake in an alarm condition. These features must be disabled in hoisting applications.



**2-20 Release Brake Current**

**Range:**

0.00 A\* [0.00 - par. 16-37]

**Function:**

Set the motor current for release of the mechanical brake, when a start condition is present. The upper limit is specified in par. 16-37 *Inv. Max. Current*.

**2-21 Activate Brake Speed [RPM]**

**Range:**

0 RPM\* [0 - 60.000]

**Function:**

Set the motor speed for activation of the mechanical brake, when a stop condition is present. The upper speed limit is specified in par. 4-53 *Warning Speed High*.

**2-22 Activate Brake Speed [Hz]**

**Range:**

0 Hz\* [0 - 5000]

**Function:**

Set the motor frequency for activation of the mechanical brake, when a stop condition is present.

**2-23 Activate Brake Delay**

**Range:**

0.0 s\* [0.0 - 5.0 s]

**Function:**

Enter the brake delay time of the coast after ramp-down time. The shaft is held at zero speed with full holding torque. Ensure that the mechanical brake has locked the load before the motor enters coast mode. See *Mechanical Brake Control* section in the Design Guide.

**2-24 Stop delay**

**Range:**

0.0 s\* [0.0 - 5.0 s]

**Function:**

Set the time interval from the moment when the motor is stopped until the brake closes. This parameter is a part of the stopping function.

**2-25 Brake Release Time**

**Range:**

0.20 s\* [0.00 - 5.00 s]

**Function:**

This value defines the time it takes for the mechanical brake to open/ close. This parameter must act as a time-out when brake feedback is activated.

**2-26 Torque Ref**

**Range:** 0.00%\* [-100.00 - 100.00 %]  
**Function:** The value defines the torque applied against the closed mechanical brake, before release

**2-27 Torque Ramp Time**

**Range:** 0.2 s\* [0.0 - 5.0 s]  
**Function:** The value defines the duration of the torque ramp in clockwise direction.

**2-28 Gain Boost Factor**

**Range:** 1.00\* [0.00 - 4.00]  
**Function:** When a speed PID-control is connected to the output (flux closed loop) it must be possible to boost the proportional gain of the control during the *Activate Brake Delay* (par. 2-23). By increasing the gain, the bump when the motor takes over the load from the brake can be reduced. The risk of oscillation is very small due to the relatively short duration and the low (zero) speed.




Illustration 2.4: Brake release sequence for hoist mechanical brake control

## 2.6. Parameters: Reference/Ramps

### 2.6.1. 3-\*\* Reference/Reference Limits/Ramps

Parameters for reference handling, definition of limitations, and configuration of the reaction of the frequency converter to changes.

### 2.6.2. 3-0\* Reference Limits

Parameters for setting the reference unit, limits and ranges.

#### 3-00 Reference Range

**Option:**
**Function:**

Select the range of the reference signal and the feedback signal. Signal values can be positive only, or positive and negative. The minimum limit may have a negative value, unless *Speed closed loop* [1] control or *Process* [3] is selected in par. 1-00 *Configuration Mode*.

[0]	Min. - Max	For positive values only.
[1]	-Max - +Max	For both positive and negative values.

#### 3-01 Reference/Feedback Unit

**Option:**
**Function:**

Select the unit to be used in Process PID Control references and feedbacks.

[0]	None
[1]	%
[2] *	RPM
[3]	Hz
[4]	Nm
[5]	PPM
[10]	1/min
[12]	Pulse/s
[20]	I/s
[21]	I/min
[22]	I/h
[23]	m <sup>3</sup> /s
[24]	m <sup>3</sup> /min
[25]	m <sup>3</sup> /h
[30]	kg/s
[31]	kg/min
[32]	kg/h
[33]	t/min
[34]	t/h
[40]	m/s
[41]	m/min
[45]	m
[60]	° C
[70]	Mbar
[71]	Bar
[72]	Pa
[73]	kPa

[74] m WG

[80] kW

[120] GPM

[121] gal/s

[122] gal/min

[123] gal/h

[124] CFM

[125] ft<sup>3</sup>/s[126] ft<sup>3</sup>/min[127] ft<sup>3</sup>/h

[130] lb/s

[131] lb/min

[132] lb/h

[140] ft/s

[141] ft/min

[145] ft

[150] lb ft

[160] ° F

[170] psi

[171] lb/in<sup>2</sup>

[172] in WG

[173] ft WG

[180] HP

### 3-02 Minimum Reference

**Range:**

0.000 \* [-100000.000 – par. 3-03]

**Function:**

Enter the Minimum Reference. The Minimum Reference is the lowest value obtainable by summing all references. Minimum Reference is active only when par. 3-00 *Reference Range* is set to *Min. - Max.* [0].

The Minimum Reference unit matches:

- The choice of configuration in par 1-00 *Configuration Mode: for Speed closed loop* [1], RPM; for *Torque* [2], Nm.
- The unit selected in par. 3-01 *Reference/Feedback Unit*.

### 3-03 Maximum Reference

**Range:**

1500.000\* [Par. 3-02 - 100000.000]

**Function:**

Enter the Maximum Reference. The Maximum Reference is the highest value obtainable by summing all references.

**The Maximum Reference unit matches:**

- The choice of configuration in par. 1-00 *Configuration Mode: for Speed closed loop* [1], RPM; for *Torque* [2], Nm.
- The unit selected in par. 3-01 *Reference/Feedback Unit*.

### 3-04 Reference Function

**Option:**

[0] \* Sum

**Function:**

Sums both external and preset reference sources.

[1] External/Preset

Use either the preset or the external reference source.

Shift between external and preset via a command on a digital input.

### 2.6.3. 3-1\* References


Parameters for setting up the reference sources.

Select the preset reference(s). *Select Preset ref. bit 0 / 1 / 2 [16], [17] or [18] for the corresponding digital inputs in parameter group 5.1\* Digital Inputs.*

#### 3-10 Preset Reference

Array [8]  
Range: 0-7

0.00%\* [-100.00 - 100.00 %] Enter up to eight different preset references (0-7) in this parameter, using array programming. The preset reference is stated as a percentage of the value Ref<sub>MAX</sub> (par. 3-03 *Maximum Reference*) If a Ref<sub>MIN</sub> different from 0 (Par. 3-02 *Minimum Reference*) is programmed, the preset reference is calculated as a percentage of the full reference range, i.e. on the basis of the difference between Ref<sub>MAX</sub> and Ref<sub>MIN</sub>. Afterwards, the value is added to Ref<sub>MIN</sub>. When using preset references, select Preset ref. bit 0 / 1 / 2 [16], [17] or [18] for the corresponding digital inputs in parameter group 5.1\* Digital Inputs.



Preset ref. bit	2	1	0
Preset ref. 0	0	0	0
Preset ref. 1	0	0	1
Preset ref. 2	0	1	0
Preset ref. 3	0	1	1
Preset ref. 4	1	0	0
Preset ref. 5	1	0	1
Preset ref. 6	1	1	0
Preset ref. 7	1	1	1

#### 3-11 Jog Speed

**Range:** Size related [0.0 - par. 4-14]  
**Function:** The jog speed is a fixed output speed at which the frequency converter is running when the jog function is activated. See also par. 3-80.

#### 3-12 Catch up/slow Down Value

**Range:** 0.00% [0.00 - 100.00%]  
**Function:** Enter a percentage (relative) value to be either added to or deducted from the actual reference for Catch up or Slow down respectively. If *Catch up* is selected via one of the digital inputs (par. 5-10 to par. 5-15), the percentage (relative) value is added to the total reference. If *Slow down* is selected via one of the digital inputs (par. 5-10 to par. 5-15), the percentage (relative) value is deducted from the total reference. Obtain extended functionality with the DigiPot function. See parameter group 3-9\* *Digital Potentiometer*.



3-13 Reference Site

**Option:** **Function:**  
Select which reference site to activate.

[0] *	Linked to Hand / Auto	Use local reference when in Hand mode; or remote reference when in Auto mode.
[1]	Remote	Use remote reference in both Hand mode and Auto mode.
[2]	Local	Use local reference in both Hand mode and Auto mode.

3-14 Preset Relative Reference

**Range:** **Function:**  
0.00%\* [-200.00 - 200.00 %]  
The actual reference, X, is increased or decreased with the percentage Y, set in par.3-14. This results in the actual reference Z. Actual reference (X) is the sum of the inputs selected in par.3-15, Reference Source 1, par. 3-16, Reference Source 2, par.3-17, Reference Source 3, and par.8-02, Control Word Source.



3-15 Reference Source 1

**Option:** **Function:**  
Select the reference input to be used for the first reference signal. Par. 3-15, 3-16 and 3-17 define up to three different reference signals. The sum of these reference signals defines the actual reference.

[0]	No function
[1] *	Analog input 53
[2]	Analog input 54
[7]	Frequency input 29 (FC 302 only)
[8]	Frequency input 33
[11]	Local bus reference
[20]	Digital pot.meter
[21]	Analog input X30-11
[22]	Analog input X30-12

3-16 Reference Source 2

**Option:** **Function:**  
Select the reference input to be used for the second reference signal. Par. 3-15, 3-16 and 3-17 define up to three different reference signals. The sum of these reference signals defines the actual reference.

[0]	No function
[1]	Analog input 53
[2]	Analog input 54



- [7] Frequency input 29 (FC 302 only)
- [8] Frequency input 33
- [11] Local bus reference
- [20] \* Digital pot.meter
- [21] Analog input X30-11
- [22] Analog input X30-12

**3-17 Reference Source 3**

**Option:**

**Function:**

Select the reference input to be used for the third reference signal. Par. 3-15, 3-16 and 3-17 define up to three different reference signals. The sum of these reference signals defines the actual reference.


- [0] No function
- [1] Analog input 53
- [2] Analog input 54
- [7] Frequency input 29 (FC 302 only)
- [8] Frequency input 33
- [11] \* Local bus reference
- [20] Digital pot.meter
- [21] Analog input X30-11
- [22] Analog input X30-12

**3-18 Relative Scaling Reference Source**

**Option:**

**Function:**

Select a variable value to be added to the fixed value (defined in par. 3-14 *Preset Relative Reference*). The sum of the fixed and variable values (labelled Y in the illustration below) is multiplied with the actual reference (labelled X in the illustration below). This product is then added to the actual reference ( $X+X*Y/100$ ) to give the resultant actual reference.



This parameter cannot be adjusted while the motor is running.

- [0] \* No function
- [1] Analog input 53
- [2] Analog input 54
- [7] Frequency input 29 (FC 302 only)
- [8] Frequency input 33
- [11] Local bus reference
- [20] Digital pot.meter
- [21] Analog input X30-11
- [22] Analog input X30-12

**3-19 Jog Speed**

**Range:**

150 RPM\* [0 - par. 4-13 RPM]

**Function:**

Enter a value for the jog speed  $n_{JOG}$ , which is a fixed output speed. The frequency converter runs at this speed when the jog function is activated. The maximum limit is defined in par. 4-13 *Motor Speed High Limit (RPM)*. See also par. 3-80.


2

**2.6.4. Ramps**


**3-4\* Ramp 1**

For each of four ramps (par. 3-4\*, 3-5\*, 3-6\* and 3-7\*) configure the ramp parameters: ramp type, ramping times (duration of acceleration and deceleration) and level of jerk compensation for S ramps.

Start by setting the linear ramping times corresponding to the figures.



If S-ramps are selected then set the level of non-linear jerk compensation required. Set jerk compensation by defining the proportion of ramp-up and ramp-down times where acceleration and deceleration are variable (i.e. increasing or decreasing). The S-ramp acceleration and deceleration settings are defined as a percentage of the actual ramp time.



**3-40 Ramp 1 Type**

**Option:**

**Function:**

Select the ramp type, depending on requirements for acceleration/deceleration.

A linear ramp will give constant acceleration during ramping. An S-ramp will give non-linear acceleration, compensating for jerk in the application.

[0] *	Linear	
[1]	S-ramp Const Jerk	Acceleration with lowest possible jerk.
[2]	S-ramp Const Time	S-ramp based on the values set in par. 3-41 and 3-42.


**NB!**  
 If S-ramp [1] is selected and the reference during ramping is changed the ramp time may be prolonged in order to realize a jerk free movement which may result in a longer start or stop time.  
 Additional adjustment of the S-ramp ratios or switching initiators may be necessary.

**3-41 Ramp 1 Ramp up Time**

**Range:**  
 Size related [0.01 - 3600.00 s]

**Function:**  
 Enter the ramp-up time, i.e. the acceleration time from 0 RPM to the rated motor speed  $n_{M,N}$  (par. 1-25). Choose a ramp-up time such that the output current does not exceed the current limit in par. 4-18 during ramping. The value 0.00 corresponds to 0.01 sec. in speed mode. See ramp-down time in par. 3-42.

$$Par. 3 - 41 = \frac{t_{acc} [s] \times n_{M, N} (par. 1 - 25) [RPM]}{\Delta ref [RPM]}$$



**3-42 Ramp 1 Ramp Down Time**

**Range:**  
 Size related [0.01 - 3600.00 s]

**Function:**  
 Enter the ramp-down time, i.e. the deceleration time from the rated motor speed  $n_{M,N}$  (par. 1-25) to 0 RPM. Choose a ramp-down time such that no over-voltage arises in the inverter due to regenerative operation of the motor, and such that the generated current does not exceed the current limit set in par. 4-18. The value 0.00 corresponds to 0.01 s in speed mode. See ramp-up time in par. 3-41.

$$Par. 3 - 42 = \frac{t_{acc} [s] \times n_{M, N} (par. 1 - 25) [RPM]}{\Delta ref [RPM]}$$

**3-45 Ramp 1 S-ramp Ratio at Accel. Start**

**Range:**  
 50%\* [1 - 99%]

**Function:**  
 Enter the proportion of the total ramp-up time (par. 3-41) in which the acceleration torque increases. The larger the percentage value, the greater the jerk compensation achieved, and thus the lower the torque jerks occurring in the application.

**3-46 Ramp 1 S-ramp Ratio at Accel. End**

**Range:**  
 50%\* [1 - 99%]

**Function:**  
 Enter the proportion of the total ramp-up time (par. 3-41) in which the acceleration torque decreases. The larger the percentage value, the greater the jerk compensation achieved, and thus the lower the torque jerks in the application.

**3-47 Ramp 1 S-ramp Ratio at Decel. Start**

**Range:**  
 50%\* [1 - 99%]

**Function:**  
 Enter the proportion of the total ramp-down time (par. 3-42) where the deceleration torque increases. The larger the percentage value, the greater the jerk compensation achieved, and thus the lower the torque jerks in the application.

### 3-48 Ramp 1 S-ramp Ratio at Decel. End

**Range:**

50%\* [1 - 99%]

**Function:**

Enter the proportion of the total ramp-down time (par. 3-42) where the deceleration torque decreases. The larger the percentage value, the greater the jerk compensation achieved, and thus the lower the torque jerks in the application.

### 2.6.5. 3-5\* Ramp 2

Choosing ramp parameters, see 3-4\*.

### 3-50 Ramp 2 Type

**Option:**
**Function:**

Select the ramp type, depending on requirements for acceleration/deceleration. A linear ramp will give constant acceleration during ramping. An S-ramp will give non-linear acceleration, compensating for jerk in the application.

[0] \* Linear

[1] S-ramp Const Jerk Acceleration with lowest possible jerk

[2] S-ramp Const Time S-ramp based on the values set in par. 3-51 and 3-52


**NB!**

If S-ramp [1] is selected and the reference during ramping is changed the ramp time may be prolonged in order to realize a jerk free movement which may result in a longer start or stop time.

Additional adjustment of the S-ramp ratios or switching initiators may be necessary.

### 3-51 Ramp 2 Ramp up Time

**Range:**

Size related [0.01 - 3600.00 s]

**Function:**

Enter the ramp-up time, i.e. the acceleration time from 0 RPM to the rated motor speed  $n_{M,N}$  (par. 1-25). Choose a ramp-up time such that the output current does not exceed the current limit in par. 4-18 during ramping. The value 0.00 corresponds to 0.01 sec. in speed mode. See ramp-down time in par. 3-52.

$$Par. 3 - 51 = \frac{t_{acc} [s] \times n_{M, N} (par. 1 - 25) [RPM]}{\Delta ref [RPM]}$$

### 3-52 Ramp 2 Ramp down Time

**Range:**

Size related [0.01 - 3600.00 s.]

**Function:**

Enter the ramp-down time, i.e. the deceleration time from the rated motor speed  $n_{M,N}$  (par. 1-25) to 0 RPM. Choose a ramp-down time such that no over-voltage arises in the inverter due to regenerative operation of the motor, and such that the generated current does not exceed the current limit set in par. 4-18. The value 0.00 corresponds to 0.01 s in speed mode. See ramp-up time in par. 3-51.

$$Par. 3 - 52 = \frac{t_{dec} [s] \times n_{M, N} (par. 1 - 25) [RPM]}{\Delta ref [RPM]}$$

### 3-55 Ramp 2 S-ramp Ratio at Accel. Start

**Range:**

50%\* [1 - 99%]

**Function:**

Enter the proportion of the total ramp-up time (par. 3-51) in which the acceleration torque increases. The larger the percentage value, the greater the jerk compensation achieved, and thus the lower the torque jerks in the application.

### 3-56 Ramp 2 S-ramp Ratio at Accel. End

**Range:**

50%\* [1 - 99%]

**Function:**

Enter the proportion of the total ramp-up time (par. 3-51) in which the acceleration torque decreases. The larger the percentage value, the greater the jerk compensation achieved, and thus the lower the torque jerks in the application.

**3-57 Ramp 2 S-ramp Ratio at Decel. Start**

**Range:**

50%\* [1 - 99%]

**Function:**

Enter the proportion of the total ramp-down time (par. 3-52) where the deceleration torque increases. The larger the percentage value, the greater the jerk compensation achieved, and thus the lower the torque jerks in the application.

**3-58 Ramp 2 S-ramp Ratio at Decel. End**

**Range:**

50%\* [1 - 99%]

**Function:**

Enter the proportion of the total ramp-down time (par. 3-52) where the deceleration torque decreases. The larger the percentage value, the greater the jerk compensation achieved, and thus the lower the torque jerks in the application.

**2.6.6. 3-6\* Ramp 3**

Configure ramp parameters, see 3-4\*.

**3-60 Ramp 3 Type**

**Option:**

**Function:**

Select the ramp type, depending on requirements for acceleration and deceleration. A linear ramp will give constant acceleration during ramping. An S-ramp will give non-linear acceleration, compensating for jerk in the application.

[0] *	Linear	
[1]	S-ramp Const Jerk	Accelerates with lowest possible jerk.
[2]	S-ramp Const Time	S-ramp based on the values set in par. 3-61 and 3-62



**NB!**

If S-ramp [1] is selected and the reference during ramping is changed the ramp time may be prolonged in order to realize a jerk free movement which may result in a longer start or stop time.

Additional adjustment of the S-ramp ratios or switching initiators may be necessary.

**3-61 Ramp 3 Ramp up Time**

**Range:**

Size related [0.01 - 3600.00 s]

**Function:**

Enter the ramp-up time, i.e. the acceleration time from 0 RPM to the rated motor speed  $n_{M,N}$  (par. 1-25). Choose a ramp-up time such that the output current does not exceed the current limit in par. 4-18 during ramping. The value 0.00 corresponds to 0.01 sec. in speed mode. See ramp-down time in par. 3-62.

**3-62 Ramp 3 Ramp down Time**

**Range:**

Size related [0.01 - 3600.00 s]

**Function:**

Enter the ramp-down time, i.e. the deceleration time from the rated motor speed  $n_{M,N}$  (par. 1-25) to 0 RPM. Choose a ramp-down time such that no over-voltage arises in the inverter due to regenerative operation of the motor, and such that the generated current does not exceed the current limit set in par. 4-18. The value 0.00 corresponds to 0.01 s in speed mode. See ramp-up time in par. 3-61.

$$Par. 3 - 62 = \frac{t_{dec} [s] \times n_{M, N} (par. 1 - 25) [RPM]}{\Delta ref [RPM]}$$

**3-65 Ramp 3 S-ramp Ratio at Accel. Start**

**Range:**

50%\* [1 - 99%]

**Function:**

Enter the proportion of the total ramp-up time (par. 3-61) in which the acceleration torque increases. The larger the percentage value, the greater the jerk compensation achieved, and thus the lower the torque jerks in the application.

**3-66 Ramp 3 S-ramp Ratio at Accel. End****Range:**

50%\* [1 - 99%]

**Function:**

Enter the proportion of the total ramp-up time (par. 3-61) in which the acceleration torque decreases. The larger the percentage value, the greater the jerk compensation achieved, and thus the lower the torque jerks in the application.

**3-67 Ramp 3 S-ramp Ratio at Decel. Start****Range:**

50%\* [1 - 99%]

**Function:**

Enter the proportion of the total ramp-down time (par. 3-62) where the deceleration torque increases. The larger the percentage value, the greater the jerk compensation achieved, and thus the lower the torque jerks in the application.

**3-68 Ramp 3 S-ramp Ratio at Decel. End****Range:**

50%\* [1 - 99%]

**Function:**

Enter the proportion of the total ramp-down time (par. 3-62) where the deceleration torque decreases. The larger the percentage value, the greater the jerk compensation achieved, and thus the lower the torque jerks in the application.

**2.6.7. 3-7\* Ramp 4**

Configure ramp parameters, see 3-4\*.

**3-70 Ramp 4 Type****Option:****Function:**

Select the ramp type, depending on requirements for acceleration and deceleration. A linear ramp will give constant acceleration during ramping. An S-ramp will give non-linear acceleration, compensating for jerk in the application

[0] \* Linear

[1] S-ramp Const Jerk Accelerates with lowest possible jerk.

[2] S-ramp Const Time S-ramp based on the values set in par. 3-71 and 3-72.

**NB!**

If S-ramp [1] is selected and the reference during ramping is changed the ramp time may be prolonged in order to realize a jerk free movement which may result in a longer start or stop time.

Additional adjustment of the S-ramp ratios or switching initiators may be necessary.

**3-71 Ramp 4 Ramp up Time****Range:**

Size related [0.01 - 3600.00 s]

**Function:**

Enter the ramp-up time, i.e. the acceleration time from 0 RPM to the rated motor speed  $n_{M,N}$  (par. 1-25). Choose a ramp-up time such that the output current does not exceed the current limit in par. 4-18 during ramping. The value 0.00 corresponds to 0.01 sec. in speed mode. See ramp-down time in par. 3-72.

$$Par. 3 - 71 = \frac{t_{acc} [s] \times n_{M, N} (par. 1 - 25) [RPM]}{\Delta ref [RPM]}$$

**3-72 Ramp 4 Ramp Down Time****Range:**

Size related [0.01 - 3600.00 s]

**Function:**

Enter the ramp-down time, i.e. the deceleration time from the rated motor speed  $n_{M,N}$  (par. 1-25) to 0 RPM. Choose a ramp-down time such that no over-voltage arises in the inverter due to regenerative operation of the motor, and such that the generated current does not exceed the current limit set in par. 4-18. The value 0.00 corresponds to 0.01 s in speed mode. See ramp-up time in par. 3-71.

$$Par. 3 - 72 = \frac{t_{dec} [s] \times n_{M, N} (par. 1 - 25) [RPM]}{\Delta ref [RPM]}$$

**3-75 Ramp 4 S-ramp Ratio at Accel. Start**

**Range:**

50%\* [1 - 99%]

**Function:**

Enter the proportion of the total ramp-up time (par. 3-71) in which the acceleration torque increases. The larger the percentage value, the greater the jerk compensation achieved, and thus the lower the torque jerks in the application.

**3-76 Ramp 4 S-ramp Ratio at Accel. End**

**Range:**

50%\* [1 - 99%]

**Function:**

Enter the proportion of the total ramp-up time (par. 3-71) in which the acceleration torque decreases. The larger the percentage value, the greater the jerk compensation achieved, and thus the lower the torque jerks in the application.

**3-77 Ramp 4 S-ramp Ratio at Decel. Start**

**Range:**

50%\* [1 - 99%]

**Function:**

Enter the proportion of the total ramp-down time (par. 3-72) where the deceleration torque increases. The larger the percentage value, the greater the jerk compensation achieved, and thus the lower the torque jerks in the application.

**3-78 Ramp 4 S-ramp Ratio at Decel. End**

**Range:**

50%\* [1 - 99%]

**Function:**

Enter the proportion of the total ramp-down time (par. 3-72) where the deceleration torque decreases. The larger the percentage value, the greater the jerk compensation achieved, and thus the lower the torque jerks in the application.

**2.6.8. 3-8\* Other Ramps**

Configure parameters for special ramps e.g. Jog or Quick Stop.


**3-80 Jog Ramp Time**

**Range:**

Size related [0.01 - 3600.00 s]

**Function:**

Enter the jog ramp time, i.e. the acceleration/deceleration time between 0 RPM and the rated motor frequency  $n_{M,N}$  (set in par. 1-25 *Motor Nominal Speed*). Ensure that the resultant output current required for the given jog ramp time does not exceed the current limit in par. 4-18. The jog ramp time starts upon activation of a jog signal via the control panel, a selected digital input, or the serial communication port.



$$Par. 3 - 80 = \frac{t_{jog} [s] \times n_{M, N} (par. 1 - 25) [RPM]}{\Delta log speed (par. 3 - 19) [RPM]}$$

**3-81 Quick Stop Ramp Time**

**Range:**


3 s\* [0.01 - 3600.00 s]

**Function:**

Enter the quick-stop ramp-down time, i.e. the deceleration time from the rated motor speed to 0 RPM. Ensure that no resultant over-voltage will arise in the inverter due to regenerative operation of the motor required to achieve the given ramp-down time. Ensure also that the generated current required to achieve the given ramp-

2



down time does not exceed the current limit (set in par. 4-18). Quick-stop is activated by means of a signal on a selected digital input, or via the serial communication port.



$$Par. 3 - 81 = \frac{t_{Qstop} [s] \times n_{M, N} (par. 1 - 25) [RPM]}{\Delta jog ref (par. 3 - 19) [RPM]}$$

### 2.6.9. 3-9\* Digital Pot.Meter

The digital potentiometer function allows the user to increase or decrease the actual reference by adjusting the set-up of the digital inputs using the functions *Increase*, *Decrease* or *Clear*. To activate the function, at least one digital input must be set up to *Increase* or *Decrease*.



### 3-90 Step Size

**Range:**

0.10%\* [0.01 - 200.00%]

**Function:**

Enter the increment size required for INCREASE/DECREASE, as a percentage of the nominal speed set in par. 1-25. If INCREASE/ DECREASE is activated the resulting reference will be increased / decreased by the amount set in this parameter.

### 3-91 Ramp Time

**Range:**

1.00 s\* [0.000 - 3600.00 s]

**Function:**

Enter the ramp time, i.e. the time for adjustment of the reference from 0% to 100% of the specified digital potentiometer function (Increase, Decrease or Clear).



If Increase/ Decrease is activated for longer than the ramp delay period specified in par. 3-95 the actual reference will be ramped up / down according to this ramp time. The ramp time is defined as the time used to adjust the reference by the step size specified in par. 3-90 *Step Size*.

### 3-92 Power Restore

**Option:**

[0] \* Off

[1] On

**Function:**

Resets the Digital Potentiometer reference to 0% after power up.

Restores the most recent Digital Potentiometer reference at power up.

### 3-93 Maximum Limit

**Range:**

100%\* [-200 - 200 %]

**Function:**

Set the maximum permissible value for the resultant reference. This is advisable if the Digital Potentiometer is used for fine tuning of the resulting reference.

### 3-94 Minimum Limit

**Range:**

-100%\* [-200 - 200 %]

**Function:**

Set the minimum permissible value for the resultant reference. This is advisable if the Digital Potentiometer is used for fine tuning of the resulting reference.

### 3-95 Ramp Delay

**Range:**

1.000 s\* [0.000 - 3600.00 s]

**Function:**

Enter the delay required from activation of the digital potentiometer function until the frequency converter starts to ramp the reference. With a delay of 0 ms, the reference starts to ramp as soon as INCREASE/ DECREASE is activated. See also par. 3-91 *Ramp Time*.

## 2.7. Parameters: Limits/Warnings

### 2.7.1. 4-\*\* Limits and Warnings

Parameter group for configuring limits and warnings.

### 2.7.2. 4-1\* Motor Limits

Define torque, current and speed limits for the motor, and the reaction of the frequency converter when the limits are exceeded.

A limit may generate a message on the display. A warning will always generate a message on the display or on the fieldbus. A monitoring function may initiate a warning or a trip, upon which the frequency converter will stop and generate an alarm message.

#### 4-10 Motor Speed Direction

**Option:**

**Function:**

Select the motor speed direction(s) required. Use this parameter to prevent unwanted reversing. When par. 1-00 *Configuration Mode* is set to *Process* [3], par. 4-10 is set to *Clockwise* [0] as default. The setting in par. 4-10 does not limit options for setting par.4-13.

This parameter cannot be adjusted while the motor is running.

[0] *	Clockwise
[1]	Counter clockwise
[2]	Both directions

#### 4-11 Motor Speed Low Limit [RPM]

**Range:**

0 RPM\* [0 - par. 4-13]

**Function:**

Enter the minimum limit for motor speed. The Motor Speed Low Limit can be set to correspond to the manufacturer's recommended minimum motor speed. The Motor Speed Low Limit must not exceed the setting in par. 4-13 *Motor Speed High Limit [RPM]*.

#### 4-12 Motor Speed Low Limit [Hz]

**Range:**

0 Hz\* [0 - par. 4-14]

**Function:**

Enter the minimum limit for motor speed. The Motor Speed Low Limit can be set to correspond to the minimum output frequency of the motor shaft. The Motor Speed Low Limit must not exceed the setting in par. 4-14 *Motor Speed High Limit [Hz]*.

#### 4-13 Motor Speed High Limit [RPM]

**Range:**

3600 RPM [Par. 4-11 - 60.000]

**Function:**

Enter the maximum limit for motor speed. The Motor Speed High Limit can be set to correspond to the manufacturer's maximum rated motor speed. The Motor Speed High Limit must exceed the setting in par. 4-11 *Motor Speed Low Limit [RPM]*.



**NB!**

Max. output frequency cannot exceed 10% of the inverter switching frequency (par. 14-01).


#### 4-14 Motor Speed High Limit [Hz]

**Range:**

Size related\* [0 - 1000 Hz]


**Function:**


Enter the maximum limit for motor speed. The Motor Speed High Limit can be set to correspond to the manufacturer's recommended maximum frequency of the motor shaft. The Motor Speed High Limit must exceed the setting in par. 4-12 *Motor Speed Low Limit [Hz]*. Only par. 4-11 or 4-12 will be displayed depending on other parameters set in the Main Menu and depending on default settings dependant on global geographical location.

 **NB!**  
Max. output frequency cannot exceed 10% of the inverter switching frequency (par. 14-01).

**4-16 Torque Limit Motor Mode**

**Range:** 160.0 %\* [0.0 - Variable Limit %] **Function:** Sets the torque limit for motor operation. The torque limit is active in the speed range up to the rated motor speed (par. 1-25). To protect the motor from reaching the stalling torque, the default setting is 1.6 x the rated motor torque (calculated value). If a setting in par. 1-00 to par. 1-26 is changed, par. 4-16 to 4-18 are not automatically reset to the default settings.



 Changing par. 4-16 *Torque Limit Motor Mode* when par. 1-00 is set to *Speed open loop* [0], par. 1-66 *Min Current at Low Speed* is automatically readjusted.

**4-17 Torque Limit Generator Mode**


**Range:** 160.0 %\* [0.0 - Variable Limit %] **Function:** Sets the torque limit for generator mode operation. The torque limit is active in the speed range up to the rated motor speed (par. 1-25). See illustration for par. 4-16 as well as par. 14-25 for further details.

**4-18 Current Limit**

**Range:** 160.0 %\* [0.0 - Variable Limit %] **Function:** Enter the current limit for motor and generator mode operation. The default setting is 1.6 x the rated motor current (set in par. 1-24). If a setting in par. 1-00 to par. 1-26 is changed, par. 4-16 to par. 4-18 are not automatically reset to the default settings.  
To obtain maximum output torque and prevent the motor from stalling, it is recommendable *not* to set par. 4-18 lower than par. 4-16 and 4-17 (Torque Limits)

**4-19 Max Output Frequency**

**Range:** 132.0 Hz\* [0.0 - 1000.0 Hz] **Function:** Provides a final limit on the output frequency for improved safety in applications where you want to avoid accidental over-speeding. This limit is final in all configurations (independent of the setting in par. 1-00).

 **NB!**  
Max. output frequency cannot exceed 10% of the inverter switching frequency (par. 14-01).

Par. 4-19 cannot be adjusted while the motor is running.

#### 4-20 Torque Limit Factor SourceOption

**Option:**

**Function:**

Select an analog input for scaling the settings in par. 4-16 and 4-17 from 0% to 100% (or inverse). The signal levels corresponding to 0% and 100% are defined in the analog input scaling, e.g. par. group 6-1\*. This parameter is only active when par. 1-00 *Configuration Mode* is in *Speed Open Loop* or *Speed Closed Loop*.

[0] *	No function
[2]	Analog input 53
[4]	Analog input 53 inv
[6]	Analog input 54
[8]	Analog input 54 inv
[10]	Analog input X30-11
[12]	Analog input X30-11 inv
[14]	Analog input X30-12
[16]	Analog input X30-12 inv

#### 4-21 Speed Limit Factor SourceOption

**Option:**

**Function:**

Select an analog input for scaling the settings in par. 4-19 from 0% to 100% (or inverse). The signal levels corresponding to 0% and 100% are defined in the analog input scaling, e.g. par. group 6-1\*. This parameter is only active when par. 1-00 *Configuration Mode* is in *Torque Mode*.

[0] *	No function
[2]	Analog input 53
[4]	Analog input 53 inv
[6]	Analog input 54
[8]	Analog input 54 inv
[10]	Analog input X30-11
[12]	Analog input X30-11 inv
[14]	Analog input X30-12
[16]	Analog input X30-12 inv

### 2.7.3. 4-3\* Motor Feedback Monitoring

The parameter group includes monitoring and handling of motor feedback devices as encoders, resolvers etc.

#### 4-30 Motor Feedback Loss Function

**Option:**

**Function:**

Select which reaction the frequency converter should take in the case a feedback fault is detected. The selected action will take place if the feedback signal differs from the output speed with more than specified in par. 4-31 during the time set in par. 4-32.

[0]	Disabled
[1]	Warning
[2] *	Trip


**4-31 Motor Feedback Speed Error**

**Range:**

300 RPM\* [1-600 RPM]

**Function:**

Select the max allowed tracking error in speed from the calculated and the actual mechanical shaft output speed.



**4-32 Motor Feedback Loss Timeout**

**Range:**

0.05 s\* [0.00 - 60.00 sec]


**Function:**

Set the timeout value allowing the speed error set in par. 4-31 to be exceeded.

**2.7.4. 4-5\* Adjustable Warnings**

Define adjustable warning limits for current, speed, reference and feedback. Warnings are shown on the display, programmed output or serial bus.

Warnings are shown on display, programmed output or serial bus.



**4-50 Warning Current Low**

**Range:**

0.00 A\* [0.00 - par. 4-51]

**Function:**

Enter the  $I_{LOW}$  value. When the motor current falls below this limit, the display reads *Current Low*. The signal outputs can be programmed to produce a status signal on terminal 27 or 29 (FC 302 only) and on relay output 01 or 02 (FC 302 only). Refer to the drawing in this section.

**4-51 Warning Current High****Range:**

par. 16-37 A\* [Par. 4-50 - par. 16-37]

**Function:**

Enter the  $I_{HIGH}$  value. When the motor current exceeds this limit, the display reads *Current High*. The signal outputs can be programmed to produce a status signal on terminal 27 or 29 (FC 302 only) and on relay output 01 or 02 (FC 302 only). Refer to the drawing in this section.

**4-52 Warning Speed Low****Range:**

0 RPM\* [0 - par. 4-13]

**Function:**

Enter the  $n_{LOW}$  value. When the motor speed exceeds this limit, the display reads *Speed Low*. The signal outputs can be programmed to produce a status signal on terminal 27 or 29 (FC 302 only) and on relay output 01 or 02 (FC 302 only).

**4-53 Warning Speed High****Range:**

par. 4-13 RPM\* [Par. 4-52 - par. 4-13]

**Function:**

Enter the  $n_{HIGH}$  value. When the motor speed exceeds this limit, the display reads *Speed High*. The signal outputs can be programmed to produce a status signal on terminal 27 or 29 (FC 302 only) and on relay output 01 or 02 (FC 302 only). Programme the upper signal limit of the motor speed,  $n_{HIGH}$ , within the normal working range of the frequency converter. Refer to the drawing in this section.

**4-54 Warning Reference Low****Range:**

-999999.999\* [-999999.999 - par. 4-55]

**Function:**

Enter the lower reference limit. When the actual reference falls below this limit, the display indicates *Ref Low*. The signal outputs can be programmed to produce a status signal on terminal 27 or 29 (FC 302 only) and on relay output 01 or 02 (FC 302 only).

**4-55 Warning Reference High****Range:**

999999.999\* [Par. 4-54 - 999999.999]

**Function:**

Enter the upper reference limit. When the actual reference exceeds this limit, the display reads *Ref High*. The signal outputs can be programmed to produce a status signal on terminal 27 or 29 (FC 302 only) and on relay output 01 or 02 (FC 302 only).

**4-56 Warning Feedback Low****Range:**

-999999.999\* [-999999.999 - par. 4-57]

**Function:**

Enter the lower feedback limit. When the feedback falls below this limit, the display reads *Feedb Low*. The signal outputs can be programmed to produce a status signal on terminal 27 or 29 (FC 302 only) and on relay output 01 or 02 (FC 302 only).

**4-57 Warning Feedback High****Range:**

999999.999\* [Par. 4-56 - 999999.999]

**Function:**

Enter the upper feedback limit. When the feedback exceeds this limit, the display reads *Feedb High*. The signal outputs can be programmed to produce a status signal on terminal 27 or 29 (FC 302 only) and on relay output 01 or 02 (FC 302 only).

**4-58 Missing Motor Phase Function**

Displays an alarm in the event of a missing motor phase.

[0]	Off	Select [Off] for no missing motor phase alarm. However the [On] setting is strongly recommended to avoid motor damage.
-----	-----	--

[1] *	On	Select [On] to display an alarm in the event of a missing motor phase.
-------	----	--

This parameter cannot be adjusted while the motor is running.

**2.7.5. 4-6\* Speed Bypass**

Define the Speed Bypass areas for the ramps.

Some systems call for avoiding certain output frequencies or speeds, due to resonance problems in the system. A maximum of four frequency or speed ranges can be avoided.

**4-60 Bypass Speed From [RPM]**

Array [4]

**4-60 Bypass Speed From [RPM]**

**Range:**

0 RPM\* [0 - par. 4-13]

**Function:**

Some systems call for avoiding certain output speeds due to resonance problems in the system. Enter the lower limits of the speeds to be avoided.

**4-61 Bypass Speed From [Hz]**

Array [4]

0 Hz\* [0 - par. 4-14 Hz]

Some systems call for avoiding certain output speeds due to resonance problems in the system. Enter the lower limits of the speeds to be avoided.

**4-62 Bypass Speed To [RPM]**

Array [4]

0 RPM\* [0 - par. 4-13]

Some systems call for avoiding certain output speeds due to resonance problems in the system. Enter the upper limits of the speeds to be avoided.

**4-63 Bypass Speed To [Hz]**

Array [4]

0 Hz\* [0 - par. 4-14]

Some systems call for avoiding certain output speeds due to resonance problems in the system. Enter the upper limits of the speeds to be avoided.

## 2.8. Parameters: Digital In/Out

### 2.8.1. 5-\*\* Digital In/Out

Parameter group for configuring the digital input and output.

### 2.8.2. 5-0\* Digital I/O Mode

Parameters for configuring the IO mode. NPN/PNP and setting up IO to Input or Output.

#### 5-00 Digital I/O Mode

Option:	Function:
	Digital inputs and programmed digital outputs are pre-programmable for operation either in PNP or NPN systems.
[0] *	PNP Action on positive directional pulses (‡). PNP systems are pulled down to GND.
[1]	NPN Action on negative directional pulses (‡). NPN systems are pulled up to + 24 V, internally in the frequency converter.



**NB!**

When changing this parameter, a power cycle must be carried out before the parameter change is active.

This parameter cannot be adjusted while the motor is running.

#### 5-01 Terminal 27 Mode

Option:	Function:
[0] *	Input Defines terminal 27 as a digital input.
[1]	Output Defines terminal 27 as a digital output.

This parameter cannot be adjusted while the motor is running.

#### 5-02 Terminal 29 Mode

Option:	Function:
[0] *	Input Defines terminal 29 as a digital input.
[1]	Output Defines terminal 29 as a digital output.

This parameter is available for FC 302 only.

This parameter cannot be adjusted while the motor is running.

### 2.8.3. 5-1\* Digital Inputs

Parameters for configuring the input functions for the input terminals.

The digital inputs are used for selecting various functions in the frequency converter. All digital inputs can be set to the following functions:



Digital input function	Select	Terminal
No operation	[0]	All *term 32, 33
Reset	[1]	All
Coast inverse	[2]	All *term 27
Coast and reset inverse	[3]	All
Quick stop inverse	[4]	All
DC-brake inverse	[5]	All
Stop inverse	[6]	All
Start	[8]	All *term 18
Latched start	[9]	All
Reversing	[10]	All *term 19
Start reversing	[11]	All
Enable start forward	[12]	All
Enable start reverse	[13]	All
Jog	[14]	All *term 29
Preset reference on	[15]	All
Preset ref bit 0	[16]	All
Preset ref bit 1	[17]	All
Preset ref bit 2	[18]	All
Freeze reference	[19]	All
Freeze output	[20]	All
Speed up	[21]	All
Speed down	[22]	All
Set-up select bit 0	[23]	All
Set-up select bit 1	[24]	All
Precise stop inverse	[26]	18, 19
Precises start, stop	[27]	18, 19
Catch up	[28]	All
Slow down	[29]	All
Counter input	[30]	29, 33
Pulse input	[32]	29, 33
Ramp bit 0	[34]	All
Ramp bit 1	[35]	All
Mains failure inverse	[36]	All
Latched precise start	[40]	18, 19
Latched precise stop inverse	[41]	18, 19
DigiPot Increase	[55]	All
DigiPot Decrease	[56]	All
DigiPot Clear	[57]	All
Counter A (up)	[60]	29, 33
Counter A (down)	[61]	29, 33
Reset Counter A	[62]	All
Counter B (up)	[63]	29, 33
Counter B (down)	[64]	29, 33
Reset Counter B	[65]	All
Mech. Brake Feedb.	[70]	All
Mech. Brake Feedb. Inv.	[71]	All
PTC Card 1	[80]	All

All = Terminals 18, 19, 27, 29, 32, 33, X30/2, X30/3, X30/4. X30/ are the terminals on MCB 101.

Terminal 29 is available in FC 302 only.

Functions dedicated to only one digital input are stated in the associated parameter.

All digital inputs can be programmed to these functions:

[0]	No operation	No reaction to signals transmitted to the terminal.
[1]	Reset	Resets frequency converter after a TRIP/ALARM. Not all alarms can be reset.
[2]	Coast inverse	(Default Digital input 27): Coasting stop, inverted input (NC). The frequency converter leaves the motor in free mode. Logic '0' => coasting stop.
[3]	Coast and reset inverse	Reset and coasting stop Inverted input (NC). Leaves motor in free mode and resets frequency converter. Logic '0' => coasting stop and reset.
[4]	Quick stop inverse	Inverted input (NC). Generates a stop in accordance with quick-stop ramp time set in par. 3-81. When motor stops, the shaft is in free mode. Logic '0' => Quick-stop.
[5]	DC-brake inverse	Inverted input for DC braking (NC). Stops motor by energizing it with a DC current for a certain time period. See par. 2-01 to par. 2-03. The function is only active when the value in par. 2-02 is different from 0. Logic '0' => DC braking.
[6]	Stop inverse	Stop Inverted function. Generates a stop function when the selected terminal goes from logical level '1' to '0'. The stop is performed according to the selected ramp time (par. 3-42, par. 3-52, par. 3-62, par. 3-72).



**NB!**

When the frequency converter is at the torque limit and has received a stop command, it may not stop by itself. To ensure that the frequency converter stops, configure a digital output to *Torque limit & stop* [27] and connect this digital output to a digital input that is configured as coast.

[8]	Start	(Default Digital input 18): Select start for a start/stop command. Logic '1' = start, logic '0' = stop.
[9]	Latched start	The motor starts, if a pulse is applied for min. 2 ms. The motor stops when Stop inverse is activated.
[10]	Reversing	(Default Digital input 19). Change the direction of motor shaft rotation. Select Logic '1' to reverse. The reversing signal only changes the direction of rotation. It does not activate the start function. Select both directions in par. 4-10 <i>Motor Speed Direction</i> . The function is not active in process closed loop.
[11]	Start reversing	Used for start/stop and for reversing on the same wire. Signals on start are not allowed at the same time.
[12]	Enable start forward	Rotates motor shaft clockwise at start.
[13]	Enable start reverse	Rotates motor shaft counterclockwise at start.
[14]	Jog	(Default Digital input 29): Use to activate jog speed. See par. 3-11.
[15]	Preset reference on	Shifts between external reference and preset reference. It is assumed that <i>External/preset</i> [1] has been selected in par. 3-04. Logic '0' = external reference active; logic '1' = one of the eight preset references is active.
[16]	Preset ref bit 0	Preset ref. bit 0,1, and 2 enables a choice between one of the eight preset references according to the table below.
[17]	Preset ref bit 1	Same as Preset ref bit 0 [16].
[18]	Preset ref bit 2	Same as Preset ref bit 0 [16].

Preset ref. bit	2	1	0
Preset ref. 0	0	0	0
Preset ref. 1	0	0	1
Preset ref. 2	0	1	0
Preset ref. 3	0	1	1
Preset ref. 4	1	0	0
Preset ref. 5	1	0	1
Preset ref. 6	1	1	0
Preset ref. 7	1	1	1

[19]	Freeze ref	Freezes the actual reference, which is now the point of enable/condition for Speed up and Speed down to be used. If Speed up/down is used, the speed change always follows ramp 2 (par. 3-51 and 3-52) in the range 0 - par. 3-03 <i>Maximum Reference</i> .
[20]	Freeze output	Freezes the actual motor frequency (Hz), which is now the point of enable/condition for Speed up and Speed down to be used. If Speed up/down is used, the speed change always follows ramp 2 (par. 3-51 and 3-52) in the range 0 - par. 1-23 <i>Motor Frequency</i> .



**NB!**

When Freeze output is active, the frequency converter cannot be stopped via a low 'start [8]' signal. Stop the frequency converter via a terminal programmed for Coasting inverse [2] or Coast and reset, inverse.


[21]	Speed up	Select Speed up and Speed down if digital control of the up/down speed is desired (motor potentiometer). Activate this function by selecting either Freeze reference or Freeze output. When Speed up/ down is activated for less than 400 msec. the resulting reference will be increased/ decreased by 0.1 %. If Speed up/ down is activated for more than 400 msec. the resulting reference will follow the setting in ramping up/ down parameter 3-x1/ 3-x2.
------	----------	---

	Shut down	Catch up
Unchanged speed	0	0
Reduced by %-value	1	0
Increased by %-value	0	1
Reduced by %-value	1	1

[22]	Speed down	Same as Speed up [21].
------	------------	------------------------

- [23] Set-up select bit 0 Select Set-up select bit 0 or Select Set-up select bit 1 to select one of the four set-ups. Set par. 0-10 *Active Set-up* to Multi Set-up.
- [24] Set-up select bit 1 (Default Digital input 32): Same as Set-up select bit 0 [23].
- [26] Precise stop inv. Prolongs stop signal to give a precise stop independent of speed. Sends an inverted stop signal when the precise stop function is activated in par. 1-83 *Precise Stop Function*. Precise stop inverse function is available for terminals 18 or 19.

[27] Precise start, stop Use when Precise ramp stop [0] is selected in par 1-83 *Precise stop function*.



- [28] Catch up Increases reference value by percentage (relative) set in par. 3-12.
- [29] Slow down Reduces reference value by percentage (relative) set in par. 3-12.
- [30] Counter input Precise stop function in par. 1-83 acts as Counter stop or speed compensated counter stop with or without reset. The counter value must be set in par. 1-84.
- [32] Pulse input Use pulse sequence as either reference or feedback. Scaling is done in par. group 5-5\*.
- [34] Ramp bit 0 Enables a choice between one of the 4 ramps available, according to the table below.
- [35] Ramp bit 1 Same as Ramp bit 0.

Preset ramp bit	1	0
Ramp 1	0	0
Ramp 2	0	1
Ramp 3	1	0
Ramp 4	1	1

- [36] Mains failure inverse Activates par. 14-10 *Mains Failure*. Mains failure inverse is active in the Logic .0. situation.
- [41] Latched Precise Stop inverse Sends a latched stop signal when the precise stop function is activated in par. 1-83 *Precise Stop Function*. The Latched Precise stop inverse function is available for terminals 18 or 19.
- [55] DigiPot Increase INCREASE signal to the Digital Potentiometer function described in parameter group 3-9\*
- [56] DigiPot Decrease DECREASE signal to the Digital Potentiometer function described in parameter group 3-9\*
- [57] DigiPot Clear Clears the Digital Potentiometer reference described in parameter group 3-9\*
- [60] Counter A (Terminal 29 or 33 only) Input for increment counting in the SLC counter.
- [61] Counter A (Terminal 29 or 33 only) Input for decrement counting in the SLC counter.
- [62] Reset Counter A Input for reset of counter A.
- [63] Counter B (Terminal 29 or 33 only) Input for increment counting in the SLC counter.
- [64] Counter B (Terminal 29 or 33 only) Input for decrement counting in the SLC counter.
- [65] Reset Counter B Input for reset of counter B.
- [70] Mech. Brake Feedback Brake feedback for hoisting applications
- [71] Mech. Brake Feedback inv. Inverted brake feedback for hoisting applications
- [80] PTC Card 1 All Digital Inputs can be set to PTC Card 1 [80]. However, only one Digital Input must be set to this choice.

### 5-10 Terminal 18 Digital Input

Option:	Function:
[8] * Start	Select the function from the available digital input range.

### 5-11 Terminal 19 Digital Input

Option:	Function:
[10] * Reversing	Select the function from the available digital input range.

### 5-12 Terminal 27 Digital Input

Option:	Function:
[2] * Coast inverse	Select the function from the available digital input range.

### 5-13 Terminal 29 Digital Input

Option:	Function:
	Select the function from the available digital input range and the additional options [60], [61], [63] and [64]. Counters are used in Smart Logic Control functions. This parameter is available for FC 302 only.

[14] \* Jog

[60] Counter A (up)

[61] Counter A (down)

[63] Counter B (up)

[64] Counter B (down)

### 5-14 Terminal 32 Digital Input

Option:	Function:
[0] * No operation	Select the function from the available digital input range.

### 5-15 Terminal 33 Digital Input

Option:	Function:
	Select the function from the available digital input range and the additional options [60], [61], [63] and [64]. Counters are used in Smart Logic Control functions.

[0] \* No operation

[60] Counter A (up)

[61] Counter A (down)

[63] Counter B (up)

[64] Counter B (down)

### 5-16 Terminal X30/3 Digital Input

Option:	Function:
[0] * No operation	This parameter is active when option module MCB 101 is installed in the frequency converter. Follow the function stated in 5-1*

### 5-17 Terminal X30/4 Digital Input

Option:	Function:
[0] * No operation	This parameter is active when option module MCB 101 is installed in the frequency converter. Follow the function stated in 5-1*

### 5-18 Terminal X30/4 Digital Input

Option:	Function:
[0] * No operation	This parameter is active when option module MCB 101 is installed in the frequency converter. Follow the function stated in 5-1*

**5-19 Terminal 37 Safe Stop**

**Option:**

**Function:**

[1] *	Safe Stop Alarm	Coasts frequency converter when safe stop is activated. Manual reset from LCP, digital input or fieldbus.
[3]	Safe Stop Auto Reset	Coasts frequency converter when safe stop is activated (term 37 off). When safe stop circuit is reestablished, the frequency converter will continue without manual reset.
[4]	PTC 1 Alarm	Coasts frequency converter when safe stop is activated. Manual reset from LCP, digital input or fieldbus. Choice 4 is only available when the MCB 112 PTC Thermistor Card is connected.
[5]	PTC 1 Warning	Coasts frequency converter when safe stop is activated (term 37 off). When safe stop circuit is reestablished, the frequency converter will continue without manual reset, unless a Digital Input set to PTC Card 1 [80] is still enabled. Choice 5 is only available when the MCB 112 PTC Thermistor Card is connected.
[6]	PTC 1 & Relay A	This choice is used when the PTC option is gated together with a Stop button through a Safety relay to T-37. Coasts frequency converter when safe stop is activated. Manual reset from LCP, digital input or fieldbus. Choice 6 is only available when the MCB 112 PTC Thermistor Card is connected.
[7]	PTC 1 & Relay W	This choice is used when the PTC option is gated together with a Stop button through a Safety relay to T-37. Coasts frequency converter when safe stop is activated (term 37 off). When safe stop circuit is reestablished, the frequency converter will continue without manual reset, unless a Digital Input set to PTC Card 1 [80] is (still) enabled. Choice 7 is only available when the MCB 112 PTC Thermistor Card is connected.
[8]	PTC 1 & Relay A/W	This choice makes it possible to use a combination of Alarm and Warning. Choice 8 is only available when the MCB 112 PTC Thermistor Card is connected.
[9]	PTC 1 & Relay W/A	This choice makes it possible to use a combination of Alarm and Warning. Choice 9 is only available when the MCB 112 PTC Thermistor Card is connected.



**NB!**

When Auto Reset/ Warning is selected the frequency converter opens up for automatic restart.

**Overview of functions, alarms and warnings**

Function	No.	PTC	Relay
No Function	[0]	-	-
Safe Stop Alarm	[1]*	-	Safe Stop [A68]
Safe Stop Warning	[3]	-	Safe Stop [W68]
PTC 1 Alarm	[4]	PTC 1 Safe Stop [A71]	-
PTC 1 Warning	[5]	PTC 1 Safe Stop [W71]	-
PTC 1 & Relay A	[6]	PTC 1 Safe Stop [A71]	Safe Stop [A68]
PTC 1 & Relay W	[7]	PTC 1 Safe Stop [W71]	Safe Stop [W68]
PTC 1 & Relay A/W	[8]	PTC 1 Safe Stop [A71]	Safe Stop [W68]
PTC 1 & Relay W/A	[9]	PTC 1 Safe Stop [W71]	Safe Stop [A68]

W means warning and A means alarm. For further information, see Alarms and Warnings in section *Troubleshooting* in the Design Guide or the Operating Instructions

A dangerous failure related to Safe Stop will give Alarm: Dangerous Failure [A72].

**2.8.4. 5-3\* Digital Outputs**

Parameters for configuring the output functions for the output terminals. The 2 solid-state digital outputs are common for terminals 27 and 29. Set the I/O function for terminal 27 in par. 5-01 *Terminal 27 Mode*, and set the I/O function for terminal 29 in par. 5-02 *Terminal 29 Mode*. These parameters cannot be adjusted while the motor is running.

[0]	No operation	<i>Default for all digital outputs and relay outputs</i>
[1]	Control ready	The control board receives supply voltage.
[2]	Drive ready	The frequency converter is ready for operation and applies a supply signal on the control board.

[3]	Drive ready / remote control	The frequency converter is ready for operation and is in Auto On mode.
[4]	Enable / no warning	Ready for operation. No start or stop command is been given (start/disable). There are no warnings.
[5]	VLT running	Motor is running.
[6]	Running / no warning	Output speed is higher than the speed set in par. 1-81 <i>Min Speed for Function at Stop [RPM]</i> . The motor is running and there are no warnings.
[7]	Run in range / no warning	Motor is running within the programmed current and speed ranges set in par. 4-50 to par. 4-53. There are no warnings.
[8]	Run on reference / no warning	Motor runs at reference speed.
[9]	Alarm	An alarm activates the output. There are no warnings.
[10]	Alarm or warning	An alarm or a warning activates the output.
[11]	At torque limit	The torque limit set in par. 4-16 or par. 1-17 has been exceeded.
[12]	Out of current range	The motor current is outside the range set in par. 4-18.
[13]	Below current, low	Motor current is lower than set in par. 4-50.
[14]	Above current, high	Motor current is higher than set in par. 4-51.
[15]	Out of range	Output frequency is outside the frequency range set in any limit parameter.
[16]	Below speed, low	Output speed is lower than the setting in par. 4-52.
[17]	Above speed, high	Output speed is higher than the setting in par. 4-53.
[18]	Out of feedback range	Feedback is outside the range set in par. 4-56 and 4-57.
[19]	Below feedback low	Feedback is below the limit set in par. 4-56 <i>Warning Feedback Low</i> .
[20]	Above feedback high	Feedback is above the limit set in par. 4-57 <i>Warning Feedback High</i> .
[21]	Thermal warning	The thermal warning turns on when the temperature exceeds the limit in the motor, the frequency converter, the brake resistor, or the thermistor.
[22]	Ready, no thermal warning	Frequency converter is ready for operation and there is no over-temperature warning.
[23]	Remote, ready, no thermal warning	Frequency converter is ready for operation and is in Auto On mode. There is no over-temperature warning.
[24]	Ready, no over-/ under voltage	Frequency converter is ready for operation and the mains voltage is within the specified voltage range (see <i>General Specifications</i> section).
[25]	Reverse	<i>Reversing. Logic '1'</i> when CW rotation of the motor. Logic '0' when CCW rotation of the motor. If the motor is not rotating the output will follow the reference.
[26]	Bus OK	Active communication (no time-out) via the serial communication port.
[27]	Torque limit and stop	Use in performing a coasting stop and in torque limit condition. If the frequency converter has received a stop signal and is at the torque limit, the signal is Logic '0'.
[28]	Brake, no brake warning	Brake is active and there are no warnings.
[29]	Brake ready, no fault	Brake is ready for operation and there are no faults.
[30]	Brake fault (IGBT)	Output is Logic '1' when the brake IGBT is short-circuited. Use this function to protect the frequency converter if there is a fault on the brake modules. Use the output/relay to cut out the main voltage from the frequency converter.
[31]	Relay 123	Relay is activated when Control Word [0] is selected in parameter group 8-**.
[32]	Mechanical brake control	Enables control of an external mechanical brake, see description in the section <i>Control of Mechanical Brake</i> , and par. group 2-2*
[33]	Safe stop activated (FC 302 only)	Indicates that the safe stop on terminal 37 has been activated.
[40]	Out of ref range	
[41]	Below reference low	
[42]	Above reference high	
[45]	Bus Ctrl	

[46]	Bus Ctrl On at timeout	
[47]	Bus Ctrl Off at timeout	
[51]	MCO controlled	
[55]	Pulse output	
[60]	Comparator 0	See par. group 13-1*. If Comparator 0 is evaluated as TRUE, the output will go high. Otherwise, it will be low.
[61]	Comparator 1	See par. group 13-1*. If Comparator 1 is evaluated as TRUE, the output will go high. Otherwise, it will be low.
[62]	Comparator 2	See par. group 13-1*. If Comparator 2 is evaluated as TRUE, the output will go high. Otherwise, it will be low.
[63]	Comparator 3	See par. group 13-1*. If Comparator 3 is evaluated as TRUE, the output will go high. Otherwise, it will be low.
[64]	Comparator 4	See par. group 13-1*. If Comparator 4 is evaluated as TRUE, the output will go high. Otherwise, it will be low.
[65]	Comparator 5	See par. group 13-1*. If Comparator 5 is evaluated as TRUE, the output will go high. Otherwise, it will be low.
[70]	Logic Rule 0	See par. group 13-4*. If Logic Rule 0 is evaluated as TRUE, the output will go high. Otherwise, it will be low.
[71]	Logic Rule 1	See par. group 13-4*. If Logic Rule 1 is evaluated as TRUE, the output will go high. Otherwise, it will be low.
[72]	Logic Rule 2	See par. group 13-4*. If Logic Rule 2 is evaluated as TRUE, the output will go high. Otherwise, it will be low.
[73]	Logic Rule 3	See par. group 13-4*. If Logic Rule 3 is evaluated as TRUE, the output will go high. Otherwise, it will be low.
[74]	Logic Rule 4	See par. group 13-4*. If Logic Rule 4 is evaluated as TRUE, the output will go high. Otherwise, it will be low.
[75]	Logic Rule 5	See par. group 13-4*. If Logic Rule 5 is evaluated as TRUE, the output will go high. Otherwise, it will be low.
[80]	SL Digital Output A	See par. 13-52 <i>SL Control Action</i> . The output will go high whenever the Smart Logic Action [38] <i>Set dig. out. A high</i> is executed. The output will go low whenever the Smart Logic Action [32] <i>Set dig. out. A low</i> is executed.
[81]	SL Digital Output B	See par. 13-52 <i>SL Control Action</i> . The input will go high whenever the Smart Logic Action [39] <i>Set dig. out. A high</i> is executed. The input will go low whenever the Smart Logic Action [33] <i>Set dig. out. A low</i> is executed.
[82]	SL Digital Output C	See par. 13-52 <i>SL Control Action</i> . The input will go high whenever the Smart Logic Action [40] <i>Set dig. out. A high</i> is executed. The input will go low whenever the Smart Logic Action [34] <i>Set dig. out. A low</i> is executed.
[83]	SL Digital Output D	See par. 13-52 <i>SL Control Action</i> . The input will go high whenever the Smart Logic Action [41] <i>Set dig. out. A high</i> is executed. The input will go low whenever the Smart Logic Action [35] <i>Set dig. out. A low</i> is executed.
[84]	SL Digital Output E	See par. 13-52 <i>SL Control Action</i> . The input will go high whenever the Smart Logic Action [42] <i>Set dig. out. A high</i> is executed. The input will go low whenever the Smart Logic Action [36] <i>Set dig. out. A low</i> is executed.
[85]	SL Digital Output F	See par. 13-52 <i>SL Control Action</i> . The input will go high whenever the Smart Logic Action [43] <i>Set dig. out. A high</i> is executed. The input will go low whenever the Smart Logic Action [37] <i>Set dig. out. A low</i> is executed.
[120]	Local reference active	Output is high when par. 3-13 <i>Reference Site</i> = [2] <i>Local</i> or when par. 3-13 <i>Reference Site</i> = [0] <i>Linked to hand auto</i> at the same time as the LCP is in Hand on mode.
[121]	Remote reference active	Output is high when par. 3-13 <i>Reference Site</i> = <i>Remote</i> [1] or <i>Linked to hand/auto</i> [0] while the LCP is in [Auto on] mode.
[122]	No alarm	Output is high when no alarm is present.
[123]	Start command active	Output is high when there is an active Start command (i.e. via digital input bus connection or [Hand on] or [Auto on]), and no Stop or Start command is active.
[124]	Running reverse	Output is high when the frequency converter is running counter clockwise (the logical product of the status bits 'running' AND 'reverse').
[125]	Drive in hand mode	Output is high when the frequency converter is in Hand on mode (as indicated by the LED light above [Hand on]).
[126]	Drive in auto mode	Output is high when the frequency converter is in Hand on mode (as indicated by the LED light above [Auto on]).

**5-30 Terminal 27 Digital Output**

**Option:**

**Function:**

[45]	Bus ctrl.	Controls output via bus. The state of the output is set in par. 5-90. The output state is retained in the event of bus time-out.
[46]	Bus ctrl. on at timeout	Controls output via bus. The state of the output is set in par. 5-90. In the event of bus time-out the output state is set high (On).
[47]	Bus ctrl. off at timeout	Controls output via bus. The state of the output is set in par. 5-90. In the event of bus time-out the output state is set low (Off).

### 5-31 Terminal 29 Digital Output

Option:	Function:
[45] Bus ctrl.	Controls output via bus. The state of the output is set in par. 5-90. The output state is retained in the event of bus time-out.
[46] Bus ctrl. on at timeout	Controls output via bus. The state of the output is set in par. 5-90. In the event of bus time-out the output state is set high (On).
[47] Bus ctrl. off at timeout	Controls output via bus. The state of the output is set in par. 5-90. In the event of bus time-out the output state is set low (Off).

This parameter only applies for FC 302.

### 5-32 Terminal X30/6 Digital Output (MCB 101)

Option:	Function:
[0] * No operation	This parameter is active when option module MCB 101 is mounted in the frequency converter. Follow the function stated in 5-3*.

### 5-33 Terminal X30/7 Digital Output (MCB 101)

Option:	Function:
[0] * No operation	This parameter is active when option module MCB 101 is mounted in the frequency converter. Follow the function stated in 5-3*.

## 2.8.5. 5-4\* Relays

Parameters for configuring the timing and the output functions for the relays.

### 5-40 Function Relay

Option:	Function:
[0] (Relay 1)	Relay 2 is included in FC 302 only. Par. 5-40 functions are as for par. 5-3*, including options 36 and 37. Par. 5-40 options are as for par. 5-30, including options 36 and 37. Relay 2 is included in FC 302 only. Relay 3, 4, 5 and 6 are included in MCB 113 Relay option module. Relay 7, 8 and 9 are included in MCB 105 Relay option module.
[1] (Relay 2)	
[2] Relay 3	
[3] Relay 4	
[4] Relay 5	
[5] Relay 6	
[6] Relay 7	
[7] Relay 8	
[8] Relay 9	
[36] Control word bit 11	
[37] Control word bit 12	


### 5-41 On Delay, Relay

Enter the delay of the relay cut-in time. Select one of available mechanical relays and MCO 105 in an array function. See par. 5-40.

Array [8] (Relay 1 [0], Relay 2 [1], Relay 7 [6], Relay 8 [7], Relay 9 [8])

0.01s\* [0.01 - 600.00 s]





**5-42 Off Delay, Relay**

Enter the delay of the relay cut-out time. Select one of available mechanical relays and MCO 105 in an array function. See par. 5-40.

Array [8] (Relay 1 [0], Relay 2 [1], Relay 7 [6], Relay 8 [7], Relay 9 [8])


0.01s\* [0.01 - 600.00 s.]

The diagram shows a 'Selected Event' signal that transitions from high to low during the 'On Delay' period. Despite this change, the 'Relay output' continues to rise and reaches its high state after the 'On Delay' (P 5-41). Similarly, when the 'Selected Event' transitions from low to high during the 'Off Delay' period, the 'Relay output' continues to stay high until the 'Off Delay' (P 5-42) expires. The diagram is labeled '130BA172.10'.

If the Selected Event condition changes before the on- or off delay timer expires, the relay output is unaffected.

**2.8.6. 5-5\* Pulse Input**

The pulse input parameters are used to define an appropriate window for the impulse reference area by configuring the scaling and filter settings for the pulse inputs. Input terminals 29 or 33 act as frequency reference inputs. Set terminal 29 (par. 5-13) or terminal 33 (par. 5-15) to *Pulse input* [32]. If terminal 29 is used as an input, then set par. 5-01 to *Input* [0].



**5-50 Term. 29 Low Frequency**

**Range:**

100 Hz\* [0 - 110000 Hz]

**Function:**

Enter the low frequency limit corresponding to the low motor shaft speed (i.e. low reference value) in par. 5-52. Refer to the diagram in this section. This parameter is available for FC 302 only.

**5-51 Term. 29 High Frequency****Range:**

100 Hz [0 - 110000 Hz]

**Function:**

Enter the high frequency limit corresponding to the high motor shaft speed (i.e. high reference value) in par. 5-53.

This parameter is available for FC 302 only.

**5-52 Term. 29 Low Ref./Feedb. Value****Range:**

0.000\* [-1000000.000 - par. 5-53]

**Function:**

Enter the low reference value limit for the motor shaft speed [RPM]. This is also the lowest feedback value, see also par. 5-57. Set terminal 29 to digital output (par. 5-02 = *Output* [1] and par. 5-13 = applicable value).

This parameter is available for FC 302 only.

**5-53 Term. 29 High Ref./Feedb. Value****Range:**

1500.000\* [Par. 5-52 - 1000000.000]

**Function:**

Enter the high reference value [RPM] for the motor shaft speed and the high feedback value, see also par.5-58.

Select terminal 29 as a digital output (par. 5-02 = *Output* [1] and par. 5-13 = applicable value).

This parameter is available for FC 302 only.

**5-54 Pulse Filter Time Constant #29****Range:**

100 ms\* [1 - 1000 ms]

**Function:**

Enter the pulse filter time constant. The pulse filter dampens oscillations of the feedback signal, which is an advantage if there is a lot of noise in the system. A high time constant value results in better dampening but also increases the time delay through the filter. This parameter is available for FC 302 only.

This parameter cannot be adjusted while the motor is running.

**5-55 Term. 33 Low Frequency****Range:**

100Hz\* [0 - 110000 Hz]

**Function:**

Enter the low frequency corresponding to the low motor shaft speed (i.e. low reference value) in par. 5-57. Refer to the diagram in this section.

**5-56 Term. 33 High Frequency****Range:**

100Hz\* [0 - 110000 Hz]

**Function:**

Enter the high frequency corresponding to the high motor shaft speed (i.e. high reference value) in par. 5-58.

**5-57 Term. 33 Low Ref./Feedb. Value****Range:**

0.000 \* [-100000.000 – par. 5-58]

**Function:**

Enter the low reference value [RPM] for the motor shaft speed. This is also the low feedback value, see also par. 5-52.

**5-58 Term. 33 High Ref./Feedb. Value****Range:**

1500.000\* [Par. 5-57 - 100000.000]

**Function:**

Enter the high reference value [RPM] for the motor shaft speed. See also par. 5-53 *Term. 29 High Ref./Feedb. Value*.

**5-59 Pulse Filter Time Constant #33****Range:**

100 ms [1 - 1000 ms]


**Function:**

Enter the pulse filter time constant. The low-pass filter reduces the influence on and dampens oscillations on the feedback signal from the control.

This is an advantage, e.g. if there is a great amount on noise in the system. This parameter cannot be adjusted while the motor is running.

### 2.8.7. 5-6\* Pulse Outputs

Parameters for configuring the scaling and output functions of pulse outputs. The pulse outputs are designated to terminals 27 or 29. Select terminal 27 output in par. 5-01 and terminal 29 output in par. 5-02.



Options for readout output variables:

Parameters for configuring the scaling and output functions of pulse outputs. The pulse outputs are designated to terminals 27 or 29. Select terminal 27 output in par. 5-01 and terminal 29 output in par. 5-02.

[0] *	No operation
[45]	Bus control
[48]	Bus control time-out
[51]	MCO controlled
[100]	Output frequency
[101]	Reference
[102]	Feedback
[103]	Motor current
[104]	Torque relative to limit
[105]	Torque relative to rated
[106]	Power
[107]	Speed
[108]	Torque
[109]	Max Out Freq

#### 5-60 Terminal 27 Pulse Output Variable

Option:	Function:
[0] No operation	Select the variable for viewing on the terminal 27 display. This parameter cannot be adjusted while the motor is running.

#### 5-62 Pulse Output Maximum Frequency #27

Range:	Function:
5000 Hz* [0 - 32000 Hz]	Set the maximum frequency for terminal 27, corresponding to the output variable selected in par. 5-60. This parameter cannot be adjusted while the motor is running.

#### 5-63 Terminal 29 Pulse Output Variable

Option:	Function:
[0] * No operation	Select the variable for viewing on the terminal 29 display. This parameter is available for FC 302 only. This parameter cannot be adjusted while the motor is running.

**5-65 Pulse Output Maximum Frequency #29**

**Option:**

[5000Hz]\* 0 - 32000 Hz

**Function:**

Set the maximum frequency for terminal 29 corresponding to the output variable set in par. 5-63. This parameter cannot be adjusted while the motor is running.

**5-66 Terminal X30/6 Pulse Output Variable**

**Option:**

[0]\* No operation

**Function:**

Select the variable for read-out on terminal X30/6. This parameter cannot be adjusted while the motor is running. This parameter is active when option module MCB 101 is installed in the frequency converter.

**5-68 Pulse Output Maximum Frequency #X30/6**

**Range:**

5000Hz\* [0 - 32000 Hz]


**Function:**

Select the maximum frequency on terminal X30/6 referring to the output variable in par. 5-66. This parameter cannot be adjusted while the motor is running. This parameter is active when option module MCB 101 is mounted in the frequency converter.

**2.8.8. 5-7\* 24 V Encoder Input**

Parameters for configuring the 24 V encoder.

Connect the 24 V encoder to terminal 12 (24 V DC supply), terminal 32 (Channel A), terminal 33 (Channel B), and terminal 20 (GND). The digital inputs 32/33 are active for encoder inputs when 24 V encoder is selected in par. 1-02 and par. 7-00. The encoder used is a dual channel (A and B) 24 V type. Max input frequency: 110 kHz.



**5-70 Term 32/33 Pulses per Revolution**

**Range:**

1024PPR\* [128 - 4096 PPR]

**Function:**

Set the encoder pulses per revolution on the motor shaft. Read the correct value from the encoder. This parameter cannot be adjusted while the motor is running.

**5-71 Term 32/33 Encoder Direction**

Option:	Function:
[0] *      Clockwise	Change the detected encoder rotation direction without changing the wiring to the encoder. Sets channel A 90° (electrical degrees) behind channel B upon clockwise rotation of the encoder shaft.
[1]          Counter clockwise	Sets channel A 90° (electrical degrees) ahead of channel B upon clockwise rotation of the encoder shaft.

This parameter cannot be adjusted while the motor is running.

**2.8.9. 5-9\*Bus Controlled**

This parameter group selects digital and relay outputs via a fieldbus setting.

**5-90 Digital & Relay Bus Control**

Option:	Function:
[0] *      0 - FFFFFFFF	This parameter holds the state of the digital outputs and relays that is controlled by bus. A logical '1' indicates that the output is high or active. A logical '0' indicates that the output is low or inactive.

Bit 0	Digital Output Terminal 27
Bit 1	Digital Output Terminal 29
Bit 2	Digital Output Terminal X 30/6
Bit 3	Digital Output Terminal X 30/7
Bit 4	Relay 1 output terminal
Bit 5	Relay 2 output terminal
Bit 6	Option B Relay 1 output terminal
Bit 7	Option B Relay 2 output terminal
Bit 8	Option B Relay 3 output terminal
Bit 9-15	Reserved for future terminals
Bit 16	Option C Relay 1 output terminal
Bit 17	Option C Relay 2 output terminal
Bit 18	Option C Relay 3 output terminal
Bit 19	Option C Relay 4 output terminal
Bit 20	Option C Relay 5 output terminal
Bit 21	Option C Relay 6 output terminal
Bit 22	Option C Relay 7 output terminal
Bit 23	Option C Relay 8 output terminal
Bit 24-31	Reserved for future terminals

**5-93 Pulse Output #27 Bus Control**

Range:	Function:
0%* [0.00 - 100.00%]	Set the output frequency transferred to the output terminal 27 when the terminal is configured as 'Bus Controlled' in par. 5-60 [45].

**5-94 Pulse Output #27 Time-out Preset**

Range:	Function:
0.00%* [0.00 - 100.00%]	Set the output frequency transferred to the output terminal 27 when the terminal is configured as 'Bus Ctrl Timeout' in par. 5-60 [48]. And a time-out is detected.

**5-95 Pulse Output #29 Bus Control**

Range:	Function:
0%* [0.00 - 100.00%]	Set the output frequency transferred to the output terminal 29 when the terminal is configured as 'Bus Controlled' in par. 5-60 [45]. This parameter only applies for FC 302.

**5-96 Pulse Output #29 Time-out Preset**

Range:	Function:
0.00%* [0.00 - 100.00%]	Set the output frequency transferred to the output terminal 29 when the terminal is configured as 'Bus Ctrl Timeout' in par. 5-60 [48]. And a time-out is detected.

*This parameter only applies for FC 302.*

## 2.9. Parameters: Analog In/Out

### 2.9.1. 6-\*\* Analog In/Out

Parameter group for configuration of the analog input and output.

### 2.9.2. 6-0\* Analog I/O Mode

The analog inputs can freely be allocated to be either voltage (FC 301: 0..10 V, FC 302: 0..+/- 10V) or current (FC 301/302: 0/4..20 mA) input.



**NB!**

Thermistors may be connected to either an analog or a digital input.

#### 6-00 Live Zero Timeout Time

**Range:**

10s\* [1 - 99 s]

**Function:**

Enter the Live Zero Time-out time period. Live Zero Time-out Time is active for analog inputs, i.e. terminal 53 or terminal 54, allocated to current and used as reference or feedback sources. If the reference signal value associated with the selected current input falls below 50% of the value set in par. 6-10, par. 6-12, par. 6-20 or par. 6-22 for a time period longer than the time set in par. 6-00, the function selected in par. 6-01 will be activated.

#### 6-01 Live Zero Timeout Function

**Option:**

**Function:**

Select the time-out function. The function set in par. 6-01 will be activated if the input signal on terminal 53 or 54 is below 50% of the value in par. 6-10, par. 6-12, par. 6-20 or par. 6-22 for a time period defined in par. 6-00. If several time-outs occur simultaneously, the frequency converter prioritises the time-out functions as follows:

1. Par. 6-01 *Live Zero Time-out Function*
2. Par. 5-74 *Encoder Loss Function*
3. Par. 8-04 *Control-word Time-out Function*

The output frequency of the frequency converter can be:


The output frequency of the frequency converter can be:

- [1] frozen at the present value
- [2] overruled to stop
- [3] overruled to jog speed
- [4] overruled to max. speed
- [5] overruled to stop with subsequent trip

[0] *	Off
[1]	Freeze Output
[2]	Stop
[3]	Jogging
[4]	Max. speed
[5]	Stop and trip

### 2.9.3. 6-1\* Analog Input 1

Parameters for configuring the scaling and limits for analog input 1 (terminal 53).



**6-10 Terminal 53 Low Voltage**

**Range:** 0.07 V\* [FC 301: 0V - par. 6-11]  
[FC 302: -10V - par. 6-11]

**Function:** Enter the low voltage value. This analog input scaling value should correspond to the minimum reference value, set in par. 6-14. See also the section *Reference Handling*.

**6-11 Terminal 53 High Voltage**

**Range:** 10.0V\* [Par. 6-10 to 10.0 V]

**Function:** Enter the high voltage value. This analog input scaling value should correspond to the high reference/feedback value set in par. 6-15.

**6-12 Terminal 53 Low Current**

**Range:** 0.14 mA\* [0.0 to par. 6-13 mA]

**Function:** Enter the low current value. This reference signal should correspond to the minimum reference value, set in par. 3-02. The value must be set at >2 mA in order to activate the Live Zero Time-out Function in par. 6-01.

**6-13 Terminal 53 High Current**

**Range:** 20.0 mA\* [ Par. 6-12 to 20.0 mA]

**Function:** Enter the high current value corresponding to the high reference/feedback set in par. 6-15.

**6-14 Terminal 53 Low Ref./Feedb. Value**

**Range:** 0.000 Unit\* [-1000000.000 to par. 6-15]

**Function:** Enter the analog input scaling value that corresponds to the low voltage/low current set in par. 6-10 and 6-12.

**6-15 Terminal 53 High Ref./Feedb. Value**

**Range:** 1500.000 Unit\* [Par. 6-14 to 1000000.000]

**Function:** Enter the analog input scaling value that corresponds to the maximum reference feedback value set in par. 6-11 and 6-13.

**6-16 Terminal 53 Filter Time Constant**

**Range:** 0.001s\* [0.001 - 10.000 s]

**Function:** Enter the time constant. This is a first-order digital low pass filter time constant for suppressing electrical noise in terminal 53. A high time constant value improves dampening but also increases the time delay through the filter.  
This parameter cannot be adjusted while the motor is running.

### 2.9.4. 6-2\* Analog Input 2

Parameters for configuring the scaling and limits for analog input 2 (terminal 54).

#### 6-20 Terminal 54 Low Voltage

<b>Range:</b>	<b>Function:</b>
0.07 V* [FC 301: 0V - par. 6-11] [FC 302: -10V - par. 6-11]	Enter the low voltage value. This analog input scaling value should correspond to the minimum reference value, set in par. 3-02. See also the section <i>Reference Handling</i> .

#### 6-21 Terminal 54 High Voltage

<b>Range:</b>	<b>Function:</b>
10.0V* [Par. 6-20 to 10.0 V]	Enter the high voltage value. This analog input scaling value should correspond to the high reference/feedback value set in par. 6-25.

#### 6-22 Terminal 54 Low Current

<b>Range:</b>	<b>Function:</b>
0.14 mA* [0.0 to par. 6-23 mA]	Enter the low current value. This reference signal should correspond to the minimum reference value, set in par. 3-02. The value must be set at >2 mA in order to activate the Live Zero Time-out Function in par. 6-01.

#### 6-23 Terminal 54 High Current

<b>Range:</b>	<b>Function:</b>
20.0 mA* [Par. 6-22 to - 20.0 mA]	Enter the high current value corresponding to the high reference/feedback value set in par. 6-25.

#### 6-24 Terminal 54 Low Ref./Feedb. Value

<b>Range:</b>	<b>Function:</b>
0.000 Unit* [-1000000.000 to par. 6-25]	Enter the analog input scaling value that corresponds to the minimum reference feedback value set in par. 3-02.

#### 6-25 Terminal 54 high ref./feedb. value

<b>Range:</b>	<b>Function:</b>
1500.000 Unit* [Par. 6-24 to 1000000.000]	Enter the analog input scaling value that corresponds to the maximum reference feedback value set in par. 3-03.

#### 6-26 Terminal 54 Filter Time Constant

<b>Range:</b>	<b>Function:</b>
0.001s* [0.001 - 10.000 s]	Enter the time constant. This is a first-order digital low pass filter time constant for suppressing electrical noise in terminal 54. A high time constant value improves dampening but also increases the time delay through the filter. This parameter cannot be adjusted while the motor is running.

### 2.9.5. 6-3\* Analog Input 3 (MCB 101)

Parameter group for configuring the scale and limits for analog input 3 (X30/11) placed on option module MCB 101.

#### 6-30 Term. X30/11 Low Voltage

<b>Range:</b>	<b>Function:</b>
0.07 V* [0 - par. 6-31]	Sets the analog input scaling value to correspond to the low reference/feedback value (set in par. 6-34).

#### 6-31 Term. X30/11 High Voltage

<b>Range:</b>	<b>Function:</b>
10.0 V* [Par. 6-30 to 10.0 V]	Sets the analog input scaling value to correspond to the high reference/feedback value (set in par. 6-35).



**6-34 Term. X30/11 Low Ref./Feedb. Value**

**Range:** 0.000 Unit\* [1000000.000 to par. 6-35]  
**Function:** Sets the analog input scaling value to correspond to the low voltage value (set in par. 6-30).

**6-35 Term. X30/11 High Ref./Feedb. Value**

**Range:** 1500.000 Unit [Par. 6-34 to 1000000.000]  
**Function:** Sets the analog input scaling value to correspond to the high voltage value (set in par. 6-31).

**6-36 Term. X30/11 Filter Time Constant**

**Range:** 0.001s\* [0.001 - 10.000 s]  
**Function:** A 1<sup>st</sup> order digital low pass filter time constant for suppressing electrical noise on terminal X30/11. Par. 6-36 cannot be changed while the motor is running.

**2.9.6. 6-4\* Analog Input 4 (MCB 101)**

Parameter group for configuring the scale and limits for analog input 4 (X30/12) placed on option module MCB 101.

**6-40 Term. X30/12 Low Voltage**

**Range:** 0.7 V\* [0 to par. 6-41]  
**Function:** Sets the analog input scaling value to correspond to the low reference/feedback value set in par. 6-44.

**6-41 Term. X30/12 High Voltage**

**Range:** 10.0V\* [Par. 6-40 to 10.0 V]  
**Function:** Sets the analog input scaling value to correspond to the high reference/feedback value set in par. 6-45.

**6-44 Term. X30/12 Low Ref./Feedb. Value**

Sets the analog input scaling value to correspond to the low voltage value set in par. 6-40.

0.000 Unit\* [-1000000.000 to par. 6-45]

**6-45 Term. X30/12 High Ref./Feedb. Value**

**Range:** 1500.000 Unit\* [Par. 6-44 to 1000000.000]  
**Function:** Sets the analog input scaling value to correspond to the high voltage value set in par. 6-41.

**6-46 Term. X30/12 Filter Time Constant**

**Range:** 0.001s\* [0.001 - 10.000 s]  
**Function:** A 1<sup>st</sup> order digital low pass filter time constant for suppressing electrical noise on terminal X30/12. Par. 6-46 cannot be changed while the motor is running.

**2.9.7. 6-5\* Analog Output 1**

Parameters for configuring the scaling and limits for analog output 1, i.e. Terminal 42. Analog outputs are current outputs: 0/4 – 20 mA. Common terminal (terminal 39) is the same terminal and has the same electrical potential for analog common and digital common connection. Resolution on analog output is 12 bit.

**6-50 Terminal 42 Output**

**Option:** [0]  
**Function:** Select the function of Terminal 42 as an analog current output.

[0] No operation

[52]	MCO 305 0-20 mA
[53]	MCO 305 4-20 mA
[100]	Output frequency 0-20 mA
[101]	Reference 0-20 mA
[102]	Feedback
[103]	Motor current 0-20 mA
[104]	Torque rel to lim 0-20 mA
[105]	Torque rel to rated 0-20 mA
[106]	Power
[107]	Speed
[108]	Torque
[109]	Max Out Freq 0-20 mA
[130]	Output freq. 4-20 mA
[131]	Reference 4-20 mA
[132]	Feedback 4-20 mA
[133]	Motor cur. 4-20 mA
[134]	Torque % lim. 4-20 mA
[135]	Torque % nom 4-20 mA
[136]	Power 4-20 mA
[137]	Speed 4-20 mA
[138]	Torque 4-20 mA
[139]	Bus ctrl. 0-20 mA
[140]	Bus ctrl. 4-20 mA
[141]	Bus ctrl. 0-20 mA, time-out
[142]	Bus ctrl. 4-20 mA, time-out
[150]	Max Out Freq 4-20 mA

### 6-51 Terminal 42 Output Min Scale

See the drawing below for details.

0%* [0 – 200%]	Scale the minimum output of the selected analog signal at terminal 42, as a percentage of the maximum signal value. E.g. if 0 mA (or 0 Hz) is desired at 25% of the maximum output value, then programme 25%. Scaling values up to 100% can never be higher than the corresponding setting in par. 6-52.
----------------	--

### 6-52 Terminal 42 Output Max Scale

**Range:**


100 %\* [000 – 200%]

**Function:**

Scale the maximum output of the selected analog signal at terminal 42. Set the value to the maximum value of the current signal output. Scale the output to give a current lower than 20 mA at full scale; or 20 mA at an output below 100% of the maximum signal value. If 20 mA is the desired output current at a value between 0 - 100% of the full-scale output, programme the percentage value in the parameter, i.e. 50% = 20 mA. If a current between 4 and 20 mA is desired at maximum output (100%), calculate the percentage value as follows:

$$20 \text{ mA} / \text{desired maximum current} \times 100 \%$$

$$\text{i.e. } 10 \text{ mA} : \frac{20}{10} \times 100 = 200 \%$$



**6-53 Terminal 42 Output Bus Control**

**Range:** 0.00%\* [0.00 – 100.00 %]      **Function:** Holds the level of Output 42 if controlled by bus.

**6-54 Terminal 42 Output Timeout Preset**

**Range:** 0.00%\* [0.00 – 100.00 %]      **Function:** Holds the preset level of Output 42.  
In case of a bus timeout and a timeout function is selected in par. 6-50 the output will preset to this level.

**2.9.8. 6-6\* Analog Output 2 (MCB 101)**

Analog outputs are current outputs: 0/4 - 20 mA. Common terminal (terminal X30/8) is the same terminal and electrical potential for analog common connection. Resolution on analog output is 12 bit.

**6-60 Terminal X30/8 Output**

Option:	Function:
[0]	No operation
[100]	Output frequency (0 . 1000 Hz), 0.20 mA
[101]	Output frequency (0 . 1000 Hz), 4.20 mA Reference (Refmin-max),0.20 mA
[102]	Reference (Ref min-max), 4.20 mA Feedback (FB min-max)0.20 mA
[103]	Feedback (FB min-max) 4.20 mA Motor current (0-Imax) 0.20 mA
[104]	Motor current (0-Imax) 4.20 mA Torque relative to limit0-Tlim,0.20 mA
[105]	Torque relative to limit 0-Tlim, 4.20 mA Torque relativetorated0-Tnom,0.20 mA
[106]	Torque relative to rated 0-Tnom, 4.20 mA Power (0-Pnom),0.20 mA

[107]	Power (0-Pnom), 4.20 mA Speed (0-Speedmax), 0.20 mA
[108]	Speed (0-Speedmax), 4.20 mA Torque (+/-160% torque), 0-20 mA
[130]	Torque (+/-160% torque), 4-20 mA Output freq. 4-20 mA
[131]	Reference 4-20 mA
[132]	Feedback 4-20 mA
[133]	Motor cur. 4-20 mA
[134]	Torque % lim. 4-20 mA
[135]	Torque % nom 4-20 mA
[136]	Power 4-20 mA
[137]	Speed 4-20 mA
[138]	Torque 4-20 mA
[139]	Bus Ctrl 0-20 mA
[140]	Bus Ctrl 4-20 mA
[141]	Bus Ctrl 0-20 mA, Timeout
[142]	Bus Ctrl 4-20 mA, Timeout
[150]	Max Out Freq 4-20 mA

### 6-61 Term. X30/8 Output Min Scale

**Range:**

0%\* [0.00 - 200 %]

**Function:**

Scales the minimum output of the selected analog signal on terminal X30/8. Scale the minimum value as a percentage of the maximum signal value, i.e. 0 mA (or 0 Hz) is desired at 25% of the maximum output value and 25% is programmed. The value can never be higher than the corresponding setting in par. 6-62 if value is below 100%.

This parameter is active when option module MCB 101 is mounted in the frequency converter.

### 6-62 Term. X30/8 Output Max Scale

**Range:**

100%\* [0.00 - 200 %]

**Function:**

Scales the maximum output of the selected analog signal on terminal X30/8. Scale the value to the desired maximum value of the current signal output. Scale the output to give a lower current than 20 mA at full scale or 20 mA at an output below 100% of the maximum signal value. If 20 mA is the desired output current at a value between 0 - 100% of the full-scale output, program the percentage value in the parameter, i.e. 50% = 20 mA. If a current between 4 and 20 mA is desired at maximum output (100%), calculate the percentage value as follows:

$20 \text{ mA} / \text{desired maximum current} \times 100 \%$

i.e.  $10 \text{ mA} : \frac{20}{10} \times 100 = 200 \%$

## 2.10. Parameters: Controllers

### 2.10.1. 7-\*\*\* Controllers

Parameter group for configuring application controls.

### 2.10.2. 7-0\* Speed PID Ctrl.

Parameters for configuring the speed PID control.

#### 7-00 Speed PID Feedback Source

**Option:**

**Function:**

Select the encoder for closed loop feedback.

The feedback may come from a different encoder (typically mounted on the application itself) than the motor mounted encoder feedback selected in par. 1-02.

This parameter cannot be adjusted while the motor is running.

- [0] Motor feedb. p.1-02  
(FC 302 only)
- [1] 24V encoder
- [2] MCB 102
- [3] MCB 103
- [4] MCO encoder 1
- [5] MCO encoder 2



**NB!**

If separate encoders are used (FC 302 only) the ramp settings parameters in the following groups: 3-4\*, 3-5\*, 3-6\*, 3-7\* and 3-8\* must be adjusted according to the gear ratio between the two encoders.

#### 7-02 ProportionalGain

**Range:**

Size related [0.000 - 1.000]

**Function:**

Enter the speed controller proportional gain. The proportional gain amplifies the error (i.e. the deviation between the feedback signal and the set-point). This parameter is used with par. 1-00 *Speed open loop* [0] and *Speed closed loop* [1] control. Quick control is obtained at high amplification. However if the amplification is too great, the process may become unstable.

#### 7-03 Speed PID Integral Time

**Range:**

8.0 ms\* [2.0 - 20000.0 ms]

**Function:**

Enter the speed controller integral time, which determines the time the internal PID control takes to correct errors. The greater the error, the more quickly the gain increases. The integral time causes a delay of the signal and therefore a dampening effect, and can be used to eliminate steady state speed error. Obtain quick control through a short integral time, though if the integral time is too short, the process becomes unstable. An excessively long integral time disables the integral action, leading to major deviations from the required reference, since the process regulator takes too long to regulate errors. This parameter is used with *Speed open loop* [0] and *Speed closed loop* [1] control, set in par. 1-00 *Configuration Mode*.

#### 7-04 Speed PID Differentiation Time

**Range:**

30.0 ms [0.0 - 200.0 ms]

**Function:**

Enter the speed controller differentiation time. The differentiator does not react to constant error. It provides gain proportional to the rate of change of the speed feedback. The quicker the error changes, the stronger the gain from the differentiator. The gain is proportional with the speed at which errors change. Setting this parameter to zero disables the differentiator. This parameter is used with par. 1-00 *Speed closed loop* [1] control.

**7-05 Speed PID Diff Gain Limit**

**Range:**

5.000\* [1.0 - 20.0]

**Function:**

Set a limit for the gain provided by the differentiator. Since the differential gain increases at higher frequencies, limiting the gain may be useful. For example, set up a pure D-link at low frequencies and a constant D-link at higher frequencies. This parameter is used with par. 1-00 *Speed closed loop* [1] control.

**7-06 Speed PID Lowpass Filter Time**

**Range:**

10.0 ms\* [1.0 - 100.0 ms]

**Function:**

Set a time constant for the speed control low-pass filter. The low-pass filter improves steady-state performance and dampens oscillations on the feedback signal. This is an advantage if there is a great amount on noise in the system, see illustration below. For example, if a time constant ( $\tau$ ) of 100 ms is programmed, the cut-off frequency for the low-pass filter will be  $1/0.1 = 10 \text{ RAD/sec.}$ , corresponding to  $(10/2 \times \pi) = 1.6 \text{ Hz.}$  The PID regulator only regulates a feedback signal that varies by a frequency of less than 1.6 Hz. If the feedback signal varies by a higher frequency than 1.6 Hz, the PID regulator does not react.


Practical settings of Par. 7-06 taken from the number of pulses per revolutions from encoder:

Encoder PPR	Par. 7-06
512	10 ms
1024	5 ms
2048	2 ms
4096	1 ms

Note that severe filtering can be detrimental to dynamic performance.

This parameter is used with par. 1-00 *Speed closed loop* [1] and *Torque* [2] control.

The filter time in flux sensorless must be adjusted to 3-5 ms.



**7-08 Speed PID Feed Forward Factor**

**Range:**

0%\* [0 - 500%]

**Function:**

The reference signal bypasses the speed controller by the amount specified. This feature increases the dynamic performance of the speed control loop.

**2.10.3. 7-2\* Process Ctrl. Feedb.**

Select the feedback sources for the Process PID Control, and how this feedback should be handled.

**7-20 Process CL Feedback 1 Source**

**Option:**

**Function:**

The effective feedback signal is made up of the sum of up to two different input signals.

Select which frequency converter input should be treated as the source of the first of these signals. The second input signal is defined in par. 7-22.

[0] *	No function
[1]	Analog input 53
[2]	Analog input 54
[3]	Frequency input 29 (FC 302 only)
[4]	Frequency input 33
[5]	Bus feedback 1
[6]	Bus feedback 2
[7]	Analog input X30/11
[8]	Analog input X30/12

**7-22 Process CL Feedback 2 Source**

**Option:**

**Function:**

The effective feedback signal is made up of the sum of up to two different input signals. Select which frequency converter input should be treated as the source of the second of these signals. The first input signal is defined in par. 7-21.

[0] *	No function
[1]	Analog input 53
[2]	Analog input 54
[3]	Frequency input 29 (FC 302 only)
[4]	Frequency input 33
[5]	Bus feedback 1
[6]	Bus feedback 2
[7]	Analog input X30/11
[8]	Analog input X30/12

**2.10.4. 7-3\* Process PID Ctrl.**

Parameters for configuring the Process PID control.

**7-30 Process PID Normal/ Inverse Control**

**Option:**

**Function:**

Normal and inverse control are implemented by introducing a difference between the reference signal and the feedback signal.

[0] *	Normal	Sets process control to increase the output frequency.
[1]	Inverse	Sets process control to reduce the output frequency.

**7-31 Process PID Anti Windup**

**Option:**

**Function:**

[0] *	Off	Ceases regulation of an error when the output frequency can no longer be adjusted.
[1]	On	Continues regulation of an error even when the output frequency cannot be increased or decreased.

**7-32 Process PID Start Speed**

**Range:**

**Function:**

0 RPM\* [0 - 6000 RPM]

Enter the motor speed to be attained as a start signal for commencement of PID control. When the power is switched on, the frequency converter will commence ramping and then operate under speed open loop control. Thereafter, when the Process PID start speed is reached, the frequency converter will change over to Process PID control.

**7-33 Process PID Proportional Gain****Range:**

0.01 N/A\* [0.00 - 10.00 N/A]

**Function:**

Enter the PID proportional gain. The proportional gain multiplies the error between the set point and the feedback signal.

**7-34 Process PID Integral Time****Range:**

10000.00 s\* [0.01 - 10000.00]

**Function:**

Enter the PID integral time. The integrator provides an increasing gain at a constant error between the set point and the feedback signal. The integral time is the time needed by the integrator to reach the same gain as the proportional gain.

**7-35 Process PID Differentiation Time****Range:**

0.00 s\* [0.00 - 10.00 s]

**Function:**

Enter the PID differentiation time. The differentiator does not react to a constant error, but provides a gain only when the error changes. The shorter the PID differentiation time, the stronger the gain from the differentiator.

**7-36 Process PID Diff. Gain Limit****Range:**

5.0 N/A\* [1.0 - 50.0 N/A]

**Function:**

Enter a limit for the differentiator gain (DG). If there is no limit, the DG will increase when there are fast changes. Limit the DG to obtain a pure differentiator gain at slow changes and a constant differentiator gain where fast changes occur.

**7-38 Process PID Feed Forward Factor****Range:**

0%\* [0 - 500%]

**Function:**

Enter the PID feed forward (FF) factor. The FF factor sends a constant fraction of the reference signal to bypass the PID control, so the PID control only affects the remaining fraction of the control signal. Any change to this parameter will thus affect the motor speed. When the FF factor is activated it provides less overshoot, and high dynamics when changing the set point. Par. 7-38 is active when par. 1-00 *Configuration Mode* is set to [3] Process.

**7-39 On Reference Bandwidth****Range:**

5%\* [0 - 200%]

**Function:**

Enter the On Reference bandwidth. When the PID Control Error (the difference between the reference and the feedback) is less than the set value of this parameter the On Reference status bit is high, i.e. =1.



## 2.11. Parameters: Communications and Options

### 2.11.1. 8-\*\* Comm. and Options

Parameter group for configuring communications and options.

### 2.11.2. 8-0\* General Settings

General settings for communications and options.

#### 8-01 Control Site

The setting in this parameter overrides the settings in par. 8-50 to 8-56.

[0] *	Digital and ctrl. word	Control by using both digital input and control word.
[1]	Digital only	Control by using digital inputs only.
[2]	Control word only	Control by using control word only.

#### 8-02 Control Word Source

##### Option:

##### Function:

[0] None

[1] FC RS485

[2] FC USB

[3] Option A

[4] Option B

[5] Option C0

[6] Option C1

[30] External Can  
 Select the source of the control word: one of two serial interfaces or four installed options. During initial power-up, the frequency converter automatically sets this parameter to *Option A* [3] if it detects a valid fieldbus option installed in slot A. If the option is removed, the frequency converter detects a change in the configuration, sets par. 8-02 back to default setting *FC RS485*, and the frequency converter then trips. If an option is installed after initial power-up, the setting of par. 8-02 will not change but the frequency converter will trip and display: Alarm 67 *Option Changed*.  
 This parameter cannot be adjusted while the motor is running.

#### 8-03 Control Word Timeout Time

##### Range:

1.0s\* [0.1 - 18000.0 s]

##### Function:

Enter the maximum time expected to pass between the reception of two consecutive telegrams. If this time is exceeded, it indicates that the serial communication has stopped. The function selected in par. 8-04 *Control Word Time-out Function* will then be carried out. The time-out counter is triggered by a valid control word.

#### 8-04 Control Word Timeout Function

##### Option:

##### Function:

[0] \* Off

[1] Freeze Output

[2] Stop

[3] Jogging

[4] Max. Speed

[5] Stop and trip

[7] Select set-up 1

[8] Select set-up 2

[9] Select set-up 3

[10]	Select set-up 4	Select the time-out function. The time-out function activates when the control word fails to be updated within the time period specified in par. 8-03 <i>Control Word Time-out Time</i> . <ul style="list-style-type: none"> <li>- <i>Off</i> [0]: Resume control via serial bus (Fieldbus or standard) using the most recent control word.</li> <li>- <i>Freeze output</i> [1]: Freeze output frequency until communication resumes.</li> <li>- <i>Stop</i> [2]: Stop with auto restart when communication resumes.</li> <li>- <i>Jogging</i> [3]: Run the motor at JOG frequency until communication resumes.</li> <li>- <i>Max. freq.</i> [4]: Run the motor at maximum frequency until communication resumes.</li> <li>- <i>Stop and trip</i> [5]: Stop the motor, then reset the frequency converter in order to restart: via the fieldbus, via the reset button on the LCP or via a digital input.</li> <li>- <i>Select set-up 1-4</i> [7] - [10]: This option changes the set-up upon reestablishment of communication following a control word time-out. If communication resumes causing the time-out situation to disappear, par. 8-05 <i>End-of-time-out Function</i> defines whether to resume the set-up used before the time-out or to retain the set-up endorsed by the time-out function. Note the following configuration required in order to change the set-up after a time-out: Set Par. 0-10 <i>Active set-up to Multi set-up</i> [9], and select the relevant link in par. 0-12 <i>This Set-up Linked To</i>.</li> </ul>
------	-----------------	--

### 8-05 End-of-Timeout Function

Select the action after receiving a valid control word following a time-out. This parameter is active only when par. 8-04 is set to [Set-up 1-4].

[0]	Hold set-up	Retains the set-up selected in par. 8-04 and displays a warning, until par. 8-06 toggles. Then the frequency converter resumes its original set-up.
[1] *	Resume set-up	Resumes the set-up active prior to the time-out.

### 8-06 Reset Control Word Timeout

#### Option:

[0] \* Do not reset

#### Function:

[1] Do reset

Select *Do reset* [1] to return the frequency converter to the original set-up following a control word time-out. When the value is set to *Do reset* [1], the frequency converter performs the reset and then immediately reverts to the *Do not reset* [0] setting.

Select *Do not reset* [0] to retain the set-up specified in par. 8-04, *Select setup 1-4* following a control word time-out.

This parameter is active only when *Hold set-up* [0] has been selected in par. 8-05 *End-of-Time-out Function*.

### 8-07 Diagnosis Trigger

#### Option:

[0] \* Disable

#### Function:

[1] Trigger on alarms

[2] Trigger alarms/warn. This parameter enables and controls the frequency converter diagnosis function and permits expansion of the diagnosis data to 24 byte.



#### NB!

It relates only to Profibus.

- *Disable* [0]: Do not send extended diagnosis data even if they appear in the frequency converter.
- *Trigger on alarms* [1]: Send extended diagnosis data when one or more alarms appear in alarm par. 16-90 or 9-53.
- *Trigger alarms/warn.* [2]: Send extended diagnosis data if one or more alarms or warnings appear in alarm par. 16-90, 9-53, or warning par. 16-92.

The content of the extended diagnosis frame is as follows:

Byte	Content	Description
0 - 5	Standard DP Diagnose Data	Standard DP Diagnose Data
6	PDU length xx	Header of extended diagnostic data
7	Status type = 0x81	Header of extended diagnostic data
8	Slot = 0	Header of extended diagnostic data
9	Status info = 0	Header of extended diagnostic data
10 - 13	VLT par. 16-92	VLT warning word
14 - 17	VLT par. 16-03	VLT status word
18 - 21	VLT par. 16-90	VLT alarm word
22 - 23	VLT par. 9-53	Communication warning word (Profibus)

Enabling diagnosis may cause increased bus traffic. Diagnosis functions are not supported by all fieldbus types.

### 2.11.3. 8-1\* Ctrl. Word Settings

Parameters for configuring the option control word profile.

#### 8-10 Control Word Profile

**Option:**

**Function:**

[0] \* FC profile

[1] PROFIdrive profile

[5] ODVA

[7] CANopen DSP 402 Select the interpretation of the control and status words corresponding to the installed fieldbus. Only the selections valid for the fieldbus installed in slot A will be visible in the LCP display.  
For guidelines in selection of *FC profile* [0] and *PROFIdrive profile* [1] please refer to the *Serial communication via RS 485 Interface* section.  
For additional guidelines in the selection of *PROFIdrive profile* [1], *ODVA* [5] and *CANopen DSP 402* [7], please refer to the Operating Instructions for the installed fieldbus.

#### 8-13 Configurable Status Word STW

**Option:**

**Function:**

This parameter enables configuration of bit 12 – 15 in the status word.

[0] No function

[1] \* Profile default Function corresponds to the profile default selected in par. 8-10.

[2] Alarm 68 only Only set in case of an Alarm 68.

[3] Trip except Alarm 68 Set in case of a trip, except if the trip is executed by an Alarm 68.

[16] T37 DI status The bit indicates the status of terminal 37.  
"0" indicates T37 is low (safe stop)  
"1" indicates T37 is high (normal)

### 2.11.4. 8-3\* FC Port Settings

Parameters for configuring the FC Port.

#### 8-30 Protocol

**Option:**

**Function:**

[0] \* FC

[1] FC MC Select the protocol for the FC (standard) port.

#### 8-31 Address

**Range:**

**Function:**

1\* [1 - 126 ]

Enter the address for the FC (standard) port.  
Valid range: 1 - 126.

**8-32 FC Port Baud Rate**

Option:	Function:
[0]	2400 Baud
[1]	4800 Baud
[2] *	9600 Baud
[3]	19200 Baud
[4]	38400 Baud
[7]	115200 Baud      Baud rate selection for the FC (standard) port.

**8-35 Minimum Response Delay**

Range:	Function:
10ms* [1 - 500 ms]	Specify the minimum delay time between receiving a request and transmitting a response. This is used for overcoming modem turnaround delays.

**8-36 Max Response Delay**

Range:	Function:
5000ms* [1 - 10000 ms]	Specify the maximum permissible delay time between transmitting a request and receiving a response. Exceeding this delay time will cause control word time-out.

**8-37 Max Inter-Char Delay**

Range:	Function:
25ms* [0 - 30 ms]	Specify the maximum permissible time interval between receipt of two bytes. This parameter activates time-out if transmission is interrupted. This parameter is active only when par. 8-30 is set to <i>FC MC</i> [1] protocol.

**8-40 FC MC Protocol Set**

Option:	Function:
[1] *	Standard Telegram 1
[200]	Custom Telegram      Enables use of freely configurable telegrams or standard telegrams for the FC port.

**2.11.5. 8-5\* Digital/Bus**

Parameters for configuring the control word Digital/Bus merging.

**8-50 Coasting Select**

Select control of the coasting function via the terminals (digital input) and/or via the bus.

[0]	Digital input
[1]	Bus
[2]	Logic AND
[3] *	Logic OR

**NB!**

This parameter is active only when *par. 8-01 Control Site* is set to [0] *Digital and control word*.

**8-51 Quick Stop Select**

Option:	Function:
[0]	Digital input
[1]	Bus
[2]	Logic AND

[3] \* Logic OR Select control of the Quick Stop function via the terminals (digital input) and/or via the bus.



**NB!**

This parameter is active only when par. 8-01 *Control Site* is set to [0] *Digital and control word*.

**8-52 DC Brake Select**

Select control of the DC brake via the terminals (digital input) and/or via the fieldbus.

[0] Digital input

[1] Bus

[2] Logic AND

[3] \* Logic OR



**NB!**

This parameter is active only when par. 8-01 *Control Site* is set to [0] *Digital and control word*.

**8-53 Start Select**

Select control of the frequency converter start function via the terminals (digital input) and/or via the fieldbus.

[0] Digital input

[1] Bus Activates Start command via the serial communication port or fieldbus option.

[2] Logic AND Activates Start command via the fieldbus/serial communication port, AND additionally via one of the digital inputs.

[3] \* Logic OR Activates Start command via the fieldbus/serial communication port OR via one of the digital inputs.



**NB!**

This parameter is active only when par. 8-01 *Control Site* is set to [0] *Digital and control word*.

**8-54 Reversing Select**

**Option:**

**Function:**

[0] Digital input

[1] Bus

[2] Logic AND

[3] \* Logic OR

Select control of the frequency converter reverse function via the terminals (digital input) and/or via the fieldbus. Select *Bus* [1], to activate the Reverse command via the serial communication port or fieldbus option. Select *Logic AND* [2] to activate the Reverse command via the fieldbus/serial communication port, AND additionally via one of the digital inputs. Select *Logic OR* [3] to activate the Reverse command via the fieldbus/serial communication port OR via one of the digital inputs.



**NB!**

This parameter is active only when par. 8-01 *Control Site* is set to [0] *Digital and control word*.

**8-55 Set-up Select**

Select control of the frequency converter set-up selection via the terminals (digital input) and/or via the fieldbus.

[0]	Digital input	
[1]	Bus	Activates the set-up selection via the serial communication port or fieldbus option.
[2]	Logic AND	Activates the set-up selection via the fieldbus/serial communication port, AND additionally via one of the digital inputs.
[3] *	Logic OR	Activate the set-up selection via the fieldbus/serial communication port OR via one of the digital inputs.

**NB!**

This parameter is active only when *par. 8-01 Control Site* is set to [0] *Digital and control word*.

**8-56 Preset Reference Select**

Select control of the frequency converter Preset Reference selection via the terminals (digital input) and/or via the fieldbus.

[0]	Digital input	
[1]	Bus	Activates Preset Reference selection via the serial communication port or fieldbus option.
[2]	Logic AND	Activates Preset Reference selection via the fieldbus/serial communication port, AND additionally via one of the digital inputs.
[3] *	Logic OR	Activates the Preset Reference selection via the fieldbus/serial communication port OR via one of the digital inputs.

**NB!**

This parameter is active only when *par. 8-01 Control Site* is set to [0] *Digital and control word*.

**2.11.6. 8-9\* Bus Jog**

Parameters for configuring the Bus Jog.

**8-90 Bus Jog 1 Speed**

<b>Range:</b>	<b>Function:</b>
100 RPM* [0 - par. 4-13 RPM]	Enter the jog speed. This is a fixed jog speed activated via the serial port or fieldbus option.

**8-91 Bus Jog 2 Speed**

<b>Range:</b>	<b>Function:</b>
200 RPM* [0 - par. 4-13 RPM]	Enter the jog speed. This is a fixed jog speed activated via the serial port or fieldbus option.

**2.12. Parameters: Profibus****2.12.1. 9-\*\* Profibus**

Parameter group for all Profibus-specific parameters.

**9-00 Setpoint**

<b>Range:</b>	<b>Function:</b>
0* [0-65535]	This parameter receives cyclical reference from a Master Class 2. If the control priority is set to Master Class 2, the reference for the frequency converter is taken from this parameter, whereas the cyclical reference will be ignored.

**9-07 Actual Value**

**Range:**

0\* [0-65535]

**Function:**

This parameter delivers the MAV for a Master Class 2. The parameter is valid if the control priority is set to Master Class 2.

**9-15 PCD Write Configuration**

Array [10]

None

3-02 Minimum Reference

3-03 Maximum Reference

3-12 Catch Up/Slow Down Value

3-41 Ramp 1 Ramp Up Time

3-42 Ramp 1 Ramp Down Time

3-51 Ramp 2 Ramp Up Time

3-52 Ramp 2 Ramp Down Time

3-80 Jog Ramp Time

3-81 Quick Stop Ramp Time

4-11 Motor Speed Low Limit [RPM]

4-13 Motor Speed High Limit [RPM]

4-16 Torque Limit Motor Mode

4-17 Torque Limit Generator Mode

7-28 Minimum Feedback

7-29 Maximum Feedback

8-90 Bus Jog 1 Speed

8-91 Bus Jog 2 Speed

16-80 Fieldbus CTW 1

16-82 Fieldbus REF 1

34-01 PCD 1 Write to MCO

34-02 PCD 2 Write to MCO

34-03 PCD 3 Write to MCO

34-04 PCD 4 Write to MCO

34-05 PCD 5 Write to MCO

34-06 PCD 6 Write to MCO

34-07 PCD 7 Write to MCO

34-08 PCD 8 Write to MCO

34-09 PCD 9 Write to MCO

34-10 PCD 10 Write to MCO Select the parameters to be assigned to PCD 3 to 10 of the telegrams. The number of available PCDs depends on the telegram type. The values in PCD 3 to 10 will then be written to the selected parameters as data values. Alternatively, specify a standard Profibus telegram in par. 9-22.

**9-16 PCD Read Configuration**

Array [10]

None

16-00 Control Word

16-01 Reference [Unit]

16-02 Reference %

16-03 Status Word

16-04 Main Actual Value [Unit]

16-05 Main Actual Value [%]

16-09 Custom Readout

16-10 Power [kW]

16-11 Power [hp]

16-12 Motor Voltage

16-13 Frequency

16-14 Motor Current

16-16 Torque

16-17 Speed [RPM]

16-18 Motor Thermal

16-19 KTY Sensor Temperature

16-21 Phase Angle

16-30 DC Link Voltage

16-32 Brake Energy / s

16-33 Brake Energy / 2 min 16-34 Heatsink Temp.

16-35 Inverter Thermal

16-38 SL Control State

16-39 Control Card Temp.

16-50 External Reference

16-51 Pulse Reference



16-52 Feedback [Unit]

16-53 Digi Pot Reference

16-60 Digital Input

16-61 Terminal 53  
Switch Setting

16-62 Analog Input 53

16-63 Terminal 54  
Switch Setting

16-64 Analog Input 54

16-65 Analog Output  
42 [mA]

16-66 Digital Output  
[bin]

16-67 Freq. Input 29  
[Hz]

16-68 Freq. Input 33  
[Hz]

16-69 Pulse Output 27  
[Hz]

16-70 Pulse Output 29  
[Hz]

16-71 Pulse Output  
[bin]

16-84 Comm Option  
STW [Binary]

16-85 FC port CTW 1  
Signal

16-90 Alarm Word

16-91 Alarm Word 2

16-92 Warning Word

16-93 Warning Word 2

16-94 Extended Status  
Word

16-95 Extended Status  
Word 2

34-21 PCD 1 Read from  
MCO

34-22 PCD 2 Read from  
MCO

34-23 PCD 3 Read from  
MCO

34-24 PCD 4 Read from  
MCO

34-25 PCD 5 Read from  
MCO

34-26 PCD 6 Read from  
MCO

34-27 PCD 7 Read from  
MCO

34-28 PCD 8 Read from MCO

34-29 PCD 9 Read from MCO

34-30 PCD 10 Read from MCO

34-40 Digital Inputs

34-41 Digital Outputs

34-50 Actual Position

34-51 Commanded Position

34-52 Actual Master Position

34-53 Slave Index Position

34-54 Master Index Position

34-55 Curve Position

34-56 Track Error

34-57 Synchronizing Error

34-58 Actual Velocity

34-59 Actual Master Velocity

34-60 Synchronizing Status

34-61 Axis Status

34-62 Program Status Select the parameters to be assigned to PCD 3 to 10 of the telegrams. The number of available PCDs depends on the telegram type. PCDs 3 to 10 contain the actual data values of the selected parameters. For standard Profibus telegrams, see par. 9-22.

### 9-18 Node Address

**Range:**

126\* [0 - 126]

**Function:**

Enter the station address in this parameter or alternatively in the hardware switch. In order to adjust the station address in par. 9-18, the hardware switch must be set to 126 or 127 (i.e. all switches set to 'on'). Otherwise this parameter will display the actual setting of the switch.

### 9-22 Telegram Selection

**Option:**

[1] Standard telegram 1

[101] PPO 1

[102] PPO 2

[103] PPO 3

[104] PPO 4

[105] PPO 5

[106] PPO 6

[107] PPO 7

[108] \* PPO 8

**Function:**

Read only.  
Displays the Profibus telegram configuration.

### 9-23 Parameters for Signals

Array [1000]  
Read only

This parameter contains a list of signals available for selection in par. 9-15 and 9-16.

### 9-27 Parameter Edit

**Option:**

**Function:**

Parameters can be edited via Profibus, the standard RS485 interface, or the LCP.

[0]	Disabled	Disables editing via Profibus.
[1] *	Enabled	Enables editing via Profibus.

### 9-28 Process Control

**Option:**

**Function:**

Process control (setting of Control Word, speed reference, and process data) is possible via either Profibus or standard fieldbus but not both simultaneously. Local control is always possible via the LCP. Control via process control is possible via either terminals or fieldbus depending on the settings in par. 8-50 to 8-56.

[0]	Disable	Disables process control via Profibus, and enables process control via standard fieldbus or Profibus Master class 2.
[1] *	Enable cyclic master	Enables process control via Profibus Master Class 1, and disables process control via standard fieldbus or Profibus Master class 2.

### 9-44 Fault Message Counter

**Range:**

**Function:**

0\* [0-65535]

This parameter displays the number of error events stored in par. 9-45 and 9-47. The maximum buffer capacity is eight error events. The buffer and counter are set to 0 upon reset or power-up.

### 9-45 Fault Code

**Range:**

**Function:**

0\* [0 - 0]

This buffer contains the alarm word for all alarms and warnings that have occurred since last reset or power-up. The maximum buffer capacity is eight error events.

### 9-47 Fault Number

**Range:**

**Function:**

0\* [0 - 0]

This buffer contains the alarm number (e.g. 2 for live zero error, 4 for mains phase loss) for all alarms and warnings that have occurred since last reset or power-up. The maximum buffer capacity is eight error events.

### 9-52 Fault Situation Counter

**Range:**

**Function:**

0\* [0 - 1000]

This parameter displays the number of error events which have occurred since last reset of power-up.

### 9-53 Profibus Warning Word

This parameter displays Profibus communication warnings. Please refer to the *Profibus Operating Instructions* for further information.

Read only

Bit:	Meaning:
0	Connection with DP-master is not ok
1	Not used
2	FDL (Field-bus Data link Layer) is not ok
3	Clear data command received
4	Actual value is not updated
5	Baudrate search
6	PROFIBUS ASIC is not transmitting
7	Initializing of PROFIBUS is not ok
8	Frequency converter is tripped
9	Internal CAN error
10	Wrong configuration data from PLC
11	Wrong ID sent by PLC
12	Internal error occurred
13	Not configured
14	Timeout active
15	Warning 34 active

### 9-63 Actual Baud Rate

**Option:**
**Function:**

This parameter displays the actual Profibus baud rate. The Profibus Master automatically sets the baud rate.

Read only

[0]	9.6 kbit/s
[1]	19.2 kbit/s
[2]	93.75 kbit/s
[3]	187.5 kbit/s
[4]	500 kbit/s
[6]	1500 kbit/s
[7]	3000 kbit/s
[8]	6000 kbit/s
[9]	12000 kbit/s
[10]	31.25 kbit/s
[11]	45.45 kbit/s
[255]	No baud rate found

### 9-64 Device Identification

**Range:**

0\* [0 - 0]

**Function:**

This parameter displays the device identification. Please refer to the *Operating Instructions for Profibus, MG33CXYY* for further explanation.

**9-65 Profile Number**

**Range:** **Function:**

Read only

0\* [0 - 0] This parameter contains the profile identification. Byte 1 contains the profile number and byte 2 the version number of the profile.



**NB!**

This parameter is not visible via LCP.

**9-67 Control Word 1**

**Range:** **Function:**

0\* [0-65535] This parameter accepts the Control Word from a Master Class 2 in the same format as PCD 1.

**9-68 Status Word 1**

**Range:** **Function:**

0\* [0-65535] This parameter delivers the Status Word for a Master Class 2 in the same format as PCD 2.

**9-70 Edit Set-up**

**Option:** **Function:**

Select the set-up to be edited.

[0]	Factory setup	Uses default data. This option can be used as a data source to return the other set-ups to a known state.
[1] *	Setup 1	Edits Set-up 1.
[2]	Setup 2	Edits Set-up 2.
[3]	Setup 3	Edits Set-up 3.
[4]	Setup 4	Edits Set-up 4.
[9]	Active setup	Follows the active set-up selected in par. 0-10.

This parameter is unique to LCP and fieldbuses. See also par. 0-11 *Edit set-up*.

**9-71 Save Data Values**

**Option:** **Function:**

Parameter values changed via Profibus are not automatically stored in non-volatile memory. Use this parameter to activate a function that stores parameter values in the EEPROM non-volatile memory, so changed parameter values will be retained at power-down.

[0] *	Off	Deactivates the non-volatile storage function.
[1]	Store edit setup	Stores all parameter values in the set-up selected in par. 9-70 in the non-volatile memory. The selection returns to Off [0] when all values have been stored.
[2]	Store all set-ups	Stores all parameter values for all set-ups in the non-volatile memory. The selection returns to Off [0] when all parameter values have been stored.

**9-72 Drive Reset**

**Option:** **Function:**

[0] *	No action	
[1]	Power-on reset	Resets frequency converter upon power-up, as for power-cycle.
[3]	Comm. option reset	Resets the Profibus option only, useful after changing certain settings in parameter group 9-**, e.g. par. 9-18. When reset, the frequency converter disappears from the fieldbus, which may cause a communication error from the master.

**9-80 Defined Parameters (1)**

Array [116]

No LCP access

Read only

0\* [0 - 115] This parameter displays a list of all the defined frequency converter parameters available for Profibus.

**9-81 Defined Parameters (2)**

Array [116]

No LCP access

Read only

0\* [0 - 115] This parameter displays a list of all the defined frequency converter parameters available for Profibus.

**9-82 Defined Parameters (3)**

Array [116]

No LCP access

Read only

0\* [0 - 115] This parameter displays a list of all the defined frequency converter parameters available for Profibus.

**9-83 Defined Parameters (4)**

Array [116]

No LCP access

Read only

0\* [0 - 115] This parameter displays a list of all the defined frequency converter parameters available for Profibus.

**9-84 Defined Parameters (5)**

**Range:** **Function:**

Array [116]

No LCP access

Read only

0\* [0 - 115] This parameter displays a list of all the defined frequency converter parameters available for Profibus.

**9-90 Changed Parameters (1)**

This parameter displays a list of all the frequency converter parameters deviating from default setting.

Array [116]

No LCP access

Read only

0\* [0 - 115]

### 9-91 Changed Parameters (2)

This parameter displays a list of all the frequency converter parameters deviating from default setting.

Array [116]

No LCP access

Read only

0\* [0 - 115]

### 9-92 Changed Parameters (3)

This parameter displays a list of all the frequency converter parameters deviating from default setting.

Array [116]

No LCP access

Read only

0\* [0 - 115]

### 9-94 Changed Parameters (5)

This parameter displays a list of all the frequency converter parameters deviating from default setting.

Array [116]

No LCP access

Read only

0\* [0 - 115]

## 2.13. Parameters: DeviceNet CAN Fieldbus

### 2.13.1. 10-\*\* DeviceNet and CAN Fieldbus

Parameter group for DeviceNet CAN fieldbus parameters.

### 2.13.2. 10-0\* Common Settings

Parameter group for configuring common settings for CAN fieldbus options.

#### 10-00 CAN Protocol

Option:	Function:
[0]	CANopen
[1] *	DeviceNet View the active CAN protocol.

**NB!**

The options depend on installed option.

**10-01 Baud Rate Select****Option:****Function:**

[16] 10 Kbps

[17] 20 Kbps

[18] 50 Kbps

[19] 100 Kbps

[20] \* 125 Kbps

[21] 250 Kbps

[22] 500 Kbps

Select the fieldbus transmission speed. The selection must correspond to the transmission speed of the master and the other fieldbus nodes.

**10-02 MAC ID****Range:****Function:**

63\* [0 - 127]

Selection of station address. Every station connected to the same network must have an unambiguous address.

**10-05 Readout Transmit Error Counter****Range:****Function:**

0\* [0 - 255]

View the number of CAN control transmission errors since the last power-up.

**10-06 Readout Receive Error Counter****Option:****Function:**

[0] 0 - 255

View the number of CAN control receipt errors since the last power-up.

**10-07 Readout Bus Off Counter****Range:****Function:**

0\* [0 - 255]

View the number of Bus Off events since the last power-up.

**2.13.3. 10-1\* DeviceNet**

Parameters specific to the DeviceNet fieldbus.

**10-10 Process Data Type Selection****Option:****Function:**Select the Instance (telegram) for data transmission. The Instances available are dependent upon the setting of par. 8-10 *Control Word Profile*.When par. 8-10 is set to [0] *FC profile*, par. 10-10 options [0] and [1] are available.When par. 8-10 is set to [5] *ODVA*, par. 10-10 options [2] and [3] are available.

Instances 100/150 and 101/151 are Danfoss-specific. Instances 20/70 and 21/71 are ODVA-specific AC Drive profiles.

For guidelines in telegram selection, please refer to the DeviceNet Operating Instructions.

Note that a change to this parameter will be executed immediately.

[0] Instance 100/150

[1] Instance 101/151

[2] Instance 20/70

[3] Instance 21/71



## 10-11 Process Data Config Write

**Option:**

**Function:**

[0] \*

None

3-02 Minimum refer-  
ence

3-03 Maximum refer-  
ence

3-12 Catch up/slow  
down value

3-41 Ramp 1 ramp up  
time

3-42 Ramp 1 ramp  
down time

3-51 Ramp 2 ramp up  
time

3-52 Ramp 2 ramp  
down time

3-80 Jog ramp time

3-81 Quick stop ramp  
time

4-11 Motor speed low  
limit (RPM)

4-13 Motor speed high  
limit (RPM)

4-16 Torque limit mo-  
tor mode

4-17 Torque limit gen-  
erator mode

7-28 Minimum Feed-  
back

7-29 Maximum Feed-  
back

8-90 Bus Jog 1 Speed

8-91 Bus Jog 2 Speed

16-80 Fieldbus CTW 1  
(Fixed)

16-82 Fieldbus REF 1  
(Fixed)

34-01 PCD 1 Write to  
MCO

34-02 PCD 2 Write to  
MCO

34-03 PCD 3 Write to  
MCO

34-04 PCD 4 Write to  
MCO

34-05 PCD 5 Write to  
MCO

34-06 PCD 6 Write to  
MCO

34-07 PCD 7 Write to  
MCO

34-08 PCD 8 Write to  
MCO

34-09 PCD 9 Write to  
MCO

34-10 PCD 10 Write to MCO Select the process write data for I/O Assembly Instances 101/151. Elements [2] and [3] of this array can be selected. Elements [0] and [1] of the array are fixed.

### 10-12 Process Data Config Read

#### Option:

#### Function:

None

16-00 Control Word

16-01 Reference [Unit]

16-02 Reference %

16-03 Status Word  
(Fixed)

16-04 Main Actual Val-  
ue [Unit]

16-05 Main Actual Val-  
ue (%) (Fixed)

16-10 Power [kW]

16-11 Power [hp]

16-12 Motor Voltage

16-13 Frequency

16-14 Motor Current

16-16 Torque

16-17 Speed [RPM]

16-18 Motor Thermal

16-19 KTY Sensor  
Temperature

16-21 Phase Angle

16-30 DC Link Voltage

16-32 BrakeEnergy/s

16-33 BrakeEnergy/2  
min

16-34 Heatsink Temp.

16-35 Inverter Thermal

16-38 SL Control State

16-39 Controlcard  
Temp.

16-50 External Refer-  
ence

16-51 Pulse Reference

16-52 Feedback [Unit]

16-53 Digi Pot Refer-  
ence

16-60 Digital Input

16-61 Terminal 53  
Switch Setting

16-62 Analog Input 53

16-63 Terminal 54  
Switch Setting

16-64 Analog Input 54

16-65 Analog Output  
42 [mA]

16-66 Digital Output  
[bin]

16-67 Freq. Input #29  
[Hz]

16-68 Freq. Input #33  
[Hz]

16-69 Pulse Output  
#27 [Hz]

16-70 Pulse Output  
#29 [Hz]

16-71 Relay Output  
[bin]

16-84 Comm Option  
STW

16-85 FC Port CTW 1

16-90 Alarm Word

16-91 Alarm Word 2

16-92 Warning Word

16-93 Warning Word 2

16-94 Extended Status  
Word

16-95 Extended Status  
Word 2

34-21 PCD 1 Read from  
MCO

34-22 PCD 2 Read from  
MCO

34-23 PCD 3 Read from  
MCO

34-24 PCD 4 Read from  
MCO

34-25 PCD 5 Read from  
MCO

34-26 PCD 6 Read from  
MCO

34-27 PCD 7 Read from  
MCO

34-28 PCD 8 Read from  
MCO

34-29 PCD 9 Read from  
MCO

34-30 PCD 10 Read  
from MCO

34-40 Digital Inputs

34-41 Digital Outputs

34-50 Actual Position

34-51 Commanded Position

34-52 Actual Master Position

34-53 Slave Index Position

34-54 Master Index Position

34-55 Curve Position

34-56 Track Error

34-57 Synchronizing Error

34-58 Actual Velocity

34-59 Actual Master Velocity

34-60 Synchronizing Status

34-61 Axis Status

34-62 Program Status Select the process read data for I/O Assembly Instances 101/151. Elements [2] and [3] of this array can be selected. Elements [0] and [1] of the array are fixed.

### 10-13 Warning Parameter

**Range:**

0\* [0 - FFFF]

**Function:**

View a DeviceNet-specific Warning word. One bit is assigned to every warning. Please refer to the DeviceNet Operating Instructions (MG.33.DX.YY) for further information.

Bit:	Meaning:
0	Bus not active
1	Explicit connection timeout
2	I/O connection
3	Retry limit reached
4	Actual is not updated
5	CAN bus off
6	I/O send error
7	Initialization error
8	No bus supply
9	Bus off
10	Error passive
11	Error warning
12	Duplicate MAC ID Error
13	RX queue overrun
14	TX queue overrun
15	CAN overrun

### 10-14 Net Reference

Read only from LCP.

Select the reference source in Instance 21/71 and 20/70.

[0] \* Off Enables reference via analog/digital inputs.

[1] On Enables reference via the fieldbus.

### 10-15 Net Control

Read only from LCP.

		Select the control source in Instance 21/71 and 20-70.
[0] *	Off	Enables control via analog/digital inputs.
[1]	On	enable control via the fieldbus.

### 2.13.4. 10-2\* COS Filters

Parameters for configuring COS filter settings.

#### 10-20 COS Filter 1

<b>Range:</b>	<b>Function:</b>
0000* [0 - FFFF]	Enter the value for COS Filter 1 to set up the filter mask for the Status Word. When operating in COS (Change-Of-State), this function filters out bits in the Status Word that should not be sent if they change.

#### 10-21 COS Filter 2

<b>Range:</b>	<b>Function:</b>
0000* [0 - FFFF]	Enter the value for COS Filter 2, to set up the filter mask for the Main Actual Value. When operating in COS (Change-Of-State), this function filters out bits in the Main Actual Value that should not be sent if they change.

#### 10-22 COS Filter 3

<b>Range:</b>	<b>Function:</b>
0000* [0 - FFFF]	Enter the value for COS Filter 3, to set up the filter mask for PCD 3. When operating in COS (Change-Of-State), this function filters out bits in PCD 3 that should not be sent if they change.

#### 10-23 COS Filter 4

<b>Range:</b>	<b>Function:</b>
0000* [0 - FFFF]	Enter the value for COS Filter 4 to set up the filter mask for PCD 4. When operating in COS (Change-Of-State), this function filters out bits in PCD 4 that should not be sent if they change.

### 2.13.5. 10-3\* Parameter Access

Parameter group providing access to indexed parameters and defining programming set-up.

#### 10-30 Array Index

<b>Range:</b>	<b>Function:</b>
0* [0 - 255]	
Read only from LCP.	View array parameters. This parameter is valid only when a DeviceNet fieldbus is installed.

#### 10-31 Store Data Values

<b>Option:</b>	<b>Function:</b>	
	Parameter values changed via DeviceNet are not automatically stored in non-volatile memory. Use this parameter to activate a function that stores parameter values in the EEPROM non-volatile memory, so changed parameter values will be retained at power-down.	
[0] *	Off	Deactivates the non-volatile storage function.
[1]	Store edit setup	Stores all parameter values from the active set-up in the non-volatile memory. The selection returns to Off [0] when all values have been stored.
[2]	Store all setups	store all parameter values for all set-ups in the non-volatile memory. The selection returns to Off [0] when all parameter values have been stored.

#### 10-32 Devicenet Revision

<b>Option:</b>	<b>Function:</b>
Major revision	
Minor revision	View the DeviceNet revision number. This parameter is used for EDS file creation.

**10-33 Store Always**

Option:	Function:
[0] * Off	Deactivates non-volatile storage of data.
[1] On	Stores parameter data received via DeviceNet in EEPROM non-volatile memory as default.

**10-39 Devicenet F Parameters**

Array [1000]

No LCP access


0* [0 - 0]	This parameter is used to configure the frequency converter via DeviceNet and build the EDS-file.
------------	---

## 2.14. Parameters: Smart Logic Control

### 2.14.1. 13-\*\* Prog. Features

Smart Logic Control (SLC) is essentially a sequence of user defined actions (see par. 13-52 [x]) executed by the SLC when the associated user defined *event* (see par. 13-51 [x]) is evaluated as TRUE by the SLC. Events and *actions* are each numbered and linked together in pairs (states). This means that when *event* [0] is fulfilled (attains the value TRUE), *action* [0] is executed. After this, the conditions of *event* [1] will be evaluated and if evaluated TRUE, *action* [1] will be executed and so on. Only one *event* will be evaluated at any time. If an *event* is evaluated as FALSE, nothing happens (in the SLC) during the current scan interval and no other *events* will be evaluated. This means that when the SLC starts, it evaluates *event* [0] (and only *event*[0]) each scan interval. Only when *event* [0] is evaluated TRUE, will the SLC execute *action* [0] and start evaluating *event* [1]. It is possible to programme from 1 to 20 *events* and *actions*.

When the last *event* / *action* has been executed, the sequence starts over again from *event*[0] / *action* [0]. The illustration shows an example with three event / actions:



#### Starting and stopping the SLC:

Starting and stopping the SLC can be done by selecting .On [1], or .Off [0], in par. 13-00. The SLC always starts in state 0 (where it evaluates *event*[0]). The SLC starts when the Start Event (defined in par. 13-01 *Start Event*) is evaluated as TRUE (provided that On [1] is selected in par. 13-00). The SLC stops when the *Stop Event* (par. 13-02) is TRUE. Par. 13-03 resets all SLC parameters and start programming from scratch.

### 2.14.2. 13-0\* SLC Settings

Use the SLC settings to activate, deactivate and reset the Smart Logic Control.

### 13-00 SL Controller Mode

Option:	Function:
[0] * Off	Disables the Smart Logic Controller.
[1] On	Enables the Smart Logic Controller.

### 13-01 Start Event

Option:	Function:
[0] False	
[1] True	
[2] Running	
[3] In range	
[4] On reference	
[5] Torque limit	
[6] Current limit	
[7] Out of current range	
[8] Below I low	
[9] Above I high	
[10] Out of speed range	
[11] Below speed low	
[12] Above speed high	
[13] Out of feedb. range	
[14] Below feedb. low	
[15] Above feedb. high	
[16] Thermal warning	
[17] Mains out of range	
[18] Reversing	
[19] Warning	
[20] Alarm (trip)	
[21] Alarm (trip lock)	
[22] Comparator 0	
[23] Comparator 1	
[24] Comparator 2	
[25] Comparator 3	
[26] Logic rule 0	
[27] Logic rule 1	
[28] Logic rule 2	
[29] Logic rule 3	
[33] Digital input DI18	
[34] Digital input DI19	
[35] Digital input DI27	
[36] Digital input DI29 (FC 302 only)	
[37] Digital input DI32	
[38] Digital input DI33	
[39] * Start command	
[40] Drive stopped	
[41] Reset Trip	

[42]	Auto-reset Trip	
[43]	Ok key	
[44]	Reset key	
[45]	Left key	
[46]	Right key	
[47]	Up key	
[48]	Down key	
[50]	Comparator 4	
[51]	Comparator 5	
[60]	Logic rule 4	
[61]	Logic rule 5	<p>Select the boolean (TRUE or FALSE) input to activate Smart Logic Control.</p> <p><i>False</i> [0] enters the fixed value - FALSE.</p> <p><i>True</i> [1] enters the fixed value - TRUE.</p> <p><i>Running</i> [2] The motor is running.</p> <p><i>In range</i> [3] The motor is running within the programmed current and speed ranges set in par. 4-50 to par. 4-53.</p> <p><i>On reference</i> [4] The motor is running on reference.</p> <p><i>Torque limit</i> [5] The torque limit, set in par. 4-16 or 4-17, has been exceeded.</p> <p><i>Current limit</i> [6] The motor current limit, set in par. 4-18, has been exceeded.</p> <p><i>Out of current range</i> [7] The motor current is outside the range set in par. 4-18.</p> <p><i>Below I low</i> [8] The motor current is lower than set in par. 4-50.</p> <p><i>Above I high</i> [9] The motor current is higher than set in par. 4-51.</p> <p><i>Out of speed range</i> [10] The speed is outside the range set in par. 4-52 and 4-53.</p> <p><i>Below speed low</i> [11] The output speed is lower than the setting in par. 4-52.</p> <p><i>Above speed high</i> [12] The output speed is higher than the setting in par. 4-53.</p> <p><i>Out of feedb. Range</i> [13] The feedback is outside the range set in par. 4-56 and 4-57.</p> <p><i>Below feedb. Low</i> [14] The feedback is below the limit set in par. 4-56.</p> <p><i>Above feedb. High</i> [15] The feedback is above the limit set in par. 4-57.</p> <p><i>Thermal warning</i> [16] The thermal warning turns on when the temperature exceeds the limit in the motor, the frequency converter, the brake resistor or the thermistor.</p> <p><i>Mains out of range</i> [17] The mains voltage is outside the specified voltage range.</p> <p><i>Reversing</i> [18] The output is high when the frequency converter is running counter clockwise (the logical product of the status bits "running" AND "reverse").</p> <p><i>Warning</i> [19] A warning is active.</p> <p><i>Alarm (trip)</i> [20] A (trip) alarm is active.</p> <p><i>Alarm (trip lock)</i> [21] A (Trip lock) alarm is active.</p> <p><i>Comparator 0</i> [22] Use the result of comparator 0.</p> <p><i>Comparator 1</i> [23] Use the result of comparator 1.</p> <p><i>Comparator 2</i> [24] Use the result of comparator 2.</p> <p><i>Comparator 3</i> [25] Use the result of comparator 3.</p> <p><i>Logic rule 0</i> [26] Use the result of logic rule 0.</p> <p><i>Logic rule 1</i> [27] Use the result of logic rule 1.</p> <p><i>Logic rule 2</i> [28] Use the result of logic rule 2.</p> <p><i>Logic rule 3</i> [29] Use the result of logic rule 3.</p> <p><i>Digital input DI18</i> [33] Use the result of digital input 18.</p> <p><i>Digital input DI19</i> [34] Use the result of digital input 19.</p> <p><i>Digital input DI27</i> [35] Use the result of digital input 27.</p> <p><i>Digital input DI29 FC302Only</i> [36] Use the result of digital input 29.</p> <p><i>Digital input DI32</i> [37] Use the result of digital input 32.</p> <p><i>Digital input DI33</i> [38] Use the result of digital input 33.</p> <p><i>Start command</i> [39] A start command is issued.</p> <p><i>Drive stopped</i> [40] A stop command ( Jog, Stop, Qstop, Coast) is issued – and not from the SLC itself.</p> <p><i>Reset Trip</i> [41] A reset is issued</p> <p><i>Auto-reset Trip</i> [42] An Auto reset is performed.</p> <p><i>OK key</i> [43] The Ok key is pressed.</p> <p><i>Reset key</i> [44] The reset key is pressed.</p>



*Left key* [45] The left key is pressed.  
*Right key* [46] The right key is pressed.  
*Up key* [47] The up key is pressed.  
*Down key* [48] The down key is pressed.  
*Comparator 4* [50] Use the result of comparator 4.  
*Comparator 5* [51] Use the result of comparator 5.  
*Logic rule 4* [60] Use the result of logic rule 4.  
*Logic rule 5* [61] Use the result of logic rule 5.

### 13-02 Stop Event

#### Option:

#### Function:

[0]	False
[1]	True
[2]	Running
[3]	In range
[4]	On reference
[5]	Torque limit
[6]	Current limit
[7]	Out of current range
[8]	Below I low
[9]	Above I high
[10]	Out of speed range
[11]	Below speed low
[12]	Above speed high
[13]	Out of feedb. range
[14]	Below feedb. low
[15]	Above feedb. high
[16]	Thermal warning
[17]	Mains out of range
[18]	Reversing
[19]	Warning
[20]	Alarm (trip)
[21]	Alarm (trip lock)
[22]	Comparator 0
[23]	Comparator 1
[24]	Comparator 2
[25]	Comparator 3
[26]	Logic rule 0
[27]	Logic rule 1
[28]	Logic rule 2
[29]	Logic rule 3
[30]	SL Time-out 0
[31]	SL Time-out 1
[32]	SL Time-out 2
[33]	Digital input DI18
[34]	Digital input DI19
[35]	Digital input DI27
[36]	Digital input DI29 (FC 302 only)

[37]	Digital input DI32	
[38]	Digital input DI33	
[39]	Start command	
[40]	Drive stopped	
[41]	Reset Trip	
[42]	Auto-reset Trip	
[43]	Ok key	
[44]	Reset key	
[45]	Left key	
[46]	Right key	
[47]	Up key	
[48]	Down key	
[50]	Comparator 4	
[51]	Comparator 5	
[60]	Logic rule 4	
[61]	Logic rule 5	
[70]	SL Time-out 3	
[71]	SL Time-out 4	
[72]	SL Time-out 5	
[73]	SL Time-out 6	
[74]	SL Time-out 7	Select the boolean (TRUE or FALSE) input to activate Smart Logic Control. For descriptions [0] - [61], see 13-01 <i>Start Event</i> <i>SL Time-out 3</i> [70] Smart logic controller timer 3 is timed out. <i>SL Time-out 4</i> [71] Smart logic controller timer 4 is timed out. <i>SL Time-out 5</i> [72] Smart logic controller timer 5 is timed out. <i>SL- Time-out 6</i> [73] Smart logic controller timer 6 is timed out. <i>SL Time-out 7</i> [74] Smart logic controller timer 7 is timed out.

### 13-03 Reset SLC

#### Option:

[0] \* Do not reset SLC

#### Function:

Retains programmed settings in all group 13 parameters (13-\*).

[1] Reset SLC

Resets all group 13 parameters (13-\*) to default settings.

### 2.14.3. 13-1\* Comparators

Comparators are used for comparing continuous variables (i.e. output frequency, output current, analog input etc.) to fixed preset values. In addition, there are digital values that will be compared to fixed time values. See explanation in par. 13-10. Comparators are evaluated once in each scan interval. Use the result (TRUE or FALSE) directly. All parameters in this parameter group are array parameters with index 0 to 5. Select index 0 to programme Comparator 0, select index 1 to programme Comparator 1, and so on.

### 13-10 Comparator Operand

Array [6]

Choice [1] to [31] are variables which will be compared based on their values. Choice [50] to [186] are digital values (TRUE/FALSE) where the comparison is based on the amount of time during which they are set to TRUE or FALSE, respectively. See par. 13-11.  
Select the variable to be monitored by the comparator.

[0] \* DISABLED *DISABLED* [0] The comparator is disabled.

[1] Reference *Reference* [1] The resulting remote reference (not local) as a percentage.

[2] Feedback *Feedback* [2] In the unit [RPM] or [Hz]

[3]	Motor speed	<i>Motor speed</i> [3] [RPM] or [Hz]
[4]	Motor current	<i>Motor current</i> [4] [A]
[5]	Motor torque	<i>Motor torque</i> [5] [Nm]
[6]	Motor power	<i>Motor power</i> [6] [kW] or [hp]
[7]	Motor voltage	<i>Motor voltage</i> [7] [V]
[8]	DC-link voltage	<i>DC-link voltage</i> [8] [V]
[9]	Motor thermal	<i>Motor thermal</i> [9] Expressed as a percentage.
[10]	VLT thermal	<i>VLT thermal</i> [10] Expressed as a percentage.
[11]	Heat sink temp.	<i>Heat sink temp</i> [11] Expressed as a percentage.
[12]	Analog input AI53	<i>Analog input AI53</i> [12] Expressed as a percentage.
[13]	Analog input AI54	<i>Analog input AI54</i> [13] Expressed as a percentage.
[14]	Analog input AIFB10	<i>Analog input AIFB10</i> [14] [V]
[15]	Analog input AIS24V	<i>Analog input AIS24V</i> [15] [V] Analog input AICCT [17] [°].
[17]	Analog input AICCT	
[18]	Pulse input FI29 (FC 302 only)	<i>Pulse input FI29 (FC 302 Only)</i> [18] Expressed as a percentage.
[19]	Pulse input FI33	<i>Pulse input FI33</i> [19] Expressed as a percentage.
[20]	Alarm number	<i>Alarm number</i> [20] The error number.
[30]	Counter A	<i>Counter A</i> [30] Number of counts
[31]	Counter B	<i>Counter B</i> [31] Number of counts
[50]	False	<i>False</i> [50] Enters the fixed value of false in the comparator.
[51]	True	<i>True</i> [51] Enters the fixed value of true in the comparator.
[52]	Control ready	<i>Control ready</i> [52] The control board receives supply voltage
[53]	Drive ready	<i>Drive ready</i> [53] The frequency converter is ready for operation and applies a supply signal on the control board.
[54]	Running	<i>Running</i> [54] The motor is running.
[55]	Reversing	<i>Reversing</i> [55] The output is high when the frequency converter is running counter clockwise (the logical product of the status bits "running" AND "reverse")
[56]	In range	<i>In range</i> [56] The motor is running within the programmed current and speed ranges set in par. 4-50 to par. 4-53.
[60]	On reference	<i>On reference</i> [60] The motor is running on reference.
[61]	Below reference, low	<i>Below reference, low</i> [61] The motor is running below the value given in par. 4-54 "Warning Reference Low"
[62]	Above reference, high	<i>Above reference, high</i> [62] The motor is running above the value given in par. 4-55 "Warning Reference High"
[65]	Torque limit	<i>Torque limit</i> [65] The torque limit, set in par. 4-16 or 4-17, has been exceeded.
[66]	Current limit	<i>Current limit</i> [66] The motor current limit, set in par. 4-18, has been exceeded.
[67]	Out of current range	<i>Out of current range</i> [67] The motor current is outside the range set in par. 4-18.
[68]	Below I low	<i>Below I low</i> [68] The motor current is lower than set in par. 4-50.
[69]	Above I high	<i>Above I high</i> [69] The motor current is higher than set in par. 4-51.
[70]	Out of speed range	<i>Out of speed range</i> [70] The speed is outside the range set in par. 4-52 and 4-53.
[71]	Below speed low	<i>Below speed low</i> [71] The output speed is lower than the setting in par. 4-52.
[72]	Above speed high	<i>Above speed high</i> [72] The output speed is higher than the setting in par. 4-53.
[75]	Out of feedb. range	<i>Out of feedb. Range</i> [75] The feedback is outside the range set in par. 4-56 and 4-57.
[76]	Below feedb. low	<i>Below feedb. Low</i> [76] The feedback is below the limit set in par. 4-56.
[77]	Above feedb. high	<i>Above feedb. High</i> [77] The feedback is above the limit set in par. 4-57.
[80]	Thermal warning	<i>Thermal warning</i> [80] The thermal warning turns on when the temperature exceeds the limit in the motor, the frequency converter, the brake resistor or thermistor.
[82]	Mains out of range	<i>Mains out of range</i> [82] The mains voltage is outside the specified voltage range.
[85]	Warning	<i>Warning</i> [85] A warning is active.
[86]	Alarm (trip)	<i>Alarm (trip)</i> [86] A (trip) alarm is active.

[87]	Alarm (trip lock)	<i>Alarm (trip lock)</i> [87] A (Trip lock) alarm is active.
[90]	Bus OK	<i>Bus OK</i> [90] Active communication (no time-out) via the serial communication port.
[91]	Torque limit & stop	<i>Torque limit &amp; stop</i> [91] If the frequency converter has received a stop signal and is at the torque limit, the signal is logic "0".
[92]	Brake fault (IGBT)	<i>Brake fault (IGBT)</i> [92] The brake IGBT is short circuited.
[93]	Mech. brake control	<i>Mech. brake control</i> [93] The mechanical brake is active.
[94]	Safe stop active (FC 302 only)	<i>Safe stop active (FC 302 Only)</i> [94] Safe stop is active DI 37.
[100]	Comparator 0	<i>Comparator 0</i> [100] The result of comparator 0.
[101]	Comparator 1	<i>Comparator 1</i> [101] The result of comparator 1.
[102]	Comparator 2	<i>Comparator 2</i> [102] The result of comparator 2.
[103]	Comparator 3	<i>Comparator 3</i> [103] The result of comparator 3.
[104]	Comparator 4	<i>Comparator 4</i> [104] The result of comparator 4.
[105]	Comparator 5	<i>Comparator 5</i> [105] The result of comparator 5.
[110]	Logic rule 0	<i>Logic rule 0</i> [110] The result of Logic rule 0.
[111]	Logic rule 1	<i>Logic rule 1</i> [111] The result of Logic rule 1.
[112]	Logic rule 2	<i>Logic rule 2</i> [112] The result of Logic rule 2.
[113]	Logic rule 3	<i>Logic rule 3</i> [113] The result of Logic rule 3.
[114]	Logic rule 4	<i>Logic rule 4</i> [114] The result of Logic rule 4.
[115]	Logic rule 5	<i>Logic rule 5</i> [115] The result of Logic rule 5.
[120]	SL Time-out 0	<i>SL Time-out 0</i> [120] The result of SLC timer 0.
[121]	SL Time-out 1	<i>SL Time-out 1</i> [121] The result of SLC timer 1.
[122]	SL Time-out 2	<i>SL Time-out 2</i> [122] The result of SLC timer 2.
[123]	SL Time-out 3	<i>SL Time-out 3</i> [123] The result of SLC timer 3.
[124]	SL Time-out 4	<i>SL Time-out 4</i> [124] The result of SLC timer 4.
[125]	SL Time-out 5	<i>SL Time-out 5</i> [125] The result of SLC timer 5.
[126]	SL Time-out 6	<i>SL Time-out 6</i> [126] The result of SLC timer 6.
[127]	SL Time-out 7	<i>SL Time-out 7</i> [127] The result of SLC timer 7.
[130]	Digital input DI18	<i>Digital input DI18</i> [130] Digital input 18. High = True.
[131]	Digital input DI19	<i>Digital input DI19</i> [131] Digital input 19. High = True.
[132]	Digital input DI27	<i>Digital input DI27</i> [132] Digital input 27. High = True.
[133]	Digital input DI29	<i>Digital input DI29</i> [133] Digital input 29. High = True.
[134]	Digital input DI32	<i>Digital input DI32</i> [134] Digital input 32. High = True.
[135]	Digital input DI33	<i>Digital input DI33</i> [135] Digital input 33. High = True.
[150]	SL digital output A	<i>SL digital output A</i> [150] Use the result of the SLC output A.
[151]	SL digital output B	<i>SL digital output B</i> [151] Use the result of the SLC output B.
[152]	SL digital output C	<i>SL digital output C</i> [152] Use the result of the SLC output C.
[153]	SL digital output D	<i>SL digital output D</i> [153] Use the result of the SLC output D.
[154]	SL digital output E	<i>SL digital output E</i> [154] Use the result of the SLC output E.
[155]	SL digital output F	<i>SL digital output F</i> [155] Use the result of the SLC output F.
[160]	Relay 1	<i>Relay 1</i> [160] Relay 1 is active
[161]	Relay 2	<i>Relay 2</i> [161] Relay 2 is active
[180]	Local ref. active	<i>Local ref. active</i> [180] High when par. 3-13 "Reference site" = [2] Local or when par 3-13 is [0] Linked to hand Auto, at the same time as the LCP is in Hand on mode.
[181]	Remote ref. active	<i>Remote ref. active</i> [181] High when par. 3-13 "Reference site" = [1] Remote or [0] Linked to hand/auto, while the LCP is in Auto on mode.
[182]	Start command	<i>Start command</i> [182] High when there is an active start command, and no stop command.
[183]	Drive stopped	<i>Drive stopped</i> [183] A stop command ( Jog, Stop, Qstop, Coast) is issued – and not from the SLC itself.

[185] Drive in hand mode *Drive in hand mode* [185] High when the frequency converter is in hand mode.

[186] Drive in auto mode *Drive in auto mode* [186] High when the frequency converter is in auto mode.

### 13-11 Comparator Operator

Array [6]

For par. 13-10 containing values from [0] to [31] the following is valid:  
Select the operator to be used in the comparison.

[0] < Select < [0] for the result of the evaluation to be TRUE, when the variable selected in par. 13-10 is smaller than the fixed value in par. 13-12. The result will be FALSE, if the variable selected in par. 13-10 is greater than the fixed value in par. 13-12.

[1] \* ≈ Select ≈ [1] for the result of the evaluation to be TRUE, when the variable selected in par. 13-10 is approximately equal to the fixed value in par. 13-12.

[2] > Select > [2] for the inverse logic of option < [0].

### 13-12 Comparator Value

Array [6]

0.000 \* [-100000.000 - 100000.000] Enter the 'trigger level' for the variable that is monitored by this comparator. This is an array parameter containing comparator values 0 to 5.

#### 2.14.4. 13-2\* Timers

This parameter group consists of timer parameters.

Use the result (TRUE or FALSE) from *timers* directly to define an *event* (see par. 13-51), or as boolean input in a *logic rule* (see par. 13-40, 13-42 or 13-44). A timer is only FALSE when started by an action (i.e. Start timer 1 [29]) until the timer value entered in this parameter is elapsed. Then it becomes TRUE again.

All parameters in this parameter group are array parameters with index 0 to 2. Select index 0 to program Timer 0, select index 1 to program Timer 1, and so on.

### 13-20 SL Controller Timer

Array [8]

0.00s\* [00:00:00.000 - 99:59:59.999] Enter the value to define the duration of the FALSE output from the programmed timer. A timer is only FALSE if it is started by an action (i.e. *Start timer 1* [29]) and until the given timer value has elapsed.

#### 2.14.5. 13-4\* Logic Rules

Combine up to three boolean inputs (TRUE / FALSE inputs) from timers, comparators, digital inputs, status bits and events using the logical operators AND, OR, and NOT. Select boolean inputs for the calculation in par. 13-40, 13-42, and 13-44. Define the operators used to logically combine the selected inputs in par. 13-41 and 13-43.

##### Priority of calculation

The results of par. 13-40, 13-41, and 13-42 are calculated first. The outcome (TRUE / FALSE) of this calculation is combined with the settings of par. 13-43 and 13-44, yielding the final result (TRUE / FALSE) of the logic rule.

### 13-40 Logic Rule Boolean 1

Array [6]

[0] \* False

[1] True

[2]	Running
[3]	In range
[4]	On reference
[5]	Torque limit
[6]	Current limit
[7]	Out of current range
[8]	Below I low
[9]	Above I high
[10]	Out of speed range
[11]	Below speed low
[12]	Above speed high
[13]	Out of feedb. range
[14]	Below feedb. low
[15]	Above feedb. high
[16]	Thermal warning
[17]	Mains voltage out of range
[18]	Reversing
[19]	Warning
[20]	Alarm (trip)
[21]	Alarm (trip lock)
[22]	Comparator 0
[23]	Comparator 1
[24]	Comparator 2
[25]	Comparator 3
[26]	Logic rule 0
[27]	Logic rule 1
[28]	Logic rule 2
[29]	Logic rule 3
[30]	SL Time-out 0
[31]	SL Time-out 1
[32]	SL Time-out 2
[33]	Digital input DI18
[34]	Digital input DI19
[35]	Digital input DI27
[36]	Digital input DI29 (FC 302 only)
[37]	Digital input DI32
[38]	Digital input DI33
[39]	Start command
[40]	Drive stopped
[41]	Reset Trip
[42]	Auto-reset Trip
[43]	Ok key
[44]	Reset key
[45]	Left key
[46]	Right key

[47]	Up key	
[48]	Down key	
[50]	Comparator 4	
[51]	Comparator 5	
[60]	Logic rule 4	
[61]	Logic rule 5	
[70]	SL Time-out 3	
[71]	SL Time-out 4	
[72]	SL Time-out 5	
[73]	SL Time-out 6	
[74]	SL Time-out 7	Select the first boolean (TRUE or FALSE) input for the selected logic rule. See par. 13-01 <i>Start Event</i> ([0] - [61]) and par. 13-02 <i>Stop Event</i> ([70] - [74]) for further description.

**13-41 Logic Rule Operator 1**

Array [6]

		Select the first logical operator to use on the Boolean inputs from par. 13-40 and 13-42. [13 -XX] signifies the boolean input of par. 13-*. [0] * DISABLED Ignores par. 13-42, 13-43, and 13-44.
[1]	AND	evaluates the expression [13-40] AND [13-42].
[2]	OR	evaluates the expression [13-40] OR [13-42].
[3]	AND NOT	evaluates the expression [13-40] AND NOT [13-42].
[4]	OR NOT	evaluates the expression [13-40] OR NOT [13-42].
[5]	NOT AND	evaluates the expression NOT [13-40] AND [13-42].
[6]	Not or	evaluates the expression NOT [13-40] OR [13-42].
[7]	Not and not	evaluates the expression NOT [13-40] AND NOT [13-42].
[8]	Not or not	evaluates the expression NOT [13-40] OR NOT [13-42].

**13-42 Logic Rule Boolean 2**

Array [6]

[0]	False
[1]	True
[2]	Running
[3]	In range
[4]	On reference
[5]	Torque limit
[6]	Current limit
[7]	Out of current range
[8]	Below I low
[9]	Above I high
[10]	Out of speed range
[11]	Below speed low
[12]	Above speed high
[13]	Out of feedb. range
[14]	Below feedb. low
[15]	Above feedb. high
[16]	Thermal warning

[17]	Mains out of range	
[18]	Reversing	
[19]	Warning	
[20]	Alarm (trip)	
[21]	Alarm (trip lock)	
[22]	Comparator 0	
[23]	Comparator 1	
[24]	Comparator 2	
[25]	Comparator 3	
[26]	Logic rule 0	
[27]	Logic rule 1	
[28]	Logic rule 2	
[29]	Logic rule 3	
[30]	SL Time-out 0	
[31]	SL Time-out 1	
[32]	SL Time-out 2	
[33]	Digital input DI18	
[34]	Digital input DI19	
[35]	Digital input DI27	
[36]	Digital input DI29 (FC 302 only)	
[37]	Digital input DI32	
[38]	Digital input DI33	
[39]	Start command	
[40]	Drive stopped	
[41]	Reset Trip	
[42]	Auto-reset Trip	
[43]	Ok key	
[44]	Reset key	
[45]	Left key	
[46]	Right key	
[47]	Up key	
[48]	Down key	
[50]	Comparator 4	
[51]	Comparator 5	
[60]	Logic rule 4	
[61]	Logic rule 5	
[70]	SL Time-out 3	
[71]	SL Time-out 4	
[72]	SL Time-out 5	
[73]	SL Time-out 6	
[74]	SL Time-out 7	Select the second boolean (TRUE or FALSE) input for the selected logic rule. See par. 13-01 <i>Start Event</i> ([0] - [61]) and par. 13-02 <i>Stop Event</i> ([70] - [74]) for further description.

### 13-43 Logic Rule Operator 2

Array [6]



Select the second logical operator to be used on the boolean input calculated in par. 13-40, 13-41, and 13-42, and the boolean input coming from par. 13-44.  
 [13-44] signifies the boolean input of par. 13-44.  
 [13-40/13-42] signifies the boolean input calculated in par. 13-40, 13-41, and 13-42. DISABLED [0] (factory setting). select this option to ignore par. 13-44.

[0] *	DISABLED	
[1]	AND	Evaluates the expression [13-40/13-42] AND [13-44].
[2]	OR	Evaluates the expression [13-40/13-42] OR [13-44].
[3]	AND NOT	Evaluates the expression [13-40/13-42] AND NOT [13-44].
[4]	OR NOT	Evaluates the expression [13-40/13-42] OR NOT [13-44].
[5]	NOT AND	evaluates the expression NOT [13-40/13-42] AND [13-44].
[6]	NOT OR	Evaluates the expression NOT [13-40/13-42] OR [13-44].
[7]	NOT AND NOT	Evaluates the expression NOT [13-40/13-42] and evaluates AND NOT [13-44].
[8]	NOT OR NOT	Evaluates the expression NOT [13-40/13-42] OR NOT [13-44].

### 13-44 Logic Rule Boolean 3

#### Array [6]

[0]	False
[1]	True
[2]	Running
[3]	In range
[4]	On reference
[5]	Torque limit
[6]	Current limit
[7]	Out of current range
[8]	Below I low
[9]	Above I high
[10]	Out of speed range
[11]	Below speed low
[12]	Above speed high
[13]	Out of feedb. range
[14]	Below feedb. low
[15]	Above feedb. high
[16]	Thermal warning
[17]	Mains out of range
[18]	Reversing
[19]	Warning
[20]	Alarm (trip)
[21]	Alarm (trip lock)
[22]	Comparator 0
[23]	Comparator 1
[24]	Comparator 2
[25]	Comparator 3
[26]	Logic rule 0
[27]	Logic rule 1
[28]	Logic rule 2
[29]	Logic rule 3

[30]	SL Time-out 0	
[31]	SL Time-out 1	
[32]	SL Time-out 2	
[33]	Digital input DI18	
[34]	Digital input DI19	
[35]	Digital input DI27	
[36]	Digital input DI29 (FC 302 only)	
[37]	Digital input DI32	
[38]	Digital input DI33	
[39]	Start command	
[40]	Drive stopped	
[41]	Reset Trip	
[42]	Auto-reset Trip	
[43]	Ok key	
[44]	Reset key	
[45]	Left key	
[46]	Right key	
[47]	Up key	
[48]	Down key	
[50]	Comparator 4	
[51]	Comparator 5	
[60]	Logic rule 4	
[61]	Logic rule 5	
[70]	SL Time-out 3	
[71]	SL Time-out 4	
[72]	SL Time-out 5	
[73]	SL Time-out 6	
[74]	SL Time-out 7	Select the third boolean (TRUE or FALSE) input for the selected logic rule. See par. 13-01 <i>Start Event</i> ([0] - [61]) and par. 13-02 <i>Stop Event</i> ([70] - [74]) for further description.

### 2.14.6. 13-5\* States

Parameters for programming the Smart Logic Controller.

#### 13-51 SL Controller Event

Array [20]

[0]	False
[1]	True
[2]	Running
[3]	In range
[4]	On reference
[5]	Torque limit
[6]	Current limit
[7]	Out of current range
[8]	Below I low
[9]	Above I high

[10]	Out of speed range
[11]	Below speed low
[12]	Above speed high
[13]	Out of feedb. range
[14]	Below feedb. low
[15]	Above feedb. high
[16]	Thermal warning
[17]	Mains out of range
[18]	Reversing
[19]	Warning
[20]	Alarm (trip)
[21]	Alarm (trip lock)
[22]	Comparator 0
[23]	Comparator 1
[24]	Comparator 2
[25]	Comparator 3
[26]	Logic rule 0
[27]	Logic rule 1
[28]	Logic rule 2
[29]	Logic rule 3
[30]	SL Time-out 0
[31]	SL Time-out 1
[32]	SL Time-out 2
[33]	Digital input DI18
[34]	Digital input DI19
[35]	Digital input DI27
[36]	Digital input DI29 (FC 302 only)
[37]	Digital input DI32
[38]	Digital input DI33
[39]	Start command
[40]	Drive stopped
[41]	Reset Trip
[42]	Auto-reset Trip
[43]	Ok key
[44]	Reset key
[45]	Left key
[46]	Right key
[47]	Up key
[48]	Down key
[50]	Comparator 4
[51]	Comparator 5
[60]	Logic rule 4
[61]	Logic rule 5
[70]	SL Time-out 3
[71]	SL Time-out 4
[72]	SL Time-out 5

[73]	SL Time-out 6	
[74]	SL Time-out 7	Select the boolean input (TRUE or FALSE) to define the Smart Logic Controller event. See par. 13-01 <i>Start Event</i> ([0] - [61]) and par. 13-02 <i>Stop Event</i> ([70] - [74]) for further description.

### 13-52 SL Controller Action

#### Array [20]

[0] *	Disabled	Select the action corresponding to the SLC event. Actions are executed when the corresponding event (defined in par. 13-51) is evaluated as true. The following actions are available for selection: <i>*DISABLED</i> [0]
[1]	No action	<i>No action</i> [1]
[2]	Select set-up 1	<i>Select set-up 1</i> [2] - changes the active set-up (par. 0-10) to '1'.
[3]	Select set-up 2	<i>Select set-up 2</i> [3] - changes the active set-up (par. 0-10) to '2'.
[4]	Select set-up 3	<i>Select set-up 3</i> [4] - changes the active set-up (par. 0-10) to '3'.
[5]	Select set-up 4	<i>Select set-up 4</i> [5] - changes the active set-up (par. 0-10) to '4'. If the set-up is changed, it will merge with other set-up commands coming from either the digital inputs or via a fieldbus.
[10]	Select preset reference 0	<i>Select preset reference 0</i> [10] – selects preset reference 0.
[11]	Select preset reference 1	<i>Select preset reference 1</i> [11] – selects preset reference 1.
[12]	Select preset reference 2	<i>Select preset reference 2</i> [12] – selects preset reference 2.
[13]	Select preset reference 3	<i>Select preset reference 3</i> [13] – selects preset reference 3.
[14]	Select preset reference 4	<i>Select preset reference 4</i> [14] – selects preset reference 4.
[15]	Select preset reference 5	<i>Select preset reference 5</i> [15] – selects preset reference 5.
[16]	Select preset reference 6	<i>Select preset reference 6</i> [16] – selects preset reference 6.
[17]	Select preset reference 7	<i>Select preset reference 7</i> [17] - selects preset reference 7. If the active preset reference is changed, it will merge with other preset reference commands coming from either the digital inputs or via a fieldbus.
[18]	Select ramp 1	<i>Select ramp 1</i> [18] - selects ramp 1.
[19]	Select ramp 2	<i>Select ramp 2</i> [19] - selects ramp 2.
[20]	Select ramp 3	<i>Select ramp 3</i> [20] - selects ramp 3.
[21]	Select ramp 4	<i>Select ramp 4</i> [21] - selects ramp 4.
[22]	Run	<i>Run</i> [22] - issues a start command to the frequency converter.
[23]	Run reverse	<i>Run reverse</i> [23] - issues a start reverse command to the frequency converter.
[24]	Stop	<i>Stop</i> [24] - issues a stop command to the frequency converter.
[25]	Qstop	<i>Qstop</i> [25] - issues a quick stop command to the frequency converter.
[26]	Dcstop	<i>Dcstop</i> [26] - issues a DC stop command to the frequency converter.
[27]	Coast	<i>Coast</i> [27] - the frequency converter coasts immediately. All stop commands including the coast command stop the SLC.
[28]	Freeze output	<i>Freeze output</i> [28] - freezes the output frequency of the frequency converter.
[29]	Start timer 0	<i>Start timer 0</i> [29] - starts timer 0, see par. 13-20 for further description.
[30]	Start timer 1	<i>Start timer 1</i> [30] - starts timer 1, see par. 13-20 for further description.
[31]	Start timer 2	<i>Start timer 2</i> [31] - starts timer 2, see par. 13-20 for further description.
[32]	Set digital output A low	<i>Set digital output A low</i> [32] - any output with SL output A will be low.
[33]	Set digital output B low	<i>Set digital output B low</i> [33] - any output with SL output B will be low.

[34]	Set digital output C low	<i>Set digital output C low</i> [34] - any output with SL output C will be low.
[35]	Set digital output D low	<i>Set digital output D low</i> [35] - any output with SL output D will be low.
[36]	Set digital output E low	<i>Set digital output E low</i> [36] - any output with SL output E will be low.
[37]	Set digital output F low	<i>Set digital output F low</i> [37] - any output with SL output F will be low.
[38]	Set digital output A high	<i>Set digital output A high</i> [38] - any output with SL output A will be high.
[39]	Set digital output B high	<i>Set digital output B high</i> [39] - any output with SL output B will be high.
[40]	Set digital output C high	<i>Set digital output C high</i> [40] - any output with SL output C will be high.
[41]	Set digital output D high	<i>Set digital output D high</i> [41] - any output with SL output D will be high.
[42]	Set digital output E high	<i>Set digital output E high</i> [42] - any output with SL output E will be high.
[43]	Set digital output F high	<i>Set digital output F high</i> [43] - any output with SL output F will be high.
[60]	Reset Counter A	<i>Reset Counter A</i> [60] - resets Counter A to zero.
[61]	Reset Counter B	<i>Reset Counter B</i> [61] - resets Counter B to zero.
[70]	Start Timer 3	<i>Start Timer 3</i> [70] - Start Timer 3, see par. 13-20 for further description.
[71]	Start Timer 4	<i>Start Timer 4</i> [71] - Start Timer 4, see par. 13-20 for further description.
[72]	Start Timer 5	<i>Start Timer 5</i> [72] - Start Timer 5, see par. 13-20 for further description.
[73]	Start Timer 6	<i>Start Timer 6</i> [73] - Start Timer 6, see par. 13-20 for further description.
[74]	Start Timer 7	<i>Start Timer 7</i> [74] - Start Timer 7, see par. 13-20 for further description.

## 2.15. Parameters: Special Functions

### 2.15.1. 14-\*\* Special Functions

Parameter group for configuring special frequency converter functions.

### 2.15.2. Inverter Switching, 14-0\*

Parameters for configuring the inverter switching.

#### 14-00 Switching Pattern

**Option:** **Function:**

[0] 60 AVM

[1] \* SFAVM Select the switching pattern: 60° AVM or SFAVM.

#### 14-01 Switching Frequency

**Option:** **Function:**

[1] 1.5 kHz

#### 14-03 Overmodulation

**Option:** **Function:**

[0] Off

[1] \* On Select *On* [1] to connect the overmodulation function for the output voltage, to obtain an output voltage up to 15% greater than the mains voltage.  
Select *Off* [0] for no overmodulation of the output voltage, in order to avoid torque ripple on the motor shaft.  
This feature may be useful for applications such as grinding machines.

#### 14-04 PWM Random

**Option:** **Function:**

[0] \* Off

[1] On Select *On* [1] to transform the acoustic motor switching noise from a clear ringing tone to a less noticeable 'white' noise. This is achieved by slightly and randomly altering the synchronism of the pulse width modulated output phases.  
Select *Off* [0] for no change of the acoustic motor switching noise.

### 2.15.3. 14-1\* Mains On/Off

Parameters for configuring mains failure monitoring and handling. If a mains failure appears, the frequency converter will try to continue in a controlled way until the power in the DC link has been exhausted.

#### 14-10 Mains Failure

**Option:** **Function:**

[0] \* No function

[1] Controlled ramp-down

[2] Controlled ramp-down,  
trip

[3] Coasting

[4] Kinetic back-up

[5] Kinetic back-up, trip

[6] Alarm Function: Select the function to which the frequency converter must act when the threshold in par 14-11 has been reached.



Par 14-10 cannot be changed while motor is running.

*Controlled ramp down:*

The frequency converter will perform a controlled ramp down. If Par 2-10 is [0] or AC brake [2] Off the ramp will follow the Over Voltage Ramping. If Par 2-10 is [1] *Resistor Brake* the ramp will follow the setting in par 3-81 Quick Stop Ramp Time.

*Controlled ramp-down [1]:*

After power-up the frequency converter is ready for start. Controlled ramp-down and trip [2]: After power-up the frequency converter needs a reset for starting.





1. The power is back before the energy from DC /moment of inertia from load is too low. The frequency converter will perform a controlled ramp down when par 14-11 level has been reached.
2. The frequency converter will perform a controlled ramp down as long as energy in the DC link is present. After this point the motor will be coasted.

**Kinetic back-up:**

The frequency converter will perform a Kinetic back-up. If par. 2-10 is [0] or AC brake [2] *Off*, the ramp will follow the Over Voltage Ramping. If par. 2-10 is [1] *Resistor Brake* the ramp will follow the setting in par. 3-81 *Quick stop ramp time*.

Kinetic Back-up [4]: The frequency converter will keep on running as long as there is energy in the system due to the moment of inertia produced by the load.

Kinetic Back-up [5]: The frequency converter will ride through on speed as long as the energy is present from moment of inertia from the load. If the DC voltage goes below par. 14-11 the frequency converter will perform a trip.



**14-11 Mains Voltage at Mains Fault**

**Range:** 342 V\* [150 - 600 V]      **Function:** This parameter defines the threshold voltage at which the selected function in par. 14-10 should be activated.

**14-12 Function at Mains Imbalance**

**Option:** [0] \* Trip      **Function:**

[1] Warning

[2] Disabled

When a severe mains imbalance is detected:  
 Select *Trip* [0] to trip the frequency converter;  
 Select *Warning* [1] to issue a warning; or  
 Select *Disabled* [2] for no action.

Operation under severe main imbalance conditions reduces the lifetime of the motor. Conditions are considered severe if the motor is operated continuously near nominal load (e.g. a pump or fan running near full speed).

**2.15.4. Trip Reset, 14-2\***


Parameters for configuring auto reset handling, special trip handling and control card self test or initialisation.





**14-20 Reset Mode**

Select the reset function after tripping. Once reset, the frequency converter can be restarted.

[0] *	Manual reset	Select <i>Manual reset</i> [0], to perform a reset via [RESET] or via the digital inputs.
[1]	Automatic reset x 1	Select <i>Automatic reset x 1...x20</i> [1]-[12] to perform between one and twenty automatic resets after tripping.
[2]	Automatic reset x 2	
[3]	Automatic reset x 3	
[4]	Automatic reset x 4	
[5]	Automatic reset x 5	
[6]	Automatic reset x 6	
[7]	Automatic reset x 7	
[8]	Automatic reset x 8	
[9]	Automatic reset x 9	
[10]	Automatic reset x 10	
[11]	Automatic reset x 15	
[12]	Automatic reset x 20	
[13]	Infinite Automatic Re- set	Select <i>Infinite Automatic Reset</i> [13] for continuous resetting after tripping.

 **NB!**  
The motor may start without warning. If the specified number of AUTOMATIC RESETS is reached within 10 minutes, the frequency converter enters Manual reset [0] mode. After the Manual reset is performed, the setting of par. 14-20 reverts to the original selection. If the number of automatic resets is not reached within 10 minutes, or when a Manual reset is performed, the internal AUTOMATIC RESET counter returns to zero.

 **NB!**  
Automatic reset will also be active for resetting safe stop function in firmware version < 4.3x.

 **NB!**  
The setting in par. 14-20 is disregarded in case of Fire Mode being active (see par. 24-0\*, Fire Mode).

**14-21 Automatic Restart Time**

<b>Range:</b>	<b>Function:</b>
10s* [0 - 600 s]	Enter the time interval from trip to start of the automatic reset function. This parameter is active when par. 14-20 is set to <i>Automatic reset</i> [1] - [13].

**14-22 Operation Mode**

<b>Option:</b>	<b>Function:</b>
[0] * Normal operation	
[1] Control card test	
[2] Initialisation	Use this parameter to specify normal operation; to perform tests; or to initialise all parameters except par. 15-03, 15-04 and 15-05. This function is active only when the power is cycled to the frequency converter. Select <i>Normal operation</i> [0] for normal operation of the frequency converter with the motor in the selected application. Select <i>Control card test</i> [1] to test the analog and digital inputs and outputs and the +10 V control voltage. The test requires a test connector with internal connections. Use the following procedure for the control card test: 1. Select <i>Control card test</i> [1].

2. Disconnect the mains supply and wait for the light in the display to go out.
3. Set switches S201 (A53) and S202 (A54) = 'ON' / I.
4. Insert the test plug (see below).
5. Connect to mains supply.
6. Carry out various tests.
7. The results are displayed on the LCP and the frequency converter moves into an infinite loop.
8. Par. 14-22 is automatically set to Normal operation. Carry out a power cycle to start up in Normal operation after a control card test.

If the test is OK:


LCP read-out: Control Card OK.

Disconnect the mains supply and remove the test plug. The green LED on the Control Card will light up.

If the test fails:

LCP read-out: Control Card I/O failure.

Replace the frequency converter or Control card. The red LED on the Control Card is turned on. Test plugs (connect the following terminals to each other): 18 - 27 - 32; 19 - 29 - 33; 42 - 53 - 54



Select *Initialization* [2] to reset all parameter values to default settings, except for par. 15-03, 15-04, and 15-05. The frequency converter will reset during the next power-up. Par. 14-22 will also revert to the default setting *Normal operation* [0].

**14-25 Trip Delay at Torque Limit**

**Range:**

60 s\* [0 - 60 s]

**Function:**

Enter the torque limit trip delay in seconds. When the output torque reaches the torque limits (par. 4-16 and 4-17), a warning is triggered. When the torque limit warning has been continuously present for the period specified in this parameter, the frequency converter trips. Disable the trip delay by setting the parameter to 60 s = OFF. Thermal monitoring of the frequency converter will still remain active.

**14-26 Trip Delay at Inverter Fault**

**Range:**

Size related [0 - 30 s]

**Function:**

When the frequency converter detects an over-voltage in the set time trip will be effected after the set time. If value = 0, *protection mode* is disabled

**NB!**  
It is recommended to disable *protection mode* in hoisting applications.

#### 14-29 Service Code

<b>Range:</b>	<b>Function:</b>
000000 [000000 Hex - FFFFF]	For internal service only.

### 2.15.5. 14-3\* Current Limit Control

The frequency converter features an integral Current Limit Controller which is activated when the motor current, and thus the torque, is higher than the torque limits set in par. 4-16 and 4-17.

When the current limit is reached during motor operation or regenerative operation, the frequency converter will try to reduce torque below the preset torque limits as quickly as possible without losing control of the motor.

While the current control is active, the frequency converter can only be stopped by setting a digital input to *Coast inverse* [2] or *Coast and reset inv.* [3]. Any signal on terminals 18 to 33 will not be active until the frequency converter is no longer near the current limit.

By using a digital input set to *Coast inverse* [2] or *Coast and reset inv.* [3], the motor does not use the ramp-down time, since the frequency converter is coasted. If a quick stop is necessary, use the mechanical brake control function along with an external electro-mechanical brake attached to the application.

#### 14-30 Current Lim Cont, Proportional Gain

<b>Range:</b>	<b>Function:</b>
100 %* [0 - 500 %]	Enter the proportional gain value for the current limit controller. Selection of a high value makes the controller react faster. Too high a setting leads to controller instability.

#### 14-31 Current Lim Contr, Integration Time

<b>Range:</b>	<b>Function:</b>
0.020 s* [0.002 - 2.000 s]	Controls the current limit control integration time. Setting it to a lower value makes it react faster. A setting too low leads to control instability.

### 2.15.6. 14-4\* Energy Optimising

Parameters for adjusting the energy optimisation level in both Variable Torque (VT) and Automatic Energy Optimization (AEO) mode in par. 1-03.

#### 14-40 VT Level

<b>Range:</b>	<b>Function:</b>
66%* [40 - 90%]	Enter the level of motor magnetisation at low speed. Selection of a low value reduces energy loss in the motor, but also reduces load capability. This parameter cannot be adjusted while the motor is running.

#### 14-41 AEO Minimum Magnetisation

<b>Range:</b>	<b>Function:</b>
40%* [40 - 75%]	Enter the minimum allowable magnetisation for AEO. Selection of a low value reduces energy loss in the motor, but can also reduce resistance to sudden load changes.

#### 14-42 Minimum AEO Frequency

<b>Range:</b>	<b>Function:</b>
10Hz* [5 - 40 Hz]	Enter the minimum frequency at which the Automatic Energy Optimisation (AEO) is to be active.

#### 14-43 Motor Cosphi

<b>Range:</b>	<b>Function:</b>
0.66* [0.40 - 0.95]	The Cos(phi) setpoint is automatically set for optimum AEO performance. This parameter should normally not be altered. However in some situations it may be necessary to enter a new value to fine-tune.

### 2.15.7. Environment, 14-5\*

These parameters help the frequency converter to operate under special environmental conditions.

#### 14-50 RFI 1

**Option:**

[0] Off

**Function:**

Select *Off* [0] only if the frequency converter is fed by an isolated mains source, i.e. from a special IT mains source.

In this mode, the internal RFI filter capacitors between chassis and the mains RFI filter circuit are cut-out to avoid damage of the intermediate circuit and to reduce the ground capacity currents according to IEC 61800-3.

[1] \* On

Select *On* [1] to ensure that the frequency converter complies with EMC standards.

#### 14-52 Fan Control

**Option:**

[0] \* Auto

**Function:**

[1] On 50%

[2] On 75%

[3] On 100%

Select minimum speed of the main fan.

Select *Auto* [0] to run fan only when internal temperature in frequency converter is in range 35° C to approx. 55° C.

Fan runs at low speed below 35° C, and at full speed at approx. 55° C.

#### 14-53 Fan Monitor

Select which reaction the frequency converter should take in case a fan fault is detected.

[0] Disabled

[1] \* Warning

[2] Trip

#### 14-55 Output Filter

Select the type of output filter connected. This parameter cannot be adjusted while motor is running.

[0] \* No filter

[1] Sine-Wave Filter

#### 14-56 Capacitance Output Filter

**Range:**

2.0  $\mu\text{F}$ \* [0.1 - 6500.0  $\mu\text{F}$ ]

**Function:**

Set the capacitance of the output filter. The value can be found on the filter label.


**NB!**

This is required for correct compensation in Flux mode (par. 1-01)

#### 14-57 Inductance Output Filter

**Range:**

7.000 mH\* [0.001 - 65.000 mH]

**Function:**

Set the inductance of the output filter. The value can be found on the filter label.


**NB!**

This is required for correct compensation in Flux mode (par. 1-01)

### 2.15.8. 14-7\* Compatibility

This parameter is for setting of compatibility for VLT 3000, VLT 5000 to FC 300

#### 14-72 VLT Alarm Word

**Range:**

0\* [0 - 4294967295]

**Function:**

Read out the alarm word corresponding to VLT 3000 or VLT 5000

#### 14-73 VLT Warning Word

**Range:**

0\* [0 - 4294967295]

**Function:**

Read out the warning word corresponding to VLT 3000 or VLT 5000

#### 14-74 VLT Ext. Status Word

**Range:**

0\* [0 - 4294967295]

**Function:**

Read out the ext. status word corresponding to VLT 3000 or VLT 5000

## 2.16. Parameters: Drive Information

### 2.16.1. 15-\*\* Drive Information

Parameter group containing frequency converter information such as operating data, hardware configuration and software versions.

### 2.16.2. 15-0\* Operating Data

Parameter group containing operating data e.g. Operating Hours, kWh counters, Power Ups, etc.

#### 15-00 Operating Hours

**Range:**

0h\* [0 - 2147483647 h]

**Function:**

View how many hours the frequency converter has run. The value is saved when the frequency converter is turned off.

#### 15-01 Running Hours

**Range:**

0h\* [0 - 2147483647 h]

**Function:**

View how many hours the motor has run. Reset the counter in par. 15-07. The value is saved when the frequency converter is turned off.

#### 15-02 kWh Counter

**Range:**

0kWh\* [0 - 2147483647 kWh]

**Function:**

Registering the power consumption of the motor as a mean value over one hour. Reset the counter in par. 15-06.

#### 15-03 Power Up's

**Range:**

0\* [0 - 2147483647]

**Function:**

View the number of times the frequency converter has been powered up.

#### 15-04 Over Temp's

**Range:**

0\* [0 - 65535]

**Function:**

View the number of frequency converter temperature faults which have occurred.

#### 15-05 Over Volt's

**Range:**

0\* [0 - 65535]

**Function:**

View the number of frequency converter overvoltages which have occurred.

#### 15-06 Reset kWh Counter

**Option:**

[0]\* Do not reset

**Function:**

Select *Do not reset* [0] if no reset of the kWh counter is desired.

[1] Reset counter

Select *Reset* [1] and press [OK] to reset the kWh counter to zero (see par 15-02).



**NB!**

The reset is carried out by pressing [OK].

**15-07 Reset Running Hours Counter**

**Option:**

**Function:**

[0] \* Do not reset

[1] Reset counter Select *Reset* [1] and press [OK] to reset the Running Hours counter to zero (see par. 15-01). This parameter cannot be selected via the serial port, RS 485.  
Select *Do not reset* [0] if no reset of the Running Hours counter is desired.

**2.16.3. Data Log Settings, 15-1 \***

The Data Log enables continuous logging of up to 4 data sources (par. 15-10) at individual rates (par. 15-11). A trigger event (par. 15-12) and window (par. 15-14) are used to start and stop the logging conditionally.

**15-10 Logging Source**

Array [4]

None

14-72 VLT Alarm Word

14-73 VLT Warning Word

14-74 VLT Ext. Status Word

[16-00 Control Word]

16-01 Reference [Unit]

16-02 Reference %

16-03 Status Word

16-10 Power [kW]

16-11 Power [hp]

16-12 Motor Voltage

16-13 Frequency

16-14 Motor Current

16-16 Torque

16-17 Speed [RPM]

16-18 Motor Thermal

16-30 DC Link Voltage

16-32 Brake Energy / s

16-33 Brake Energy / 2 min

16-34 Heatsink Temp.

16-35 Inverter Thermal

16-50 External Reference

16-51 Pulse Reference

16-52 Feedback [Unit]

16-54 Feedback 1 [Unit]

16-55 Feedback 2 [Unit]

16-56 Feedback 3  
[Unit]

16-60 Digital Input

16-62 Analog Input 53

16-64 Analog Input 54

16-65 Analog Output  
42 [mA]

16-66 Digital Output  
[bin]

16-75 Analog In  
X30/11

16-76 Analog In  
X30/12

16-77 Analog Out  
X30/8 [mA]

16-90 Alarm Word

16-92 Warning Word

16-94 Extended Status  
Word

34-70 MCO Alarm Word  
1

34-71 MCO Alarm Word Select which variables are to be logged.  
2

### 15-11 Logging Interval

**Range:**

1ms\* [1 - 86400000 ms]

**Function:**

Enter the interval in milliseconds between each sampling of the variables to be logged.

### 15-12 Trigger Event

**Option:**

[0] \* False

[1] True

[2] Running

[3] In range

[4] On reference

[5] Torque limit

[6] Current limit

[7] Out of current range

[8] Below I low

[9] Above I high

[10] Out of speed range

[11] Below speed low

[12] Above speed high

[13] Out of feedb. range

[14] Below feedb. low

[15] Above feedb. high

[16] Thermal warning

[17] Mains voltage out of  
range



[18]	Reversing	
[19]	Warning	
[20]	Alarm (trip)	
[21]	Alarm (trip lock)	
[22]	Comparator 0	
[23]	Comparator 1	
[24]	Comparator 2	
[25]	Comparator 3	
[26]	Logic rule 0	
[27]	Logic rule 1	
[28]	Logic rule 2	
[29]	Logic rule 3	
[33]	Digital input DI18	
[34]	Digital input DI19	
[35]	Digital input DI27	
[36]	Digital input DI29 (FC 302 only)	
[37]	Digital input DI32	
[38]	Digital input DI33	
[50]	Comparator 4	
[51]	Comparator 5	
[60]	Logic rule 4	
[61]	Logic rule 5	Select the trigger event. When the trigger event occurs, a window is applied to freeze the log. The log will then retain a specified percentage of samples before the occurrence of the trigger event (par. 15-14).

**15-13 Logging Mode**

Option:	Function:
[0] *      Log always	Select <i>Log always</i> [0] for continuous logging.
[1]      Log once on trigger	Select <i>Log once on trigger</i> [1] to conditionally start and stop logging using par. 15-12 and par. 15-14.

**15-14 Samples Before Trigger**

Range:	Function:
50*    [0 - 100]	Enter the percentage of all samples prior to a trigger event which are to be retained in the log. See also par. 15-12 and par. 15-13.

**2.16.4. Historic Log,15-2\***

View up to 50 logged data items via the array parameters in this parameter group. For all parameters in the group, [0] is the most recent data and [49] the oldest data. Data is logged every time an *event* occurs (not to be confused with SLC events). *Events* in this context are defined as a change in one of the following areas:

1. Digital input
2. Digital outputs (not monitored in this SW release)
3. Warning word
4. Alarm word
5. Status word
6. Control word
7. Extended status word

*Events* are logged with value, and time stamp in msec. The time interval between two events depends on how often *events* occur (maximum once every scan time). Data logging is continuous but if an alarm occurs, the log is saved and the values can be viewed on the display. This feature is useful, for example when carrying out service following a trip. View the historic log contained in this parameter via the serial communication port or via the display.

### 15-20 Historic Log: Event

Array [50]

0\* [0 - 255] View the event type of the logged events.

### 15-21 Historic Log: Value

Array [50]

0\* [0 - 2147483647] View the value of the logged event. Interpret the event values according to this table:

Digital input	Decimal value. See par. 16-60 for description after converting to binary value.
Digital output (not monitored in this SW release)	Decimal value. See par. 16-66 for description after converting to binary value.
Warning word	Decimal value. See par. 16-92 for description.
Alarm word	Decimal value. See par. 16-90 for description.
Status word	Decimal value. See par. 16-03 for description after converting to binary value.
Control word	Decimal value. See par. 16-00 for description.
Extended status word	Decimal value. See par. 16-94 for description.

### 15-22 Historic Log: Time

Array [50]

0\* [0 - 2147483647] View the time at which the logged event occurred. Time is measured in ms since frequency converter start. The max. value corresponds to approx. 24 days which means that the count will restart at zero after this time period.

## 2.16.5. Alarm Log, 15-3\*

Parameters in this group are array parameters, where up to 10 fault logs can be viewed. [0] is the most recent logged data, and [9] the oldest. Error codes, values, and time stamp can be viewed for all logged data.

### 15-30 Fault Log: Error Code

Array [10]

0\* [0 - 255] View the error code and look up its meaning in the *Troubleshooting* chapter of the FC 300 Design Guide.

### 15-31 Alarm Log: Value

Array [10]

0\* [-32767 - 32767] View an extra description of the error. This parameter is mostly used in combination with alarm 38 'internal fault'.

### 15-32 Alarm Log: Time

Array [10]

0\* [0 - 2147483647]

View the time when the logged event occurred. Time is measured in seconds from frequency converter start-up.

### 2.16.6. Drive Identification, 15-4\*

Parameters containing read only information about the hardware and software configuration of the frequency converter.

#### 15-40 FC Type

**Option:****Function:**

View the FC type. The read-out is identical to the FC 300 Series power field of the type code definition, characters 1-6.

#### 15-41 Power Section

**Option:****Function:**

View the FC type. The read-out is identical to the FC 300 Series power field of the type code definition, characters 7-10.

#### 15-42 Voltage

**Option:****Function:**

View the FC type. The read-out is identical to the FC 300 Series power field of the type code definition, characters 11-12.

#### 15-43 Software Version

**Option:****Function:**

View the combined SW version (or 'package version') consisting of power SW and control SW.

#### 15-44 Ordered Typecode String

**Option:****Function:**

View the type code string used for re-ordering the frequency converter in its original configuration.

#### 15-45 Actual Typecode String

**Option:****Function:**

View the actual type code string.

#### 15-46 Frequency Converter Ordering No

**Option:****Function:**

View the 8-digit ordering number used for re-ordering the frequency converter in its original configuration.

#### 15-47 Power Card Ordering No

**Option:****Function:**

View the power card ordering number.

#### 15-48 LCP Id No

**Option:****Function:**

View the LCP ID number.

#### 15-49 SW ID Control Card

**Option:****Function:**

View the control card software version number.

### 15-50 SW ID Power Card

**Option:**                                      **Function:**  
View the power card software version number.

### 15-51 Frequency Converter Serial Number

**Option:**                                      **Function:**  
View the frequency converter serial number.

### 15-53 Power Card Serial Number

**Option:**                                      **Function:**  
View the power card serial number.

## 2.16.7. Option Ident. 15-6\*

This read-only parameter group contains information about the hardware and software configuration of the options installed in slots A, B C0 and C1.

### 15-60 Option Mounted

**Option:**                                      **Function:**  
View the installed option type.

### 15-61 Option SW Version

**Option:**                                      **Function:**  
View the installed option software version.

### 15-62 Option Ordering No

**Option:**                                      **Function:**  
Shows the ordering number for the installed options.

### 15-63 Option Serial No

**Option:**                                      **Function:**  
View the installed option serial number.

## 2.16.8. Parameter Info, 15-9\*

Parameter lists

### 15-92 Defined Parameters

Array [1000]

0\* [0 - 9999]                                      View a list of all defined parameters in the frequency converter. The list ends with 0.

### 15-93 Modified Parameters

Array [1000]

0\* [0 - 9999]

View a list of the parameters that have been changed from their default setting. The list ends with 0. Changes may not be visible until up to 30 seconds after implementation.

### 15-99 Parameter Metadata

Array [30]

0\* [0 - 9999]

This parameter contains data used by the MCT10 software tool.

2

## 2.17. Parameters: Data Read-outs

### 2.17.1. 16-\*\* Data Readouts

Parameter group for data read-outs, e.g. actual references, voltages, control, alarm, warning and status words.

### 2.17.2. 16-0\* General Status

Parameters for reading the general status, e.g. the calculated reference, the active control word, status.

#### 16-00 Control Word

**Range:**

0\* [0 - FFFF]

**Function:**

View the Control word sent from the frequency converter via the serial communication port in hex code.

#### 16-01 Reference [Unit]

**Range:**

0.000\* [-999999.000 - 999999.000]

**Function:**

View the present reference value applied on impulse or analog basis in the unit resulting from the configuration selected in par. 1-00 (Hz, Nm or RPM).

#### 16-02 Reference %

**Range:**

0%\* [-200 to 200 %]

**Function:**

View the total reference. The total reference is the sum of digital, analog, preset, bus, and freeze references, plus catch-up and slow-down.

#### 16-03 Status Word

**Range:**

0\* [0 - FFFF]

**Function:**

View the Status word sent from the frequency converter via the serial communication port in hex code.

#### 16-05 Main Actual Value [%]

**Range:**

0%\* [-100 to +100%]

**Function:**

View the two-byte word sent with the Status word to the bus Master reporting the Main Actual Value.

#### 16-09 Custom Readout

**Range:**

0.00 unit\* [x.xx - x.xx unit]

**Function:**

View the value of custom readout from par. 0-30 to par. 0-32

### 2.17.3. 16-1\* Motor Status

Parameters for reading the motor status values.

**16-10 Power [kW]****Range:**

0.0kW\* [0.0 - 1000.0 kW]

**Function:**

View the motor power in kW. The value shown is calculated on the basis of the actual motor voltage and motor current. The value is filtered, and therefore approx. 30 ms may pass from when an input value changes to when the data read-out values change.

**16-11 Power [HP]****Range:**

0 HP\* [0 to 1000 HP]

**Function:**

View the motor power in HP. The value shown is calculated on the basis of the actual motor voltage and motor current. The value is filtered, and therefore approximately 30 ms may pass from when an input value changes to when the data read-out values change.

**16-12 Motor Voltage****Range:**

0.0V\* [0.0 - 6000.0 V]

**Function:**

View the motor voltage, a calculated value used for controlling the motor.

**16-13 Motor Frequency****Range:**

0.0Hz\* [0.0 - 6500.0 Hz]

**Function:**

View the motor frequency, without resonance dampening.

**16-14 Motor Current****Range:**

0 A\* [0 to 1856 A]

**Function:**

View the motor current measured as a mean value, IRMS. The value is filtered, and thus approximately 30 ms may pass from when an input value changes to when the data read-out values change.

**16-15 Frequency [%]****Range:**

0.00%\* [0.00 - 0.00 %]

**Function:**

View a two-byte word reporting the actual motor frequency (without resonance dampening) as a percentage (scale 0000-4000 Hex) of par. 4-19 *Max. Output Frequency*. Set par. 9-16 index 1 to send it with the Status Word instead of the MAV.

**16-16 Torque****Range:**

0.0Nm\* [-3000.0 - 3000.0 Nm]

**Function:**

View the torque value with sign, applied to the motor shaft. Linearity is not exact between 160% motor current and torque in relation to the rated torque. Some motors supply more than 160% torque. Consequently, the min. value and the max. value will depend on the max. motor current as well as the motor used. The value is filtered, and thus approx. 30 ms may pass from when an input changes value to when the data read-out values change.

**16-17 Speed [RPM]****Range:**

0 RPM\* [0 - 0 RPM]

**Function:**

View the actual motor RPM. In open loop or closed loop process control the motor RPM is estimated. In speed closed loop modes the motor RPM is measured.

**16-18 Motor Thermal****Range:**

0 %\* [0 - 100 %]

**Function:**

View the calculated thermal load on the motor. The cut-out limit is 100%. The basis for calculation is the ETR function selected in par.1-90.

**16-19 KTY Sensor Temperature****Range:**

0°C\* [0 - xxx °C]

**Function:**

Returning the actual temperature on KTY sensor built into the motor.  
See par. 1-9\*.

### 16-20 Motor Angle

**Range:**

0\* [0 - 65535]

**Function:**View the current encoder/resolver angle offset relative to the index position. The value range of 0-65535 corresponds to  $0-2\pi$  (radians).

### 16-22 Torque [%]

**Range:**

0%\* [-200 - 200%]

**Function:**

Value shown is the torque in percent of nominal torque, with sign, applied to the motor shaft.

## 2.17.4. 16-3\* Drive Status

Parameters for reporting the status of the frequency converter.

### 16-30 DC Link Voltage

**Range:**

0V\* [0 - 10000 V]

**Function:**

View a measured value. The value is filtered with an 30 ms time constant.

### 16-32 Brake Energy /s

**Range:**

0 kW\* [0 to 675.000 kW]

**Function:**

View the brake power transmitted to an external brake resistor, stated as an instantaneous value.

### 16-33 Brake Energy /2 min

**Range:**

0.000kW\* [0.000 - 500.000 kW]

**Function:**

View the brake power transmitted to an external brake resistor. The mean power is calculated on an average basis for the most recent 120 seconds.

### 16-34 Heatsink Temp.

**Range:**

0°C\* [0 - 255 °C]

**Function:**View the frequency converter heatsink temperature. The cut-out limit is  $90 \pm 5$  °C, and the motor cuts back in at  $60 \pm 5$  °C.

### 16-35 Inverter Thermal

**Range:**

0 %\* [0 - 0 %]

**Function:**

View the percentage load on the inverter.

### 16-36 Inv. Nom. Current

**Range:**

A\* [0.01 - 10000.00 A]

**Function:**

View the inverter nominal current, which should match the nameplate data on the connected motor. The data are used for calculation of torque, motor protection, etc.

### 16-37 Inv. Max. Current

**Range:**

A\* [0.01 - 10000.00 A]

**Function:**

View the inverter maximum current, which should match the nameplate data on the connected motor. The data are used for calculation of torque, motor protection, etc.

### 16-38 SL Controller State

**Range:**

0\* [0 - 100]

**Function:**

View the state of the event under execution by the SL controller.

### 16-39 Control Card Temp.

**Range:**

0°C\* [0 - 100 °C]

**Function:**

View the temperature on the control card, stated in °C.

**16-40 Logging Buffer Full**

View whether the logging buffer is full (see par. 15-1\*). The logging buffer will never be full when *par. 15-13 Logging Mode* is set to *Log always* [0].

[0] *	No
[1]	Yes

**2.17.5. 16-5\* Ref. & Feedb.**

Parameters for reporting the reference and feedback input.

**16-50 External Reference**

<b>Range:</b>	<b>Function:</b>
0.0* [-200.0 - 200.0]	View the total reference, the sum of digital, analog, preset, bus and freeze references, plus catch-up and slow-down.

**16-51 Pulse Reference**

<b>Range:</b>	<b>Function:</b>
0.0* [-200 - 200]	View the reference value from programmed digital input(s). The read-out can also reflect the impulses from an incremental encoder.

**16-52 Feedback [Unit]**

<b>Range:</b>	<b>Function:</b>
0.0* [-999999.999 - 999999.999]	View the feedback unit resulting from the selection of unit and scaling in par. 3-00, 3-01, 3-02 and 3-03.

**16-53 Digi Pot Reference**

<b>Range:</b>	<b>Function:</b>
0.0* [-200 - 200]	View the contribution of the Digital Potentiometer to the actual reference.

**2.17.6. 16-6\* Inputs and Outputs**

Parameters for reporting the digital and analog IO ports.

**16-60 Digital Input**

<b>Range:</b>	<b>Function:</b>
0* [0 - 63]	View the signal states from the active digital inputs. Example: Input 18 corresponds to bit no. 5, '0' = no signal, '1' = connected signal. Bit 6 works in the opposite way, on = '0', off = '1' (safe stop input).

Bit 0	Digital input term. 33
Bit 1	Digital input term. 32
Bit 2	Digital input term. 29
Bit 3	Digital input term. 27
Bit 4	Digital input term. 19
Bit 5	Digital input term. 18
Bit 6	Digital input term. 37
Bit 7	Digital input GP I/O term. X30/4
Bit 8	Digital input GP I/O term. X30/3
Bit 9	Digital input GP I/O term. X30/2
Bit 10-63	Reserved for future terminals

**16-61 Terminal 53 Switch Setting**

View the setting of input terminal 53. Current = 0; Voltage = 1.

[0] *	Current
-------	---------



[1] Voltage

**16-62 Analog Input 53**

**Range:** 0.000\* [-20.000 - 20.000] **Function:** View the actual value at input 53.

**16-63 Terminal 54 Switch Setting**

View the setting of input terminal 54. Current = 0; Voltage = 1.

[0] \* Current

[1] Voltage

**16-64 Analog Input 54**

**Range:** 0.000\* [-20.000 - 20.000] **Function:** View the actual value at input 54.

**16-65 Analog Output 42 [mA]**

**Range:** 0.000\* [0.000 - 30.000] **Function:** View the actual value at output 42 in mA. The value shown reflects the selection in par. 06-50.

**16-66 Digital Output [bin]**

**Range:** 0\* [0 - 115] **Function:** View the binary value of all digital outputs.

**16-67 Freq. Input 29 [Hz]**

**Range:** 0\* [0 - 0] **Function:** View the actual frequency rate on terminal 29.

**16-68 Freq. Input #33 [Hz]**

**Range:** 0\* [0 - 130000] **Function:** View the actual value of the frequency applied at terminal 33 as an impulse input.

**16-69 Pulse Output #27 [Hz]**


**Range:** 0\* [0 - 40000] **Function:** View the actual value of pulses applied to terminal 27 in digital output mode.

**16-70 Pulse Output #29 [Hz]**

**Range:** 0\* [0 - 40000] **Function:** View the actual value of pulses at terminal 29 in digital output mode. This parameter is available for FC 302 only.

**16-71 Relay Output [bin]**

**Range:** 0\* [0 - 31] **Function:** View the settings of all relays.



### 16-72 Counter A

**Range:**

0\* [-2147483648 -2147483647]

**Function:**

View the present value of Counter A. Counters are useful as comparator operands, see par. 13-10. The value can be reset or changed either via digital inputs (parameter group 5-1\*) or by using an SLC action (par. 13-52).

### 16-73 Counter B

**Range:**

0\* [-2147483648 -2147483647]

**Function:**

View the present value of Counter B. Counters are useful as comparator operands (par. 13-10). The value can be reset or changed either via digital inputs (parameter group 5-1\*) or by using an SLC action (par. 13-52).

### 16-74 Precise Stop Counter

**Range:**

0\* [0 - 2147483647]

**Function:**

Returns the actual counter value of precise counter (par. 1-84).

### 16-75 Analog In X30/11

**Range:**

0.000\* [0.000 - 0.000]

**Function:**

View the actual value at input X30/11 of MCB 101.

### 16-76 Analog In X30/12

**Range:**

0.000\* [0.000 - 0.000]

**Function:**

View the actual value at input X30/12 of MCB 101.

### 16-77 Analog Out X30/8 16-77 [mA]

**Range:**

0.000\* [0.000 - 0.000]

**Function:**

View the actual value at input X30/8 in mA.

## 2.17.7. 16-8\* Fieldbus & FC Port

Parameters for reporting the BUS references and control words.

### 16-80 Fieldbus CTW 1

**Range:**

0\* [0 - 65535]

**Function:**

View the two-byte Control word (CTW) received from the Bus-Master. Interpretation of the Control word depends on the fieldbus option installed and the Control word profile selected in par. 8-10. For more information please refer to the relevant fieldbus manual.

### 16-82 Fieldbus REF 1

**Range:**

0\* [-200 - 200]

**Function:**

View the two-byte word sent with the control word from the Bus-Master to set the reference value. For more information please refer to the relevant fieldbus manual.

### 16-84 Comm. Option STW

**Range:**

0\* [0 - 65535]

**Function:**

View the extended fieldbus comm. option status word. For more information please refer to the relevant fieldbus manual.

### 16-85 FC Port CTW 1

**Range:**

0\* [0 - 65535]

**Function:**

View the two-byte Control word (CTW) received from the Bus-Master. Interpretation of the control word depends on the fieldbus option installed and the Control word profile selected in par. 8-10.

**16-86 FC Port REF 1****Range:**

0\* [0 - 0]

**Function:**

View the two-byte Status word (STW) sent to the Bus-Master. Interpretation of the Status word depends on the fieldbus option installed and the Control word profile selected in par. 8-10.

**2.17.8. 16-9\* Diagnosis Read-Out**

Parameters displaying alarm, warning and extended status words.

**16-90 Alarm Word****Range:**

0\* [0 - FFFFFFFF]

**Function:**

View the alarm word sent via the serial communication port in hex code.

**16-90 Alarm Word 2****Range:**

0\* [0 - FFFFFFFF]

**Function:**

View the alarm word sent via the serial communication port in hex code.

**16-92 Warning Word****Range:**

0\* [0 - FFFFFFFF]

**Function:**

View the warning word sent via the serial communication port in hex code.

**16-93 Warning Word 2****Range:**

0\* [0 - FFFF]

**Function:**

View the warning word sent via the serial communication port in hex code.

**16-94 Ext. Status Word****Range:**

0\* [0 - FFFF]

**Function:**

Returns the extended warning word sent via the serial communication port in hex code.

## 2.18. Parameters: Encoder Input

### 2.18.1. 17-\*\* Motor Feedb. Option

Additional parameters to configure the Encoder (MCB102) or the Resolver (MCB103) Feedback Option.

### 2.18.2. 17-1\* Inc. Enc. Interface

Parameters in this group configure the incremental interface of the MCB102 option. Note that both the incremental and absolute interfaces are active at the same time.

#### 17-10 Signal Type

Option:	Function:
[0]	None
[1] *	RS422 (5V TTL/linedrv.)
[2]	Sinusoidal 1Vpp Select the incremental type (A/B channel) of the encoder in use. Find the information on the encoder data sheet. Select <i>None</i> [0] if the feedback sensor is an absolute encoder only. This parameter cannot be adjusted while the motor is running.

#### 17-11 Resolution (PPR)

Range:	Function:
1024* [10 - 10000]	Enter the resolution of the incremental track, i.e. the number of pulses or periods per revolution. This parameter cannot be adjusted while the motor is running.

### 2.18.3. 17-2\* Abs. Enc. Interface

Parameters in this group configure the absolute interface of the MCB102 option. Note that both the incremental and absolute interfaces are active at the same time.

#### 17-20 Protocol Selection

Option:	Function:
[0] *	None
[1]	HIPERFACE
[2]	EnDat
[4]	SSI Select <i>HIPERFACE</i> [1] if the encoder is absolute only. Select <i>None</i> [0] if the feedback sensor is an incremental encoder only. This parameter cannot be adjusted while the motor is running.

#### 17-21 Resolution (Positions/Rev)

Option:	Function:
[512]	512
[1024]	1024
[2048]	2048
[4096]	4096
[8192]	SSI 4 - 8192
[16384]	16384
[32768]	HIPERFACE 512 - 32768 Select the resolution of the absolute encoder, i.e. the number of counts per revolution. This parameter cannot be adjusted while the motor is running. The value depends on setting in par. 17-20.

### 17-24 SSI Data Length

**Range:**

13\* [13 - 25]

**Function:**

Set the number of bits for the SSI telegram. Choose 13 bits for single-turn encoders and 25 bits for multi-turn encoder.

### 17-25 Clock Rate

**Range:**

260kHz\* [100 - 260 kHz]

**Function:**

Set the SSI clock rate. With long encoder cables the clock rate must be reduced.

### 17-26 SSI Data Format

**Option:**

[0]\* Gray Code

**Function:**

[1] Binary Code

Set the data format of the SSI data. Choose between Gray or Binary format.

### 17-34 HIPERFACE Baudrate

**Option:**

[0] 600

[1] 1200

[2] 2400

[3] 4800

[4]\* 9600

[5] 19200

[6] 38400

**Function:**

Select the baud rate of the attached encoder.

This parameter cannot be adjusted while the motor is running. The parameter is only accessible when par. 17-20 is set to HIPERFACE [1].

## 2.18.4. 17-5\* Resolver Interface

Parameter group 17-5\* is used for setting parameters for the MCB 103 Resolver Option.

Usually the resolver feedback is used as motor feedback from Permanent Magnet motors with par. 1-01 set to Flux with motor feedback.

Resolver parameters cannot be adjusted while the motor is running.

### 17-50 Resolver Poles

**Range:**

2\* [2-2]

**Function:**

Set the number of poles on the resolver.

The value is stated in the data sheet for resolvers.

### 17-51 Resolver Input Voltage

**Range:**

7.0V\* [4.0 - 8.0 V]

**Function:**

Set the input voltage to the resolver. The voltage is stated as RMS value.

The value is stated in the data sheet for resolvers

### 17-52 Resolver Input Frequency

**Range:**

10.0kHz\* [2.0 - 15.0 kHz]

**Function:**

Set the input frequency to the resolver.

The value is stated in the data sheet for resolvers.

### 17-53 Resolver Transformation Ratio

**Range:**

0.5\* [0.1 - 1.1]

**Function:**

Set the transformation ratio for the resolver.

The transformation ration is:

$$T_{ratio} = \frac{V_{Out}}{V_{In}}$$

The value is stated in the data sheet for resolvers.

### 17-59 Resolver Interface

**Option:**
**Function:**

[0] \* Disabled

[1] Enabled

Activate the MCB 103 resolver option when the resolver parameters are selected.

To avoid damage to resolvers par. 17-50 – par. 17-53 must be adjusted before activating this parameter.

## 2.18.5. 17-6\* Monitoring and Application

This parameter group is for selecting additional functions when MCB 102 Encoder option or MCB 103 Resolver option is fitted into option slot B as speed feedback.

Monitoring and Application parameters cannot be adjusted while the motor is running.

### 17-60 Encoder Positive Direction

**Option:**
**Function:**

[0] \* Clockwise

[1] Counter clockwise

Change the detected encoder rotation direction without changing the wiring to the encoder.

This parameter cannot be adjusted while the motor is running.

### 17-61 Encoder Signal Monitoring

**Option:**
**Function:**

[0] Disabled

[1] \* Warning

[2] Trip

Select which reaction the frequency converter should take in case a faulty encoder signal is detected.

The encoder function in par. 17-61 is an electrical check of the hardware circuit in the encoder system.

## 2.19. Parameter Lists

### FC Series

All = valid for FC 301 and FC 302 series

01 = valid for FC 301 only

02 = valid for FC 302 only

### Changes during operation

"TRUE" means that the parameter can be changed while the frequency converter is in operation and "FALSE" means that the frequency converter must be stopped before a change can be made.

### 4-Set-up

'All set-ups': the parameter can be set individually in each of the four set-ups, i. e. one single parameter can have four different data values.

'1 set-up': data value will be the same in all set-ups.

### Conversion index

This number refers to a conversion figure used when writing or reading by means of a frequency converter.

<b>Conv. index</b>	100	67	6	5	4	3	2	1	0	-1	-2	-3	-4	-5	-6
<b>Conv. factor</b>	1	1/60	1000000	100000	10000	1000	100	10	1	0.1	0.01	0.001	0.0001	0.00001	0.000001

Data type	Description	Type
2	Integer 8	Int8
3	Integer 16	Int16
4	Integer 32	Int32
5	Unsigned 8	UInt8
6	Unsigned 16	UInt16
7	Unsigned 32	UInt32
9	Visible String	VisStr
33	Normalized value 2 bytes	N2
35	Bit sequence of 16 boolean variables	V2
54	Time difference w/o date	TimD

## 2.19.1. 0-.\* Operation/Display

Par. No. #	Parameter description	Default value	4-set-up	FC 302 only	Change during op- eration	Conver- sion index	Type
<b>0-0* Basic Settings</b>							
0-01	Language	[0] English	1 set-up		TRUE	-	Ujnt8
0-02	Motor Speed Unit	[0] RPM	2 set-ups		FALSE	-	Ujnt8
0-03	Regional Settings	[0] International	2 set-ups		FALSE	-	Ujnt8
0-04	Operating State at Power-up (Hand)	[1] Forced stop, ref=old	All set-ups		TRUE	-	Ujnt8
<b>0-1* Set-up Operations</b>							
0-10	Active Set-up	[1] Set-up 1	1 set-up		TRUE	-	Ujnt8
0-11	Edit Set-up	[1] Set-up 1	All set-ups		TRUE	-	Ujnt8
0-12	This Set-up Linked to	[0] Not linked	All set-ups		FALSE	-	Ujnt8
0-13	Readout: Linked Set-ups	0 N/A	All set-ups		FALSE	0	Ujnt16
0-14	Readout: Edit Set-ups / Channel	0 N/A	All set-ups		TRUE	0	Int32
<b>0-2* LCP Display</b>							
0-20	Display Line 1.1 Small	1617	All set-ups		TRUE	-	Ujnt16
0-21	Display Line 1.2 Small	1614	All set-ups		TRUE	-	Ujnt16
0-22	Display Line 1.3 Small	1610	All set-ups		TRUE	-	Ujnt16
0-23	Display Line 2 Large	1613	All set-ups		TRUE	-	Ujnt16
0-24	Display Line 3 Large	1602	All set-ups		TRUE	-	Ujnt16
0-25	My Personal Menu	ExpressionLimit	1 set-up		TRUE	0	Ujnt16
<b>0-3* LCP Custom Readout</b>							
0-30	Unit for User-defined Readout	[0] None	All set-ups		TRUE	-	Ujnt8
0-31	Min Value of User-defined Readout	0.00 CustomReadoutUnit	All set-ups		TRUE	-2	Int32
0-32	Max Value of User-defined Readout	100.00 CustomReadoutUnit	All set-ups		TRUE	-2	Int32
<b>0-4* LCP Keypad</b>							
0-40	[Hand on] Key on LCP	[1] Enabled	All set-ups		TRUE	-	Ujnt8
0-41	[Off] Key on LCP	[1] Enabled	All set-ups		TRUE	-	Ujnt8
0-42	[Auto on] Key on LCP	[1] Enabled	All set-ups		TRUE	-	Ujnt8
0-43	[Reset] Key on LCP	[1] Enabled	All set-ups		TRUE	-	Ujnt8
<b>0-5* Copy/Save</b>							
0-50	LCP Copy	[0] No copy	All set-ups		FALSE	-	Ujnt8
0-51	Set-up Copy	[0] No copy	All set-ups		FALSE	-	Ujnt8
<b>0-6* Password</b>							
0-60	Main Menu Password	100 N/A	1 set-up		TRUE	0	Int16
0-61	Access to Main Menu w/o Password	[0] Full access	1 set-up		TRUE	-	Ujnt8
0-65	Quick Menu Password	200 N/A	1 set-up		TRUE	0	Int16
0-66	Access to Quick Menu w/o Password	[0] Full access	1 set-up		TRUE	-	Ujnt8
0-67	Bus Password Access	0 N/A	All set-ups		TRUE	0	Ujnt16



**2.19.2. 1-\*\* Load/Motor**

Par. No. #	Parameter description	Default value	4-set-up	FC 302 only	Change during operation	Conversion index	Type
<b>1-0* General Settings</b>							
1-00	Configuration Mode	null	All set-ups		TRUE	-	Uint8
1-01	Motor Control Principle	null	All set-ups		FALSE	-	Uint8
1-02	Flux Motor Feedback Source	[1] 24V encoder	All set-ups	x	FALSE	-	Uint8
1-03	Torque Characteristics	[0] Constant torque	All set-ups		TRUE	-	Uint8
1-04	Overload Mode	[0] High torque	All set-ups		FALSE	-	Uint8
1-05	Local Mode Configuration	[2] As mode par 1-00	All set-ups		TRUE	-	Uint8
<b>1-1* Motor Selection</b>							
1-10	Motor Construction	[0] Asynchron	All set-ups		FALSE	-	Uint8
<b>1-2* Motor Data</b>							
1-20	Motor Power [kW]	ExpressionLimit	All set-ups		FALSE	1	Uint32
1-21	Motor Power [HP]	ExpressionLimit	All set-ups		FALSE	-2	Uint32
1-22	Motor Voltage	ExpressionLimit	All set-ups		FALSE	0	Uint16
1-23	Motor Frequency	ExpressionLimit	All set-ups		FALSE	0	Uint16
1-24	Motor Current	ExpressionLimit	All set-ups		FALSE	-2	Uint32
1-25	Motor Nominal Speed	ExpressionLimit	All set-ups		FALSE	67	Uint16
1-26	Motor Cont. Rated Torque	ExpressionLimit	All set-ups		FALSE	-1	Uint32
1-29	Automatic Motor Adaptation (AMA)	[0] Off	All set-ups		FALSE	-	Uint8
<b>1-3* Adv. Motor Data</b>							
1-30	Stator Resistance (Rs)	ExpressionLimit	All set-ups		FALSE	-4	Uint32
1-31	Rotor Resistance (Rr)	ExpressionLimit	All set-ups		FALSE	-4	Uint32
1-33	Stator Leakage Reactance (X1)	ExpressionLimit	All set-ups		FALSE	-4	Uint32
1-34	Rotor Leakage Reactance (X2)	ExpressionLimit	All set-ups		FALSE	-4	Uint32
1-35	Main Reactance (Xh)	ExpressionLimit	All set-ups		FALSE	-4	Uint32
1-36	Iron Loss Resistance (Rfe)	ExpressionLimit	All set-ups	x	FALSE	-3	Uint32
1-37	d-axis Inductance (Ld)	ExpressionLimit	All set-ups		FALSE	-4	Int32
1-39	Motor Poles	ExpressionLimit	All set-ups		FALSE	0	Uint8
1-40	Back EMF at 1000 RPM	ExpressionLimit	All set-ups	x	FALSE	0	Uint16
1-41	Motor Angle Offset	0 N/A	All set-ups		FALSE	0	Int16
<b>1-5* Load Indep. Setting</b>							
1-50	Motor Magnetisation at Zero Speed	100 %	All set-ups		TRUE	0	Uint16
1-51	Min Speed Normal Magnetising [RPM]	ExpressionLimit	All set-ups		TRUE	67	Uint16
1-52	Min Speed Normal Magnetising [Hz]	ExpressionLimit	All set-ups		TRUE	-1	Uint16
1-53	Model Shift Frequency	ExpressionLimit	All set-ups	x	FALSE	-1	Uint16
1-55	U/f Characteristic - U	ExpressionLimit	All set-ups		TRUE	-1	Uint16
1-56	U/f Characteristic - F	ExpressionLimit	All set-ups		TRUE	-1	Uint16

Par. No. #	Parameter description	Default value	4-set-up	FC 302 only	Change during operation	Conversion index	Type
<b>1-6* Load Depen. Setting</b>							
1-60	Low Speed Load Compensation	100 %	All set-ups		TRUE	0	Int16
1-61	High Speed Load Compensation	100 %	All set-ups		TRUE	0	Int16
1-62	Slip Compensation	ExpressionLimit	All set-ups		TRUE	0	Int16
1-63	Slip Compensation Time Constant	ExpressionLimit	All set-ups		TRUE	-2	Uint16
1-64	Resonance Dampening	100 %	All set-ups		TRUE	0	Uint16
1-65	Resonance Dampening Time Constant	5 ms	All set-ups		TRUE	-3	Uint8
1-66	Min. Current at Low Speed	100 %	All set-ups	x	TRUE	0	Uint8
1-67	Load Type	[0] Passive load	All set-ups	x	TRUE	-	Uint8
1-68	Minimum Inertia	ExpressionLimit	All set-ups	x	FALSE	-4	Uint32
1-69	Maximum Inertia	ExpressionLimit	All set-ups	x	FALSE	-4	Uint32
<b>1-7* Start Adjustments</b>							
1-71	Start Delay	0.0 s	All set-ups		TRUE	-1	Uint8
1-72	Start Function	[2] Coast/delay time	All set-ups		TRUE	-	Uint8
1-73	Flying Start	[0] Disabled	All set-ups		FALSE	-	Uint8
1-74	Start Speed [RPM]	ExpressionLimit	All set-ups		TRUE	67	Uint16
1-75	Start Speed [Hz]	ExpressionLimit	All set-ups		TRUE	-1	Uint16
1-76	Start Current	0.00 A	All set-ups		TRUE	-2	Uint32
<b>1-8* Stop Adjustments</b>							
1-80	Function at Stop	[0] Coast	All set-ups		TRUE	-	Uint8
1-81	Min Speed for Function at Stop [RPM]	ExpressionLimit	All set-ups		TRUE	67	Uint16
1-82	Min Speed for Function at Stop [Hz]	ExpressionLimit	All set-ups		TRUE	-1	Uint16
1-83	Precise Stop Function	[0] Precise ramp stop	All set-ups		FALSE	-	Uint8
1-84	Precise Stop Counter Value	100000 N/A	All set-ups		TRUE	0	Uint32
1-85	Precise Stop Speed Compensation Delay	10 ms	All set-ups		TRUE	-3	Uint8
<b>1-9* Motor Temperature</b>							
1-90	Motor Thermal Protection	[0] No protection	All set-ups		TRUE	-	Uint8
1-91	Motor External Fan	[0] No	All set-ups		TRUE	-	Uint16
1-93	Thermistor Resource	[0] None	All set-ups		TRUE	-	Uint8
1-95	KTY Sensor Type	[0] KTY Sensor 1	All set-ups	x	TRUE	-	Uint8
1-96	KTY Thermistor Resource	[0] None	All set-ups	x	TRUE	-	Uint8
1-97	KTY Threshold level	80 °C	1 set-up	x	TRUE	100	Int16

**2.19.3. 2-\*\* Brakes**

Par. No. #	Parameter description	Default value	4-set-up	FC 302 only	Change during operation	Conversion index	Type
<b>2-0* DC-Brake</b>							
2-00	DC Hold Current	50 %	All set-ups		TRUE	0	Uint8
2-01	DC Brake Current	50 %	All set-ups		TRUE	0	Uint16
2-02	DC Braking Time	10.0 s	All set-ups		TRUE	-1	Uint16
2-03	DC Brake Cut In Speed [RPM]	ExpressionLimit	All set-ups		TRUE	67	Uint16
2-04	DC Brake Cut In Speed [Hz]	ExpressionLimit	All set-ups		TRUE	-1	Uint16
<b>2-1* Brake Energy Funct.</b>							
2-10	Brake Function	null	All set-ups		TRUE	-	Uint8
2-11	Brake Resistor (ohm)	ExpressionLimit	All set-ups		TRUE	0	Uint16
2-12	Brake Power Limit (kW)	ExpressionLimit	All set-ups		TRUE	0	Uint32
2-13	Brake Power Monitoring	[0] Off	All set-ups		TRUE	-	Uint8
2-15	Brake Check	[0] Off	All set-ups		TRUE	-	Uint8
2-16	AC brake Max. Current	100.0 %	All set-ups		TRUE	-1	Uint32
2-17	Over-voltage Control	[0] Disabled	All set-ups		TRUE	-	Uint8
<b>2-2* Mechanical Brake</b>							
2-20	Release Brake Current	ImaxVLT (P1637)	All set-ups		TRUE	-2	Uint32
2-21	Activate Brake Speed [RPM]	ExpressionLimit	All set-ups		TRUE	67	Uint16
2-22	Activate Brake Speed [Hz]	ExpressionLimit	All set-ups		TRUE	-1	Uint16
2-23	Activate Brake Delay	0.0 s	All set-ups		TRUE	-1	Uint8
2-24	Stop Delay	0.0 s	All set-ups		TRUE	-1	Uint8
2-25	Brake Release Time	0.20 s	All set-ups		TRUE	-2	Uint16
2-26	Torque Ref	0.00 %	All set-ups		TRUE	-2	Int16
2-27	Torque Ramp Time	0.2 s	All set-ups		TRUE	-1	Uint8
2-28	Gain Boost Factor	1.00 N/A	All set-ups		TRUE	-2	Uint16

## 2.19.4. 3-\* Reference / Ramps

Par. No. #	Parameter description	Default value	4-set-up	FC 302 only	Change during operation	Conversion index	Type
<b>3-0* Reference Limits</b>							
3-00	Reference Range	null	All set-ups		TRUE	-	Ujnt8
3-01	Reference/Feedback Unit	null	All set-ups		TRUE	-	Ujnt8
3-02	Minimum Reference	0 ReferenceFeedbackUnit	All set-ups		TRUE	-3	Int32
3-03	Maximum Reference	ExpressionLimit	All set-ups		TRUE	-3	Int32
3-04	Reference Function	[0] Sum	All set-ups		TRUE	-	Ujnt8
<b>3-1* References</b>							
3-10	Preset Reference	0.00 %	All set-ups		TRUE	-2	Int16
3-11	Jog Speed [Hz]	ExpressionLimit	All set-ups		TRUE	-1	Ujnt16
3-12	Catch up/slow Down Value	0.00 %	All set-ups		TRUE	-2	Int16
3-13	Reference Site	[0] Linked to Hand / Auto	All set-ups		TRUE	-	Ujnt8
3-14	Preset Relative Reference	0.00 %	All set-ups		TRUE	-2	Int32
3-15	Reference Resource 1	null	All set-ups		TRUE	-	Ujnt8
3-16	Reference Resource 2	null	All set-ups		TRUE	-	Ujnt8
3-17	Reference Resource 3	null	All set-ups		TRUE	-	Ujnt8
3-18	Relative Scaling Reference Resource	[0] No function	All set-ups		TRUE	-	Ujnt8
3-19	Jog Speed [RPM]	ExpressionLimit	All set-ups		TRUE	67	Ujnt16
<b>3-4* Ramp 1</b>							
3-40	Ramp 1 Type	[0] Linear	All set-ups		TRUE	-	Ujnt8
3-41	Ramp 1 Ramp up Time	ExpressionLimit	All set-ups		TRUE	-2	Ujnt32
3-42	Ramp 1 Ramp Down Time	ExpressionLimit	All set-ups		TRUE	-2	Ujnt32
3-43	Ramp 1 S-ramp Ratio at Accel. Start	50 %	All set-ups		TRUE	0	Ujnt8
3-44	Ramp 1 S-ramp Ratio at Decel. Start	50 %	All set-ups		TRUE	0	Ujnt8
3-45	Ramp 1 S-ramp Ratio at Accel. End	50 %	All set-ups		TRUE	0	Ujnt8
3-46	Ramp 1 S-ramp Ratio at Decel. End	50 %	All set-ups		TRUE	0	Ujnt8
3-47	Ramp 1 S-ramp Ratio at Accel. Start	50 %	All set-ups		TRUE	0	Ujnt8
3-48	Ramp 1 S-ramp Ratio at Decel. End	50 %	All set-ups		TRUE	0	Ujnt8
<b>3-5* Ramp 2</b>							
3-50	Ramp 2 Type	[0] Linear	All set-ups		TRUE	-	Ujnt8
3-51	Ramp 2 Ramp up Time	ExpressionLimit	All set-ups		TRUE	-2	Ujnt32
3-52	Ramp 2 Ramp down Time	ExpressionLimit	All set-ups		TRUE	-2	Ujnt32
3-53	Ramp 2 S-ramp Ratio at Accel. Start	50 %	All set-ups		TRUE	0	Ujnt8
3-54	Ramp 2 S-ramp Ratio at Decel. Start	50 %	All set-ups		TRUE	0	Ujnt8
3-55	Ramp 2 S-ramp Ratio at Accel. End	50 %	All set-ups		TRUE	0	Ujnt8
3-56	Ramp 2 S-ramp Ratio at Decel. End	50 %	All set-ups		TRUE	0	Ujnt8
3-57	Ramp 2 S-ramp Ratio at Accel. Start	50 %	All set-ups		TRUE	0	Ujnt8
3-58	Ramp 2 S-ramp Ratio at Decel. End	50 %	All set-ups		TRUE	0	Ujnt8

Par. No. #	Parameter description	Default value	4-set-up	FC 302 only	Change during operation	Conversion index	Type
<b>3-6* Ramp 3</b>							
3-60	Ramp 3 Type	[0] Linear	All set-ups		TRUE	-	Ujnt8
3-61	Ramp 3 Ramp up Time	ExpressionLimit	All set-ups		TRUE	-2	Ujnt32
3-62	Ramp 3 Ramp down Time	ExpressionLimit	All set-ups		TRUE	-2	Ujnt32
3-65	Ramp 3 S-ramp Ratio at Accel. Start	50 %	All set-ups		TRUE	0	Ujnt8
3-66	Ramp 3 S-ramp Ratio at Decel. Start	50 %	All set-ups		TRUE	0	Ujnt8
3-67	Ramp 3 S-ramp Ratio at Accel. End	50 %	All set-ups		TRUE	0	Ujnt8
3-68	Ramp 3 S-ramp Ratio at Decel. End	50 %	All set-ups		TRUE	0	Ujnt8
<b>3-7* Ramp 4</b>							
3-70	Ramp 4 Type	[0] Linear	All set-ups		TRUE	-	Ujnt8
3-71	Ramp 4 Ramp up Time	ExpressionLimit	All set-ups		TRUE	-2	Ujnt32
3-72	Ramp 4 Ramp Down Time	ExpressionLimit	All set-ups		TRUE	-2	Ujnt32
3-75	Ramp 4 S-ramp Ratio at Accel. Start	50 %	All set-ups		TRUE	0	Ujnt8
3-76	Ramp 4 S-ramp Ratio at Accel. End	50 %	All set-ups		TRUE	0	Ujnt8
3-77	Ramp 4 S-ramp Ratio at Decel. Start	50 %	All set-ups		TRUE	0	Ujnt8
3-78	Ramp 4 S-ramp Ratio at Decel. End	50 %	All set-ups		TRUE	0	Ujnt8
<b>3-8* Other Ramps</b>							
3-80	Jog Ramp Time	ExpressionLimit	All set-ups		TRUE	-2	Ujnt32
3-81	Quick Stop Ramp Time	ExpressionLimit	2 set-ups		TRUE	-2	Ujnt32
<b>3-9* Digital Pot.Meter</b>							
3-90	Step Size	0.10 %	All set-ups		TRUE	-2	Ujnt16
3-91	Ramp Time	1.00 s	All set-ups		TRUE	-2	Ujnt32
3-92	Power Restore	[0] Off	All set-ups		TRUE	-	Ujnt8
3-93	Maximum Limit	100 %	All set-ups		TRUE	0	Int16
3-94	Minimum Limit	-100 %	All set-ups		TRUE	0	Int16
3-95	Ramp Delay	1.000 N/A	All set-ups		TRUE	-3	TimD

## 2.19.5. 4-.\* Limits / Warnings

Par. No. #	Parameter description	Default value	4-set-up	FC 302 only	Change during operation	Conversion index	Type
<b>4-1* Motor Limits</b>							
4-10	Motor Speed Direction	null	All set-ups		FALSE	-	Uint8
4-11	Motor Speed Low Limit [RPM]	ExpressionLimit	All set-ups		TRUE	67	Uint16
4-12	Motor Speed Low Limit [Hz]	ExpressionLimit	All set-ups		TRUE	-1	Uint16
4-13	Motor Speed High Limit [RPM]	ExpressionLimit	All set-ups		TRUE	67	Uint16
4-14	Motor Speed High Limit [Hz]	ExpressionLimit	All set-ups		TRUE	-1	Uint16
4-16	Torque Limit Motor Mode	ExpressionLimit	All set-ups		TRUE	-1	Uint16
4-17	Torque Limit Generator Mode	100.0 %	All set-ups		TRUE	-1	Uint16
4-18	Current Limit	ExpressionLimit	All set-ups		TRUE	-1	Uint32
4-19	Max Output Frequency	132.0 Hz	All set-ups		FALSE	-1	Uint16
<b>4-2* Limit Factors</b>							
4-20	Torque Limit Factor Source	[0] No function	All set-ups		TRUE	-	Uint8
4-21	Speed Limit Factor Source	[0] No function	All set-ups		TRUE	-	Uint8
<b>4-3* Motor Fb Monitor</b>							
4-30	Motor Feedback Loss Function	[2] Trip	All set-ups		TRUE	-	Uint8
4-31	Motor Feedback Speed Error	300 RPM	All set-ups		TRUE	67	Uint16
4-32	Motor Feedback Loss Timeout	0.05 s	All set-ups		TRUE	-2	Uint16
<b>4-5* Adj. Warnings</b>							
4-50	Warning Current Low	0.00 A	All set-ups		TRUE	-2	Uint32
4-51	Warning Current High	ImaxVLT (P1637)	All set-ups		TRUE	-2	Uint32
4-52	Warning Speed Low	0 RPM	All set-ups		TRUE	67	Uint16
4-53	Warning Speed High	outputSpeedHighLimit (P413)	All set-ups		TRUE	67	Uint16
4-54	Warning Reference Low	-999999.999 N/A	All set-ups		TRUE	-3	Int32
4-55	Warning Reference High	999999.999 N/A	All set-ups		TRUE	-3	Int32
4-56	Warning Feedback Low	-999999.999 ReferenceFeedbackUnit	All set-ups		TRUE	-3	Int32
4-57	Warning Feedback High	999999.999 ReferenceFeedbackUnit	All set-ups		TRUE	-3	Int32
4-58	Missing Motor Phase Function	[1] On	All set-ups		TRUE	-	Uint8
<b>4-6* Speed Bypass</b>							
4-60	Bypass Speed From [RPM]	ExpressionLimit	All set-ups		TRUE	67	Uint16
4-61	Bypass Speed From [Hz]	ExpressionLimit	All set-ups		TRUE	-1	Uint16
4-62	Bypass Speed To [RPM]	ExpressionLimit	All set-ups		TRUE	67	Uint16
4-63	Bypass Speed To [Hz]	ExpressionLimit	All set-ups		TRUE	-1	Uint16

**2.19.6. 5- \*\* Digital In/Out**

Par. No. #	Parameter description	Default value	4-set-up	FC 302 only	Change during operation	Conversion index	Type
<b>5-0* Digital I/O mode</b>							
5-00	Digital I/O Mode	[0] PNP	All set-ups		FALSE	-	Ujnt8
5-01	Terminal 27 Mode	[0] Input	All set-ups		TRUE	-	Ujnt8
5-02	Terminal 29 Mode	[0] Input	All set-ups	x	TRUE	-	Ujnt8
<b>5-1* Digital Inputs</b>							
5-10	Terminal 18 Digital Input	null	All set-ups		TRUE	-	Ujnt8
5-11	Terminal 19 Digital Input	null	All set-ups		TRUE	-	Ujnt8
5-12	Terminal 27 Digital Input	null	All set-ups		TRUE	-	Ujnt8
5-13	Terminal 29 Digital Input	null	All set-ups	x	TRUE	-	Ujnt8
5-14	Terminal 32 Digital Input	[0] No operation	All set-ups		TRUE	-	Ujnt8
5-15	Terminal 33 Digital Input	[0] No operation	All set-ups		TRUE	-	Ujnt8
5-16	Terminal X30/2 Digital Input	[0] No operation	All set-ups		TRUE	-	Ujnt8
5-17	Terminal X30/3 Digital Input	[0] No operation	All set-ups		TRUE	-	Ujnt8
5-18	Terminal X30/4 Digital Input	[0] No operation	All set-ups		TRUE	-	Ujnt8
5-19	Terminal 37 Safe Stop	[1] Safe Stop Alarm	1 set-up		TRUE	-	Ujnt8
5-20	Terminal X46/1 Digital Input	[0] No operation	All set-ups		TRUE	-	Ujnt8
5-21	Terminal X46/3 Digital Input	[0] No operation	All set-ups		TRUE	-	Ujnt8
5-22	Terminal X46/5 Digital Input	[0] No operation	All set-ups		TRUE	-	Ujnt8
5-23	Terminal X46/7 Digital Input	[0] No operation	All set-ups		TRUE	-	Ujnt8
5-24	Terminal X46/9 Digital Input	[0] No operation	All set-ups		TRUE	-	Ujnt8
5-25	Terminal X46/11 Digital Input	[0] No operation	All set-ups		TRUE	-	Ujnt8
5-26	Terminal X46/13 Digital Input	[0] No operation	All set-ups		TRUE	-	Ujnt8
<b>5-3* Digital Outputs</b>							
5-30	Terminal 27 Digital Output	null	All set-ups		TRUE	-	Ujnt8
5-31	Terminal 29 Digital Output	null	All set-ups	x	TRUE	-	Ujnt8
5-32	Term X30/6 Digi Out (MCB 101)	null	All set-ups		TRUE	-	Ujnt8
5-33	Term X30/7 Digi Out (MCB 101)	null	All set-ups		TRUE	-	Ujnt8
<b>5-4* Relays</b>							
5-40	Function Relay	null	All set-ups		TRUE	-	Ujnt8
5-41	On Delay, Relay	0.01 s	All set-ups		TRUE	-2	Ujnt16
5-42	Off Delay, Relay	0.01 s	All set-ups		TRUE	-2	Ujnt16

Par. No. #	Parameter description	Default value	4-set-up	FC 302 only	Change during operation	Conversion index	Type
<b>5-5* Pulse Input</b>							
5-50	Term. 29 Low Frequency	100 Hz	All set-ups	x	TRUE	0	Uint32
5-51	Term. 29 High Frequency	100 Hz	All set-ups	x	TRUE	0	Uint32
5-52	Term. 29 Low Ref./Feedb. Value	0.000 ReferenceFeedbackUnit	All set-ups	x	TRUE	-3	Int32
5-53	Term. 29 High Ref./Feedb. Value	ExpressionLimit	All set-ups	x	TRUE	-3	Int32
5-54	Pulse Filter Time Constant #29	100 ms	All set-ups	x	FALSE	-3	Uint16
5-55	Term. 33 Low Frequency	100 Hz	All set-ups		TRUE	0	Uint32
5-56	Term. 33 High Frequency	100 Hz	All set-ups		TRUE	0	Uint32
5-57	Term. 33 Low Ref./Feedb. Value	0.000 ReferenceFeedbackUnit	All set-ups		TRUE	-3	Int32
5-58	Term. 33 High Ref./Feedb. Value	ExpressionLimit	All set-ups		TRUE	-3	Int32
5-59	Pulse Filter Time Constant #33	100 ms	All set-ups		FALSE	-3	Uint16
<b>5-6* Pulse Output</b>							
5-60	Terminal 27 Pulse Output Variable	null	All set-ups		TRUE	-	Uint8
5-62	Pulse Output Max Freq #27	ExpressionLimit	All set-ups		TRUE	0	Uint32
5-63	Terminal 29 Pulse Output Variable	null	All set-ups	x	TRUE	-	Uint8
5-65	Pulse Output Max Freq #29	ExpressionLimit	All set-ups	x	TRUE	0	Uint32
5-66	Terminal X30/6 Pulse Output Variable	null	All set-ups		TRUE	-	Uint8
5-68	Pulse Output Max Freq #X30/6	ExpressionLimit	All set-ups		TRUE	0	Uint32
<b>5-7* 24V Encoder Input</b>							
5-70	Term 32/33 Pulses per Revolution	1024 N/A	All set-ups		FALSE	0	Uint16
5-71	Term 32/33 Encoder Direction	[0] Clockwise	All set-ups		FALSE	-	Uint8
<b>5-9* Bus Controlled</b>							
Digital & Relay Bus Control							
5-93	Pulse Out #27 Bus Control	0 N/A	All set-ups		TRUE	0	Uint32
5-94	Pulse Out #27 Timeout Preset	0.00 %	All set-ups		TRUE	-2	N2
5-95	Pulse Out #29 Bus Control	0.00 %	1 set-up		TRUE	-2	Uint16
5-96	Pulse Out #29 Timeout Preset	0.00 %	All set-ups	x	TRUE	-2	N2
		0.00 %	1 set-up	x	TRUE	-2	Uint16



**2.19.7. 6-\*\* Analog In/Out**

Par. No. #	Parameter description	Default value	4-set-up	FC 302 only	Change during operation	Conversion index	Type
<b>6-0* Analog I/O Mode</b>							
6-00	Live Zero Timeout Time	10 s	All set-ups		TRUE	0	Ujnt8
6-01	Live Zero Timeout Function	[0] Off	All set-ups		TRUE	-	Ujnt8
<b>6-1* Analog Input 1</b>							
6-10	Terminal 53 Low Voltage	0.07 V	All set-ups		TRUE	-2	Int16
6-11	Terminal 53 High Voltage	10.00 V	All set-ups		TRUE	-2	Int16
6-12	Terminal 53 Low Current	0.14 mA	All set-ups		TRUE	-5	Int16
6-13	Terminal 53 High Current	20.00 mA	All set-ups		TRUE	-5	Int16
6-14	Terminal 53 Low Ref./Feedb. Value	0 ReferenceFeedbackUnit	All set-ups		TRUE	-3	Int32
6-15	Terminal 53 High Ref./Feedb. Value	ExpressionLimit	All set-ups		TRUE	-3	Int32
6-16	Terminal 53 Filter Time Constant	0.001 s	All set-ups		TRUE	-3	Ujnt16
<b>6-2* Analog Input 2</b>							
6-20	Terminal 54 Low Voltage	0.07 V	All set-ups		TRUE	-2	Int16
6-21	Terminal 54 High Voltage	10.00 V	All set-ups		TRUE	-2	Int16
6-22	Terminal 54 Low Current	0.14 mA	All set-ups		TRUE	-5	Int16
6-23	Terminal 54 High Current	20.00 mA	All set-ups		TRUE	-5	Int16
6-24	Terminal 54 Low Ref./Feedb. Value	0 ReferenceFeedbackUnit	All set-ups		TRUE	-3	Int32
6-25	Terminal 54 High Ref./Feedb. Value	ExpressionLimit	All set-ups		TRUE	-3	Int32
6-26	Terminal 54 Filter Time Constant	0.001 s	All set-ups		TRUE	-3	Ujnt16
<b>6-3* Analog Input 3</b>							
6-30	Terminal X30/11 Low Voltage	0.07 V	All set-ups		TRUE	-2	Int16
6-31	Terminal X30/11 High Voltage	10.00 V	All set-ups		TRUE	-2	Int16
6-34	Term. X30/11 Low Ref./Feedb. Value	0 ReferenceFeedbackUnit	All set-ups		TRUE	-3	Int32
6-35	Term. X30/11 High Ref./Feedb. Value	ExpressionLimit	All set-ups		TRUE	-3	Int32
6-36	Term. X30/11 Filter Time Constant	0.001 s	All set-ups		TRUE	-3	Ujnt16
<b>6-4* Analog Input 4</b>							
6-40	Terminal X30/12 Low Voltage	0.07 V	All set-ups		TRUE	-2	Int16
6-41	Terminal X30/12 High Voltage	10.00 V	All set-ups		TRUE	-2	Int16
6-44	Term. X30/12 Low Ref./Feedb. Value	0 ReferenceFeedbackUnit	All set-ups		TRUE	-3	Int32
6-45	Term. X30/12 High Ref./Feedb. Value	ExpressionLimit	All set-ups		TRUE	-3	Int32
6-46	Term. X30/12 Filter Time Constant	0.001 s	All set-ups		TRUE	-3	Ujnt16
<b>6-5* Analog Output 1</b>							
6-50	Terminal 42 Output	null	All set-ups		TRUE	-	Ujnt8
6-51	Terminal 42 Output Min Scale	0.00 %	All set-ups		TRUE	-2	Int16
6-52	Terminal 42 Output Max Scale	100.00 %	All set-ups		TRUE	-2	Int16
6-53	Terminal 42 Output Bus Control	0.00 %	All set-ups		TRUE	-2	N2
6-54	Terminal 42 Output Timeout Preset	0.00 %	1 set-up		TRUE	-2	Ujnt16
<b>6-6* Analog Output 2</b>							
6-60	Terminal X30/8 Output	null	All set-ups		TRUE	-	Ujnt8
6-61	Terminal X30/8 Min. Scale	0.00 %	All set-ups		TRUE	-2	Int16
6-62	Terminal X30/8 Max. Scale	100.00 %	All set-ups		TRUE	-2	Int16
<b>6-7* Analog Output 3</b>							
6-70	Terminal X45/1 Output	null	All set-ups		TRUE	-	Ujnt8
6-71	Terminal X45/1 Min. Scale	0.00 %	All set-ups		TRUE	-2	Int16
6-72	Terminal X45/1 Max. Scale	100.00 %	All set-ups		TRUE	-2	Int16
<b>6-8* Analog Output 4</b>							
6-80	Terminal X45/3 Output	null	All set-ups		TRUE	-	Ujnt8
6-81	Terminal X45/3 Min. Scale	0.00 %	All set-ups		TRUE	-2	Int16
6-82	Terminal X45/3 Max. Scale	100.00 %	All set-ups		TRUE	-2	Int16

## 2.19.8. 7-.\* Controllers

Par. No. #	Parameter description	Default value	4-set-up	FC 302 only	Change during operation	Conversion index	Type
<b>7-0* Speed PID Ctrl.</b>							
7-00	Speed PID Feedback Source	null	All set-ups		FALSE	-	Uint8
7-02	Speed PID Proportional Gain	ExpressionLimit	All set-ups		TRUE	-3	Uint16
7-03	Speed PID Integral Time	ExpressionLimit	All set-ups		TRUE	-4	Uint32
7-04	Speed PID Differentiation Time	ExpressionLimit	All set-ups		TRUE	-4	Uint16
7-05	Speed PID Diff. Gain Limit	5.0 N/A	All set-ups		TRUE	-1	Uint16
7-06	Speed PID Lowpass Filter Time	10.0 ms	All set-ups		TRUE	-4	Uint16
7-08	Speed PID Feed Forward Factor	0 %	All set-ups		FALSE	0	Uint16
<b>7-2* Process Ctrl. Feeds</b>							
7-20	Process CL Feedback 1 Resource	[0] No function	All set-ups		TRUE	-	Uint8
7-22	Process CL Feedback 2 Resource	[0] No function	All set-ups		TRUE	-	Uint8
<b>7-3* Process PID Ctrl.</b>							
7-30	Process PID Normal/ Inverse Control	[0] Normal	All set-ups		TRUE	-	Uint8
7-31	Process PID Anti Windup	[1] On	All set-ups		TRUE	-	Uint8
7-32	Process PID Start Speed	0 RPM	All set-ups		TRUE	67	Uint16
7-33	Process PID Proportional Gain	0.01 N/A	All set-ups		TRUE	-2	Uint16
7-34	Process PID Integral Time	10000.00 s	All set-ups		TRUE	-2	Uint32
7-35	Process PID Differentiation Time	0.00 s	All set-ups		TRUE	-2	Uint16
7-36	Process PID Diff. Gain Limit	5.0 N/A	All set-ups		TRUE	-1	Uint16
7-38	Process PID Feed Forward Factor	0 %	All set-ups		TRUE	0	Uint16
7-39	On Reference Bandwidth	5 %	All set-ups		TRUE	0	Uint8

**2.19.9. 8- \* Comm. and Options**

Par. No. #	Parameter description	Default value	4-set-up	FC 302 only	Change during operation	Conversion index	Type
<b>8-0* General Settings</b>							
8-01	Control Site	[0] Digital and ctrl.word	All set-ups		TRUE	-	Ujnt8
8-02	Control Word Source	null	All set-ups		TRUE	-	Ujnt8
8-03	Control Word Timeout Time	1.0 s	1 set-up		TRUE	-1	Ujnt32
8-04	Control Word Timeout Function	[0] Off	1 set-up		TRUE	-	Ujnt8
8-05	End-of-Timeout Function	[1] Resume set-up	1 set-up		TRUE	-	Ujnt8
8-06	Reset Control Word Timeout	[0] Do not reset	All set-ups		TRUE	-	Ujnt8
8-07	Diagnosis Trigger	[0] Disable	2 set-ups		TRUE	-	Ujnt8
<b>8-1* Ctrl. Word Settings</b>							
8-10	Control Word Profile	[0] FC profile	All set-ups		TRUE	-	Ujnt8
8-13	Configurable Status Word STW	[1] Profile Default	All set-ups		TRUE	-	Ujnt8
<b>8-3* FC Port Settings</b>							
8-30	Protocol	[0] FC	1 set-up		TRUE	-	Ujnt8
8-31	Address	1 N/A	1 set-up		TRUE	0	Ujnt8
8-32	FC Port Baud Rate	[2] 9600 Baud	1 set-up		TRUE	-	Ujnt8
8-35	Minimum Response Delay	10 ms	All set-ups		TRUE	-3	Ujnt16
8-36	Max Response Delay	5000 ms	1 set-up		TRUE	-3	Ujnt16
8-37	Max Inter-Char Delay	25 ms	1 set-up		TRUE	-3	Ujnt16
<b>8-4* FC MC protocol set</b>							
8-40	Telegram selection	[1] Standard telegram 1	2 set-ups		TRUE	-	Ujnt8
<b>8-5* Digital/Bus</b>							
8-50	Coasting Select	[3] Logic OR	All set-ups		TRUE	-	Ujnt8
8-51	Quick Stop Select	[3] Logic OR	All set-ups		TRUE	-	Ujnt8
8-52	DC Brake Select	[3] Logic OR	All set-ups		TRUE	-	Ujnt8
8-53	Start Select	[3] Logic OR	All set-ups		TRUE	-	Ujnt8
8-54	Reversing Select	[3] Logic OR	All set-ups		TRUE	-	Ujnt8
8-55	Set-up Select	[3] Logic OR	All set-ups		TRUE	-	Ujnt8
8-56	Preset Reference Select	[3] Logic OR	All set-ups		TRUE	-	Ujnt8
<b>8-9* Bus Jog</b>							
8-90	Bus Jog 1 Speed	100 RPM	All set-ups		TRUE	67	Ujnt16
8-91	Bus Jog 2 Speed	200 RPM	All set-ups		TRUE	67	Ujnt16

## 2.19.10. 9-.\*.\* Profibus

Par. No. #	Parameter description	Default value	4-set-up	FC 302 only	Change during operation	Conversion index	Type
9-00	Setpoint	0 N/A	All set-ups		TRUE	0	Uint16
9-07	Actual Value	0 N/A	All set-ups		FALSE	0	Uint16
9-15	PCD Write Configuration	ExpressionLimit	2 set-ups		TRUE	-	Uint16
9-16	PCD Read Configuration	ExpressionLimit	2 set-ups		TRUE	-	Uint16
9-22	Node Address	126 N/A	1 set-up		TRUE	0	Uint8
9-18	Telegram Selection	[108] PPO 8	1 set-up		TRUE	-	Uint8
9-23	Parameters for Signals	0	All set-ups		TRUE	-	Uint16
9-27	Parameter Edit	[1] Enabled	2 set-ups		FALSE	-	Uint16
9-28	Process Control	[1] Enable cyclic master	2 set-ups		FALSE	-	Uint8
9-31	Safe Address	0 N/A	1 set-up		TRUE	0	Uint16
9-44	Fault Message Counter	0 N/A	All set-ups		TRUE	0	Uint16
9-45	Fault Code	0 N/A	All set-ups		TRUE	0	Uint16
9-47	Fault Number	0 N/A	All set-ups		TRUE	0	Uint16
9-52	Fault Situation Counter	0 N/A	All set-ups		TRUE	0	Uint16
9-53	Profibus Warning Word	0 N/A	All set-ups		TRUE	0	Uint16
9-63	Actual Baud Rate	0 N/A	All set-ups		TRUE	0	V2
9-64	Device Identification	[255] No baudrate found	All set-ups		TRUE	-	Uint8
9-65	Profile Number	0 N/A	All set-ups		TRUE	0	Uint16
9-67	Control Word 1	0 N/A	All set-ups		TRUE	0	OctStr[2]
9-68	Status Word 1	0 N/A	All set-ups		TRUE	0	V2
9-71	Profibus Save Data Values	[0] Off	All set-ups		TRUE	-	Uint8
9-72	ProfibusDriveReset	[0] No action	1 set-up		FALSE	-	Uint8
9-80	Defined Parameters (1)	0 N/A	All set-ups		FALSE	0	Uint16
9-81	Defined Parameters (2)	0 N/A	All set-ups		FALSE	0	Uint16
9-82	Defined Parameters (3)	0 N/A	All set-ups		FALSE	0	Uint16
9-83	Defined Parameters (4)	0 N/A	All set-ups		FALSE	0	Uint16
9-84	Defined Parameters (5)	0 N/A	All set-ups		FALSE	0	Uint16
9-90	Changed Parameters (1)	0 N/A	All set-ups		FALSE	0	Uint16
9-91	Changed Parameters (2)	0 N/A	All set-ups		FALSE	0	Uint16
9-92	Changed Parameters (3)	0 N/A	All set-ups		FALSE	0	Uint16
9-93	Changed parameters (4)	0 N/A	All set-ups		FALSE	0	Uint16
9-94	Changed parameters (5)	0 N/A	All set-ups		FALSE	0	Uint16
9-99	Profibus Revision Counter	0 N/A	All set-ups		TRUE	0	Uint16

**2.19.11. 10-\* \* CAN Fieldbus**

Par. No. #	Parameter description	Default value	4-set-up	FC 302 only	Change during operation	Conversion index	Type
<b>10-0* Common Settings</b>							
10-00	CAN Protocol	null	2 set-ups		FALSE	-	Ujnt8
10-01	Baud Rate Select	null	2 set-ups		TRUE	-	Ujnt8
10-02	MAC ID	ExpressionLimit	2 set-ups		TRUE	0	Ujnt8
10-05	Readout Transmit Error Counter	0 N/A	All set-ups		TRUE	0	Ujnt8
10-06	Readout Receive Error Counter	0 N/A	All set-ups		TRUE	0	Ujnt8
10-07	Readout Bus Off Counter	0 N/A	All set-ups		TRUE	0	Ujnt8
<b>10-1* DeviceNet</b>							
10-10	Process Data Type Selection	null	All set-ups		TRUE	-	Ujnt8
10-11	Process Data Config Write	ExpressionLimit	2 set-ups		TRUE	-	Ujnt16
10-12	Process Data Config Read	ExpressionLimit	2 set-ups		TRUE	-	Ujnt16
10-13	Warning Parameter	0 N/A	All set-ups		TRUE	0	Ujnt16
10-14	Net Reference	[0] Off	2 set-ups		TRUE	-	Ujnt8
10-15	Net Control	[0] Off	2 set-ups		TRUE	-	Ujnt8
<b>10-2* COS Filters</b>							
10-20	COS Filter 1	0 N/A	All set-ups		FALSE	0	Ujnt16
10-21	COS Filter 2	0 N/A	All set-ups		FALSE	0	Ujnt16
10-22	COS Filter 3	0 N/A	All set-ups		FALSE	0	Ujnt16
10-23	COS Filter 4	0 N/A	All set-ups		FALSE	0	Ujnt16
<b>10-3* Parameter Access</b>							
10-30	Array Index	0 N/A	2 set-ups		TRUE	0	Ujnt8
10-31	Store Data Values	[0] Off	All set-ups		TRUE	-	Ujnt8
10-32	DeviceNet Revision	ExpressionLimit	All set-ups		TRUE	0	Ujnt16
10-33	Store Always	[0] Off	1 set-up		TRUE	-	Ujnt8
10-34	DeviceNet Product Code	ExpressionLimit	1 set-up		TRUE	0	Ujnt16
10-39	DeviceNet F Parameters	0 N/A	All set-ups		TRUE	0	Ujnt32
<b>10-5* CANopen</b>							
10-50	Process Data Config Write.	ExpressionLimit	2 set-ups		TRUE	-	Ujnt16
10-51	Process Data Config Read.	ExpressionLimit	2 set-ups		TRUE	-	Ujnt16

## 2.19.12. 13-.\*.\* Smart Logic

Par. No. #	Parameter description	Default value	4-set-up	FC 302 only	Change during operation	Conversion index	Type
<b>13-0* SLC Settings</b>							
13-00	SL Controller Mode	null	2 set-ups		TRUE	-	Ujnt8
13-01	Start Event	null	2 set-ups		TRUE	-	Ujnt8
13-02	Stop Event	null	2 set-ups		TRUE	-	Ujnt8
13-03	Reset SLC	[0] Do not reset SLC	All set-ups		TRUE	-	Ujnt8
<b>13-1* Comparators</b>							
13-10	Comparator Operand	null	2 set-ups		TRUE	-	Ujnt8
13-11	Comparator Operator	null	2 set-ups		TRUE	-	Ujnt8
13-12	Comparator Value	ExpressionLimit	2 set-ups		TRUE	-3	Int32
<b>13-2* Timers</b>							
13-20	SL Controller Timer	ExpressionLimit	1 set-up		TRUE	-3	TimD
<b>13-4* Logic Rules</b>							
13-40	Logic Rule Boolean 1	null	2 set-ups		TRUE	-	Ujnt8
13-41	Logic Rule Operator 1	null	2 set-ups		TRUE	-	Ujnt8
13-42	Logic Rule Boolean 2	null	2 set-ups		TRUE	-	Ujnt8
13-43	Logic Rule Operator 2	null	2 set-ups		TRUE	-	Ujnt8
13-44	Logic Rule Boolean 3	null	2 set-ups		TRUE	-	Ujnt8
<b>13-5* States</b>							
13-51	SL Controller Event	null	2 set-ups		TRUE	-	Ujnt8
13-52	SL Controller Action	null	2 set-ups		TRUE	-	Ujnt8

**2.19.13. 14-\* \* Special Functions**

Par. No. #	Parameter description	Default value	4-set-up	FC 302 only	Change during operation	Conversion index	Type
<b>14-0* Inverter Switching</b>							
14-00	Switching Pattern	[1] SFAYM	All set-ups		TRUE	-	Ujnt8
14-01	Switching Frequency	null	All set-ups		TRUE	-	Ujnt8
14-03	Overmodulation	[1] On	All set-ups		FALSE	-	Ujnt8
14-04	PWM Random	[0] Off	All set-ups		TRUE	-	Ujnt8
<b>14-1* Mains On/Off</b>							
14-10	Mains Failure	[0] No function	All set-ups		FALSE	-	Ujnt8
14-11	Mains Voltage at Mains Fault	ExpressionLimit	All set-ups		TRUE	0	Ujnt16
14-12	Function at Mains Imbalance	[0] Trip	All set-ups		TRUE	-	Ujnt8
<b>14-2* Trip Reset</b>							
14-20	Reset Mode	[0] Manual reset	All set-ups		TRUE	-	Ujnt8
14-21	Automatic Restart Time	10 s	All set-ups		TRUE	0	Ujnt16
14-22	Operation Mode	[0] Normal operation	All set-ups		TRUE	-	Ujnt8
14-23	Typecode Setting	null	2 set-ups		FALSE	-	Ujnt8
14-25	Trip Delay at Torque Limit	60 s	All set-ups		TRUE	0	Ujnt8
14-26	Trip Delay at Inverter Fault	ExpressionLimit	All set-ups		TRUE	0	Ujnt8
14-28	Production Settings	[0] No action	All set-ups		TRUE	-	Ujnt8
14-29	Service Code	0 N/A	All set-ups		TRUE	0	Int32
<b>14-3* Current Limit Ctrl.</b>							
14-30	Current Lim Contr, Proportional Gain	100 %	All set-ups		FALSE	0	Ujnt16
14-31	Current Lim Contr, Integration Time	0.020 s	All set-ups		FALSE	-3	Ujnt16
<b>14-4* Energy Optimising</b>							
14-40	VT Level	66 %	All set-ups		FALSE	0	Ujnt8
14-41	AEO Minimum Magnetisation	40 %	All set-ups		TRUE	0	Ujnt8
14-42	Minimum AEO Frequency	10 Hz	All set-ups		TRUE	0	Ujnt8
14-43	Motor Cosphi	ExpressionLimit	All set-ups		TRUE	-2	Ujnt16
<b>14-5* Environment</b>							
14-50	RFI Filter	[1] On	1 set-up	x	FALSE	-	Ujnt8
14-52	Fan Control	[0] Auto	All set-ups		TRUE	-	Ujnt8
14-53	Fan Monitor	[1] Warning	All set-ups		TRUE	-	Ujnt8
14-55	Output Filter	[0] No Filter	1 set-up		FALSE	-	Ujnt8
14-56	Capacitance Output Filter	2.0 uF	1 set-up		FALSE	-7	Ujnt16
14-57	Inductance Output Filter	7.000 mH	1 set-up		FALSE	-6	Ujnt16
<b>14-7* Compatibility</b>							
14-72	VLT Alarm Word	0 N/A	All set-ups		FALSE	0	Ujnt32
14-73	VLT Warning Word	0 N/A	All set-ups		FALSE	0	Ujnt32
14-74	VLT Ext. Status Word	0 N/A	All set-ups		FALSE	0	Ujnt32
<b>14-8* Options</b>							
14-80	Option Supplied by External 24VDC	[1] Yes	2 set-ups		FALSE	-	Ujnt8

## 2.19.14. 15-.\*.\* Drive Information

Par. No. #	Parameter description	Default value	4-set-up	FC 302 only	Change during operation	Conversion index	Type
<b>15-0* Operating Data</b>							
15-00	Operating Hours	0 h	All set-ups		FALSE	74	Ujnt32
15-01	Running Hours	0 h	All set-ups		FALSE	74	Ujnt32
15-02	kWh Counter	0 kWh	All set-ups		FALSE	75	Ujnt32
15-03	Power Up's	0 N/A	All set-ups		FALSE	0	Ujnt32
15-04	Over Temp's	0 N/A	All set-ups		FALSE	0	Ujnt16
15-05	Over Volt's	0 N/A	All set-ups		FALSE	0	Ujnt16
15-06	Reset kWh Counter	[0] Do not reset	All set-ups		TRUE	-	Ujnt8
15-07	Reset Running Hours Counter	[0] Do not reset	All set-ups		TRUE	-	Ujnt8
<b>15-1* Data Log Settings</b>							
15-10	Logging Source	0	2 set-ups		TRUE	-	Ujnt16
15-11	Logging Interval	ExpressionLimit	2 set-ups		TRUE	-3	TimD
15-12	Trigger Event	[0] False	1 set-up		TRUE	-	Ujnt8
15-13	Logging Mode	[0] Log always	2 set-ups		TRUE	-	Ujnt8
15-14	Samples Before Trigger	50 N/A	2 set-ups		TRUE	0	Ujnt8
<b>15-2* Historic Log</b>							
15-20	Historic Log: Event	0 N/A	All set-ups		FALSE	0	Ujnt8
15-21	Historic Log: Value	0 N/A	All set-ups		FALSE	0	Ujnt32
15-22	Historic Log: Time	0 ms	All set-ups		FALSE	-3	Ujnt32
<b>15-3* Fault Log</b>							
15-30	Fault Log: Error Code	0 N/A	All set-ups		FALSE	0	Ujnt8
15-31	Fault Log: Value	0 N/A	All set-ups		FALSE	0	Int16
15-32	Fault Log: Time	0 s	All set-ups		FALSE	0	Ujnt32
<b>15-4* Drive Identification</b>							
15-40	FC Type	0 N/A	All set-ups		FALSE	0	VisStr[6]
15-41	Power Section	0 N/A	All set-ups		FALSE	0	VisStr[20]
15-42	Voltage	0 N/A	All set-ups		FALSE	0	VisStr[20]
15-43	Software Version	0 N/A	All set-ups		FALSE	0	VisStr[15]
15-44	Ordered Typecode String	0 N/A	All set-ups		FALSE	0	VisStr[40]
15-45	Actual Typecode String	0 N/A	All set-ups		FALSE	0	VisStr[40]
15-46	Frequency Converter Ordering No	0 N/A	All set-ups		FALSE	0	VisStr[8]
15-47	Power Card Ordering No	0 N/A	All set-ups		FALSE	0	VisStr[8]
15-48	LCP Id No	0 N/A	All set-ups		FALSE	0	VisStr[8]
15-49	SW ID Control Card	0 N/A	All set-ups		FALSE	0	VisStr[20]
15-50	SW ID Power Card	0 N/A	All set-ups		FALSE	0	VisStr[20]
15-51	Frequency Converter Serial Number	0 N/A	All set-ups		FALSE	0	VisStr[20]
15-53	Power Card Serial Number	0 N/A	All set-ups		FALSE	0	VisStr[19]



Par. No. #	Parameter description	Default value	4-set-up	FC 302 only	Change during operation	Conversion index	Type
<b>15-6* Option Ident</b>							
15-60	Option Mounted	0 N/A	All set-ups		FALSE	0	VisStr[30]
15-61	Option SW Version	0 N/A	All set-ups		FALSE	0	VisStr[20]
15-62	Option Ordering No	0 N/A	All set-ups		FALSE	0	VisStr[8]
15-63	Option Serial No	0 N/A	All set-ups		FALSE	0	VisStr[18]
15-70	Option in Slot A	0 N/A	All set-ups		FALSE	0	VisStr[30]
15-71	Slot A Option SW Version	0 N/A	All set-ups		FALSE	0	VisStr[20]
15-72	Option in Slot B	0 N/A	All set-ups		FALSE	0	VisStr[30]
15-73	Slot B Option SW Version	0 N/A	All set-ups		FALSE	0	VisStr[20]
15-74	Option in Slot C0	0 N/A	All set-ups		FALSE	0	VisStr[30]
15-75	Slot C0 Option SW Version	0 N/A	All set-ups		FALSE	0	VisStr[20]
15-76	Option in Slot C1	0 N/A	All set-ups		FALSE	0	VisStr[30]
15-77	Slot C1 Option SW Version	0 N/A	All set-ups		FALSE	0	VisStr[20]
<b>15-9* Parameter Info</b>							
15-92	Defined Parameters	0 N/A	All set-ups		FALSE	0	Uint16
15-93	Modified Parameters	0 N/A	All set-ups		FALSE	0	Uint16
15-98	Drive Identification	0 N/A	All set-ups		FALSE	0	VisStr[40]
15-99	Parameter Metadata	0 N/A	All set-ups		FALSE	0	Uint16

## 2.19.15. 16-.\*.\* Data Readouts

Par. No. #	Parameter description	Default value	4-set-up	FC 302 only	Change during operation	Conversion index	Type
<b>16-0* General Status</b>							
16-00	Control Word	0 N/A	All set-ups		FALSE	0	V2
16-01	Reference [Unit]	0.000 ReferenceFeedbackUnit	All set-ups		FALSE	-3	Int32
16-02	Reference %	0.0 %	All set-ups		FALSE	-1	Int16
16-03	Status Word	0 N/A	All set-ups		FALSE	0	V2
16-05	Main Actual Value [%]	0.00 %	All set-ups		FALSE	-2	N2
16-09	Custom Readout	0.00 CustomReadoutUnit	All set-ups		FALSE	-2	Int32
<b>16-1* Motor Status</b>							
16-10	Power [kW]	0.00 kW	All set-ups		FALSE	1	Int32
16-11	Power [hp]	0.00 hp	All set-ups		FALSE	-2	Int32
16-12	Motor Voltage	0.0 V	All set-ups		FALSE	-1	Uint16
16-13	Frequency	0.0 Hz	All set-ups		FALSE	-1	Uint16
16-14	Motor Current	0.00 A	All set-ups		FALSE	-2	Int32
16-15	Frequency [%]	0.00 %	All set-ups		FALSE	-2	N2
16-16	Torque [Nm]	0.0 Nm	All set-ups		FALSE	-1	Int16
16-17	Speed [RPM]	0 RPM	All set-ups		FALSE	67	Int32
16-18	Motor Thermal	0 %	All set-ups		FALSE	0	Uint8
16-19	KTY sensor temperature	0 °C	All set-ups		FALSE	100	Int16
16-20	Motor Angle	0 N/A	All set-ups		TRUE	0	Uint16
16-22	Torque [%]	0 %	All set-ups		FALSE	0	Int16
<b>16-3* Drive Status</b>							
16-30	DC Link Voltage	0 V	All set-ups		FALSE	0	Uint16
16-32	Brake Energy /s	0.000 kW	All set-ups		FALSE	0	Uint32
16-33	Brake Energy /2 min	0.000 kW	All set-ups		FALSE	0	Uint32
16-34	Heatsink Temp.	0 °C	All set-ups		FALSE	100	Uint8
16-35	Inverter Thermal	0 %	All set-ups		FALSE	0	Uint8
16-36	Inv. Nom. Current	ExpressionLimit	All set-ups		FALSE	-2	Uint32
16-37	Inv. Max. Current	ExpressionLimit	All set-ups		FALSE	-2	Uint32
16-38	SL Controller State	0 N/A	All set-ups		FALSE	0	Uint8
16-39	Control Card Temp.	0 °C	All set-ups		FALSE	100	Uint8
16-40	Logging Buffer Full	[0] No	All set-ups		TRUE	-	Uint8
<b>16-5* Ref. &amp; Feedsb.</b>							
16-50	External Reference	0.0 N/A	All set-ups		FALSE	-1	Int16
16-51	Pulse Reference	0.0 N/A	All set-ups		FALSE	-1	Int16
16-52	Feedback [Unit]	0.000 ReferenceFeedbackUnit	All set-ups		FALSE	-3	Int32
16-53	Digi Pot Reference	0.00 N/A	All set-ups		FALSE	-2	Int16

Par. No. #	Parameter description	Default value	4-set-up	FC 302 only	Change during operation	Conversion index	Type
<b>16-6* Inputs &amp; Outputs</b>							
16-60	Digital Input	0 N/A	All set-ups		FALSE	0	Uint16
16-61	Terminal 53 Switch Setting	[0] Current	All set-ups		FALSE	-	Uint8
16-62	Analog Input 53	0.000 N/A	All set-ups		FALSE	-3	Int32
16-63	Terminal 54 Switch Setting	[0] Current	All set-ups		FALSE	-	Uint8
16-64	Analog Input 54	0.000 N/A	All set-ups		FALSE	-3	Int32
16-65	Analog Output 42 [mA]	0.000 N/A	All set-ups		FALSE	-3	Int16
16-66	Digital Output [bin]	0 N/A	All set-ups		FALSE	0	Int16
16-67	Freq. Input #29 [Hz]	0 N/A	All set-ups	x	FALSE	0	Int32
16-68	Freq. Input #33 [Hz]	0 N/A	All set-ups		FALSE	0	Int32
16-69	Pulse Output #27 [Hz]	0 N/A	All set-ups		FALSE	0	Int32
16-70	Pulse Output #29 [Hz]	0 N/A	All set-ups	x	FALSE	0	Int32
16-71	Relay Output [bin]	0 N/A	All set-ups		FALSE	0	Int16
16-72	Counter A	0 N/A	All set-ups		TRUE	0	Int32
16-73	Counter B	0 N/A	All set-ups		TRUE	0	Int32
16-74	Prec. Stop Counter	0 N/A	All set-ups		TRUE	0	Uint32
16-75	Analog In X30/11	0.000 N/A	All set-ups		FALSE	-3	Int32
16-76	Analog In X30/12	0.000 N/A	All set-ups		FALSE	-3	Int32
16-77	Analog Out X30/8 [mA]	0.000 N/A	All set-ups		FALSE	-3	Int16
16-78	Analog Out X45/1 [mA]	0.000 N/A	All set-ups		FALSE	-3	Int16
16-79	Analog Out X45/3 [mA]	0.000 N/A	All set-ups		FALSE	-3	Int16
<b>16-8* Fieldbus &amp; FC Port</b>							
16-80	Fieldbus CTW 1	0 N/A	All set-ups		FALSE	0	V2
16-82	Fieldbus REF 1	0 N/A	All set-ups		FALSE	0	N2
16-84	Comm. Option STW	0 N/A	All set-ups		FALSE	0	V2
16-85	FC Port CTW 1	0 N/A	All set-ups		FALSE	0	V2
16-86	FC Port REF 1	0 N/A	All set-ups		FALSE	0	N2
<b>16-9* Diagnosis Readouts</b>							
16-90	Alarm Word	0 N/A	All set-ups		FALSE	0	Uint32
16-91	Alarm Word 2	0 N/A	All set-ups		FALSE	0	Uint32
16-92	Warning Word	0 N/A	All set-ups		FALSE	0	Uint32
16-93	Warning Word 2	0 N/A	All set-ups		FALSE	0	Uint32
16-94	Ext. Status Word	0 N/A	All set-ups		FALSE	0	Uint32

## 2.19.16. 17-.\* \* Motor Feedb.Option

Par. No. #	Parameter description	Default value	4-set-up	FC 302 only	Change during operation	Conversion index	Type
<b>17-1* Inc. Enc. Interface</b>							
17-10	Signal Type	[1] RS422 (5V TTL)	All set-ups		FALSE	-	Ujnt8
17-11	Resolution (PPR)	1024 N/A	All set-ups		FALSE	0	Ujnt16
<b>17-2* Abs. Enc. Interface</b>							
17-20	Protocol Selection	[0] None	All set-ups		FALSE	-	Ujnt8
17-21	Resolution (Positions/Rev)	ExpressionLimit	All set-ups		FALSE	0	Ujnt32
17-24	SSI Data Length	13 N/A	All set-ups		FALSE	0	Ujnt8
17-25	Clock Rate	ExpressionLimit	All set-ups		FALSE	3	Ujnt16
17-26	SSI Data Format	[0] Gray code	All set-ups		FALSE	-	Ujnt8
17-34	HIPERFACE Baudrate	[4] 9600	All set-ups		FALSE	-	Ujnt8
<b>17-5* Resolver Interface</b>							
17-50	Poles	2 N/A	1 set-up		FALSE	0	Ujnt8
17-51	Input Voltage	7.0 V	1 set-up		FALSE	-1	Ujnt8
17-52	Input Frequency	10.0 kHz	1 set-up		FALSE	2	Ujnt8
17-53	Transformation Ratio	0.5 N/A	1 set-up		FALSE	-1	Ujnt8
17-59	Resolver Interface	[0] Disabled	All set-ups		FALSE	-	Ujnt8
<b>17-6* Monitoring and App.</b>							
17-60	Feedback Direction	[0] Clockwise	All set-ups		FALSE	-	Ujnt8
17-61	Feedback Signal Monitoring	[1] Warning	All set-ups		TRUE	-	Ujnt8

**2.19.17. 32-\* \* MCO Basic Settings**

Par. No. #	Parameter description	Default value	4-set-up	FC 302 only	Change during operation	Conversion index	Type
<b>32-0* Encoder 2</b>							
32-00	Incremental Signal Type	[1] RS422 (5V TTL)	2 set-ups		TRUE	-	Uint8
32-01	Incremental Resolution	1024 N/A	2 set-ups		TRUE	0	Uint32
32-02	Absolute Protocol	[0] None	2 set-ups		TRUE	-	Uint8
32-03	Absolute Resolution	8192 N/A	2 set-ups		TRUE	0	Uint32
32-05	Absolute Encoder Data Length	25 N/A	2 set-ups		TRUE	0	Uint8
32-06	Absolute Encoder Clock Frequency	262,000 KHz	2 set-ups		TRUE	0	Uint32
32-07	Absolute Encoder Clock Generation	[1] On	2 set-ups		TRUE	-	Uint8
32-08	Absolute Encoder Cable Length	0 m	2 set-ups		TRUE	0	Uint16
32-09	Encoder Monitoring	[0] Off	2 set-ups		TRUE	-	Uint8
32-10	Rotational Direction	[1] No action	2 set-ups		TRUE	-	Uint8
32-11	User Unit Denominator	1 N/A	2 set-ups		TRUE	0	Uint32
32-12	User Unit Numerator	1 N/A	2 set-ups		TRUE	0	Uint32
<b>32-3* Encoder 1</b>							
32-30	Incremental Signal Type	[1] RS422 (5V TTL)	2 set-ups		TRUE	-	Uint8
32-31	Incremental Resolution	1024 N/A	2 set-ups		TRUE	0	Uint32
32-32	Absolute Protocol	[0] None	2 set-ups		TRUE	-	Uint8
32-33	Absolute Resolution	8192 N/A	2 set-ups		TRUE	0	Uint32
32-35	Absolute Encoder Data Length	25 N/A	2 set-ups		TRUE	0	Uint8
32-36	Absolute Encoder Clock Frequency	262,000 KHz	2 set-ups		TRUE	0	Uint32
32-37	Absolute Encoder Clock Generation	[1] On	2 set-ups		TRUE	-	Uint8
32-38	Absolute Encoder Cable Length	0 m	2 set-ups		TRUE	0	Uint16
32-39	Encoder Monitoring	[0] Off	2 set-ups		TRUE	-	Uint8
32-40	Encoder Termination	[1] On	2 set-ups		TRUE	-	Uint8
<b>32-5* Feedback Source</b>							
32-50	Source Slave	[2] Encoder 2	2 set-ups		TRUE	-	Uint8
<b>32-6* PID Controller</b>							
32-60	Proportional factor	30 N/A	2 set-ups		TRUE	0	Uint32
32-61	Derivative factor	0 N/A	2 set-ups		TRUE	0	Uint32
32-62	Integral factor	0 N/A	2 set-ups		TRUE	0	Uint32
32-63	Limit Value for Integral Sum	1000 N/A	2 set-ups		TRUE	0	Uint16
32-64	PID Bandwidth	1000 N/A	2 set-ups		TRUE	0	Uint16
32-65	Velocity Feed-Forward	0 N/A	2 set-ups		TRUE	0	Uint32
32-66	Acceleration Feed-Forward	0 N/A	2 set-ups		TRUE	0	Uint32
32-67	Max. Tolerated Position Error	20000 N/A	2 set-ups		TRUE	0	Uint32
32-68	Reverse Behavior for Slave	[0] Reversing allowed	2 set-ups		TRUE	-	Uint8
32-69	Sampling Time for PID Control	1 ms	2 set-ups		TRUE	-3	Uint16
32-70	Scan Time for Profile Generator	1 ms	2 set-ups		TRUE	-3	Uint8
32-71	Size of the Control Window (Activation)	0 N/A	2 set-ups		TRUE	0	Uint32
32-72	Size of the Control Window (Deactiv.)	0 N/A	2 set-ups		TRUE	0	Uint32
<b>32-8* Velocity &amp; Accel.</b>							
32-80	Maximum Velocity (Encoder)	1500 RPM	2 set-ups		TRUE	67	Uint32
32-81	Shortest Ramp	1,000 s	2 set-ups		TRUE	-3	Uint32
32-82	Ramp Type	[0] Linear	2 set-ups		TRUE	-	Uint8
32-83	Velocity Resolution	100 N/A	2 set-ups		TRUE	0	Uint32
32-84	Default Velocity	50 N/A	2 set-ups		TRUE	0	Uint32
32-85	Default Acceleration	50 N/A	2 set-ups		TRUE	0	Uint32

## 2.19.18. 33-.\* \* MCO Adv. Settings

Par. No. #	Parameter description	Default value	4-set-up	FC 302 only	Change during operation	Conversion index	Type
<b>33-0* Home Motion</b>							
33-00	Force HOME	[0] Home not forced	2 set-ups		TRUE	-	Uint8
33-01	Zero Point Offset from Home Pos.	0 N/A	2 set-ups		TRUE	0	Int32
33-02	Ramp for Home Motion	10 N/A	2 set-ups		TRUE	0	Uint32
33-03	Velocity of Home Motion	10 N/A	2 set-ups		TRUE	0	Int32
33-04	Behaviour during HomeMotion	[0] Revers and index	2 set-ups		TRUE	-	Uint8
<b>33-1* Synchronization</b>							
33-10	Synchronization Factor Master (M:S)	1 N/A	2 set-ups		TRUE	0	Int32
33-11	Synchronization Factor Slave (M:S)	1 N/A	2 set-ups		TRUE	0	Int32
33-12	Position Offset for Synchronization	0 N/A	2 set-ups		TRUE	0	Int32
33-13	Accuracy Window for Position Sync.	1000 N/A	2 set-ups		TRUE	0	Int32
33-14	Relative Slave Velocity Limit	0 %	2 set-ups		TRUE	0	Uint8
33-15	Marker Number for Master	1 N/A	2 set-ups		TRUE	0	Uint16
33-16	Marker Number for Slave	1 N/A	2 set-ups		TRUE	0	Uint16
33-17	Master Marker Distance	4096 N/A	2 set-ups		TRUE	0	Uint32
33-18	Slave Marker Distance	4096 N/A	2 set-ups		TRUE	0	Uint32
33-19	Master Marker Type	[0] Encoder Z positive	2 set-ups		TRUE	-	Uint8
33-20	Slave Marker Type	[0] Encoder Z positive	2 set-ups		TRUE	-	Uint8
33-21	Master Marker Tolerance Window	0 N/A	2 set-ups		TRUE	0	Uint32
33-22	Slave Marker Tolerance Window	0 N/A	2 set-ups		TRUE	0	Uint32
33-23	Start Behaviour for Marker Sync	[0] Start Function 1	2 set-ups		TRUE	-	Uint16
33-24	Marker Number for Fault	10 N/A	2 set-ups		TRUE	0	Uint16
33-25	Marker Number for Ready	1 N/A	2 set-ups		TRUE	0	Uint16
33-26	Velocity Filter	0 us	2 set-ups		TRUE	-6	Int32
33-27	Offset Filter Time	0 ms	2 set-ups		TRUE	-3	Uint32
33-28	Marker Filter Configuration	[0] Marker filter 1	2 set-ups		TRUE	-	Uint8
33-29	Filter Time for Marker Filter	0 ms	2 set-ups		TRUE	-3	Int32
33-30	Maximum Marker Correction	0 N/A	2 set-ups		TRUE	0	Uint32
33-31	Synchronisation Type	[0] Standard	2 set-ups		TRUE	-	Uint8
<b>33-4* Limit Handling</b>							
33-40	Behaviour atEnd Limit Switch	[0] Call error handler	2 set-ups		TRUE	-	Uint8
33-41	Negative Software End Limit	-500000 N/A	2 set-ups		TRUE	0	Int32
33-42	Positive Software End Limit	500000 N/A	2 set-ups		TRUE	0	Int32
33-43	Negative Software End Limit Active	[0] Inactive	2 set-ups		TRUE	-	Uint8
33-44	Positive Software End Limit Active	[0] Inactive	2 set-ups		TRUE	-	Uint8
33-45	Time in Target Window	0 ms	2 set-ups		TRUE	-3	Uint8
33-46	Target Window LimitValue	1 N/A	2 set-ups		TRUE	0	Uint16
33-47	Size of Target Window	0 N/A	2 set-ups		TRUE	0	Uint16

Par. No. #	Parameter description	Default value	4-set-up	FC 302 only	Change during operation	Conversion index	Type
<b>33-5* I/O Configuration</b>							
33-50	Terminal X57/1 Digital Input	[0] No function	2 set-ups		TRUE	-	Ujnt8
33-51	Terminal X57/2 Digital Input	[0] No function	2 set-ups		TRUE	-	Ujnt8
33-52	Terminal X57/3 Digital Input	[0] No function	2 set-ups		TRUE	-	Ujnt8
33-53	Terminal X57/4 Digital Input	[0] No function	2 set-ups		TRUE	-	Ujnt8
33-54	Terminal X57/5 Digital Input	[0] No function	2 set-ups		TRUE	-	Ujnt8
33-55	Terminal X57/6 Digital Input	[0] No function	2 set-ups		TRUE	-	Ujnt8
33-56	Terminal X57/7 Digital Input	[0] No function	2 set-ups		TRUE	-	Ujnt8
33-57	Terminal X57/8 Digital Input	[0] No function	2 set-ups		TRUE	-	Ujnt8
33-58	Terminal X57/9 Digital Input	[0] No function	2 set-ups		TRUE	-	Ujnt8
33-59	Terminal X57/10 Digital Input	[0] No function	2 set-ups		TRUE	-	Ujnt8
33-60	Terminal X59/1 and X59/2 Mode	[1] Output	2 set-ups		FALSE	-	Ujnt8
33-61	Terminal X59/1 Digital Input	[0] No function	2 set-ups		TRUE	-	Ujnt8
33-62	Terminal X59/2 Digital Input	[0] No function	2 set-ups		TRUE	-	Ujnt8
33-63	Terminal X59/1 Digital Output	[0] No function	2 set-ups		TRUE	-	Ujnt8
33-64	Terminal X59/2 Digital Output	[0] No function	2 set-ups		TRUE	-	Ujnt8
33-65	Terminal X59/3 Digital Output	[0] No function	2 set-ups		TRUE	-	Ujnt8
33-66	Terminal X59/4 Digital Output	[0] No function	2 set-ups		TRUE	-	Ujnt8
33-67	Terminal X59/5 Digital Output	[0] No function	2 set-ups		TRUE	-	Ujnt8
33-68	Terminal X59/6 Digital Output	[0] No function	2 set-ups		TRUE	-	Ujnt8
33-69	Terminal X59/7 Digital Output	[0] No function	2 set-ups		TRUE	-	Ujnt8
33-70	Terminal X59/8 Digital Output	[0] No function	2 set-ups		TRUE	-	Ujnt8
<b>33-8* Global Parameters</b>							
33-80	Activated Program Number	-1 N/A	2 set-ups		TRUE	0	Int8
33-81	Power-up State	[1] Motor on	2 set-ups		TRUE	-	Ujnt8
33-82	Drive Status Monitoring	[1] On	2 set-ups		TRUE	-	Ujnt8
33-83	Behaviour afterError	[0] Coast	2 set-ups		TRUE	-	Ujnt8
33-84	Behaviour afterEsc.	[0] Controlled stop	2 set-ups		TRUE	-	Ujnt8
33-85	MCO Supplied by External 24VDC	[0] No	2 set-ups		TRUE	-	Ujnt8

## 2.19.19. 34-.\* MCO Data Readouts

Par. No. #	Parameter description	Default value	4-set-up	FC 302 only	Change during operation	Conversion index	Type
<b>34-0* PCD Write Par.</b>							
34-01	PCD 1 Write to MCO	0 N/A	All set-ups		TRUE	0	Uint16
34-02	PCD 2 Write to MCO	0 N/A	All set-ups		TRUE	0	Uint16
34-03	PCD 3 Write to MCO	0 N/A	All set-ups		TRUE	0	Uint16
34-04	PCD 4 Write to MCO	0 N/A	All set-ups		TRUE	0	Uint16
34-05	PCD 5 Write to MCO	0 N/A	All set-ups		TRUE	0	Uint16
34-06	PCD 6 Write to MCO	0 N/A	All set-ups		TRUE	0	Uint16
34-07	PCD 7 Write to MCO	0 N/A	All set-ups		TRUE	0	Uint16
34-08	PCD 8 Write to MCO	0 N/A	All set-ups		TRUE	0	Uint16
34-09	PCD 9 Write to MCO	0 N/A	All set-ups		TRUE	0	Uint16
34-10	PCD 10 Write to MCO	0 N/A	All set-ups		TRUE	0	Uint16
<b>34-2* PCD Read Par.</b>							
34-21	PCD 1 Read from MCO	0 N/A	All set-ups		TRUE	0	Uint16
34-22	PCD 2 Read from MCO	0 N/A	All set-ups		TRUE	0	Uint16
34-23	PCD 3 Read from MCO	0 N/A	All set-ups		TRUE	0	Uint16
34-24	PCD 4 Read from MCO	0 N/A	All set-ups		TRUE	0	Uint16
34-25	PCD 5 Read from MCO	0 N/A	All set-ups		TRUE	0	Uint16
34-26	PCD 6 Read from MCO	0 N/A	All set-ups		TRUE	0	Uint16
34-27	PCD 7 Read from MCO	0 N/A	All set-ups		TRUE	0	Uint16
34-28	PCD 8 Read from MCO	0 N/A	All set-ups		TRUE	0	Uint16
34-29	PCD 9 Read from MCO	0 N/A	All set-ups		TRUE	0	Uint16
34-30	PCD 10 Read from MCO	0 N/A	All set-ups		TRUE	0	Uint16
<b>34-4* Inputs &amp; Outputs</b>							
34-40	Digital Inputs	0 N/A	All set-ups		TRUE	0	Uint16
34-41	Digital Outputs	0 N/A	All set-ups		TRUE	0	Uint16
<b>34-5* Process Data</b>							
34-50	Actual Position	0 N/A	All set-ups		TRUE	0	Int32
34-51	Commanded Position	0 N/A	All set-ups		TRUE	0	Int32
34-52	Actual Master Position	0 N/A	All set-ups		TRUE	0	Int32
34-53	Slave Index Position	0 N/A	All set-ups		TRUE	0	Int32
34-54	Master Index Position	0 N/A	All set-ups		TRUE	0	Int32
34-55	Curve Position	0 N/A	All set-ups		TRUE	0	Int32
34-56	Track Error	0 N/A	All set-ups		TRUE	0	Int32
34-57	Synchronizing Error	0 N/A	All set-ups		TRUE	0	Int32
34-58	Actual Velocity	0 N/A	All set-ups		TRUE	0	Int32
34-59	Actual Master Velocity	0 N/A	All set-ups		TRUE	0	Int32
34-60	Synchronizing Status	0 N/A	All set-ups		TRUE	0	Int32
34-61	Axis Status	0 N/A	All set-ups		TRUE	0	Int32
34-62	Program Status	0 N/A	All set-ups		TRUE	0	Int32
<b>34-7* Diagnosis readouts</b>							
34-70	MCO Alarm Word 1	0 N/A	All set-ups		FALSE	0	Uint32
34-71	MCO Alarm Word 2	0 N/A	All set-ups		FALSE	0	Uint32



## 3. Troubleshooting

### 3.1.1. Warnings/Alarm Messages

A warning or an alarm is signalled by the relevant LED on the front of the frequency converter and indicated by a code on the display.

A warning remains active until its cause is no longer present. Under certain circumstances operation of the motor may still be continued. Warning messages may be critical, but are not necessarily so.

In the event of an alarm, the frequency converter will have tripped. Alarms must be reset to restart operation once their cause has been rectified.

**This may be done in three ways:**

1. By using the [RESET] control button on the LCP control panel.
2. Via a digital input with the "Reset" function.
3. Via serial communication/optional fieldbus.



**NB!**

After a manual reset using the [RESET] button on the LCP, the [AUTO ON] button must be pressed to restart the motor.

If an alarm cannot be reset, the reason may be that its cause has not been rectified, or the alarm is trip-locked (see also table on following page).

Alarms that are trip-locked offer additional protection, meaning that the mains supply must be switched off before the alarm can be reset. After being switched back on, the frequency converter is no longer blocked and may be reset as described above once the cause has been rectified.

Alarms that are not trip-locked can also be reset using the automatic reset function in parameters 14-20 (Warning: automatic wake-up is possible!)

If a warning and alarm is marked against a code in the table on the following page, this means that either a warning occurs before an alarm, or else that you can specify whether it is a warning or an alarm that is to be displayed for a given fault.

This is possible, for instance, in parameters 1-90 *Motor Thermal Protection*. After an alarm or trip, the motor carries on coasting, and the alarm and warning flash. Once the problem has been rectified, only the alarm continues flashing until the frequency converter is reset.

No.	Description	Warning	Alarm/Trip	Alarm/Trip Lock	Parameter Reference
1	10 Volts low	X			
2	Live zero error	(X)	(X)		6-01
3	No motor	(X)			1-80
4	Mains phase loss	(X)	(X)	(X)	14-12
5	DC link voltage high	X			
6	DC link voltage low	X			
7	DC over-voltage	X	X		
8	DC under voltage	X	X		
9	Inverter overloaded	X	X		
10	Motor ETR over temperature	(X)	(X)		1-90
11	Motor thermistor over temperature	(X)	(X)		1-90
12	Torque limit	X	X		
13	Over Current	X	X	X	
14	Earth Fault	X	X	X	
15	Hardware mismatch		X	X	
16	Short Circuit		X	X	
17	Control word time-out	(X)	(X)		8-04
23	Internal Fan Fault	X			
24	External Fan Fault	X			14-53
25	Brake resistor short-circuited	X			
26	Brake resistor power limit	(X)	(X)		2-13
27	Brake chopper short-circuited	X	X		
28	Brake check	(X)	(X)		2-15
29	Power board over temp	X	X	X	
30	Motor phase U missing	(X)	(X)	(X)	4-58
31	Motor phase V missing	(X)	(X)	(X)	4-58
32	Motor phase W missing	(X)	(X)	(X)	4-58
33	Inrush Fault		X	X	
34	Fieldbus communication fault	X	X		
36	Mains failure	X	X		
38	Internal Fault		X	X	
40	Overload of Digital Output Terminal 27	(X)			5-00, 5-01
41	Overload of Digital Output Terminal 29	(X)			5-00, 5-02
42	Overload of Digital Output On X30/6	(X)			5-32
42	Overload of Digital Output On X30/7	(X)			5-33
47	24 V supply low	X	X	X	
48	1.8 V supply low		X	X	
49	Speed limit	X			
50	AMA calibration failed		X		
51	AMA check $U_{nom}$ and $I_{nom}$		X		
52	AMA low $I_{nom}$		X		
53	AMA motor too big		X		
54	AMA motor too small		X		
55	AMA parameter out of range		X		
56	AMA interrupted by user		X		
57	AMA time-out		X		
58	AMA internal fault	X	X		
59	Current limit	X			

Table 3.1: Alarm/Warning code list

No.	Description	Warning	Alarm/Trip	Alarm/Trip Lock	Parameter Reference
61	Tracking Error	(X)	(X)		4-30
62	Output Frequency at Maximum Limit	X			
63	Mechanical Brake Low		(X)		2-20
64	Voltage Limit	X			
65	Control Board Over-temperature	X	X	X	
66	Heat sink Temperature Low	X			
67	Option Configuration has Changed		X		
68	Safe Stop	(X)	(X) <sup>1)</sup>		5-19
70	Illegal FC configuration			X	
71	PTC 1 Safe Stop	X	X <sup>1)</sup>		5-19
72	Dangerous Failure			X <sup>1)</sup>	5-19
80	Drive Initialized to Default Value		X		
90	Encoder Loss	(X)	(X)		17-61
91	Analogue input 54 wrong settings			X	S202
100-199	See Operating Instructions for MCO 305				
250	New spare part			X	14-23
251	New Type Code		X	X	

Table 3.2: Alarm/Warning code list

(X) Dependent on parameter

1) Can not be Auto reset via Par 14-20

A trip is the action when an alarm has appeared. The trip will coast the motor and can be reset by pressing the reset button or make a reset by a digital input (Par. 5-1\* [1]). The origin event that caused an alarm cannot damage the frequency converter or cause dangerous conditions. A trip lock is an action when an alarm occurs, which may cause damage to frequency converter or connected parts. A Trip Lock situation can only be reset by a power cycling.

LED indication	
Warning	yellow
Alarm	flashing red
Trip locked	yellow and red

Alarm Word Extended Status Word							
Bit	Hex	Dec	Alarm Word	Alarm Word 2	Warning Word	Warning Word 2	Extended Status Word
0	00000001	1	Brake Check	ServiceTrip, Read/Write	Brake Check		Ramping
1	00000002	2	Pwr. Card Temp	ServiceTrip, (re-served)	Pwr. Card Temp		AMA Running
2	00000004	4	Earth Fault	ServiceTrip, Type-code/Sparepart	Earth Fault		Start CW/CCW
3	00000008	8	Ctrl.Card Temp	ServiceTrip, (re-served)	Ctrl.Card Temp		Slow Down
4	00000010	16	Ctrl. Word TO	ServiceTrip, (re-served)	Ctrl. Word TO		Catch Up
5	00000020	32	Over Current		Over Current		Feedback High
6	00000040	64	Torque Limit		Torque Limit		Feedback Low
7	00000080	128	Motor Th Over		Motor Th Over		Output Current High
8	00000100	256	Motor ETR Over		Motor ETR Over		Output Current Low
9	00000200	512	Inverter Overld.		Inverter Overld.		Output Freq High
10	00000400	1024	DC under Volt		DC under Volt		Output Freq Low
11	00000800	2048	DC over Volt		DC over Volt		Brake Check OK
12	00001000	4096	Short Circuit		DC Voltage Low		Braking Max
13	00002000	8192	Inrush Fault		DC Voltage High		Braking
14	00004000	16384	Mains ph. Loss		Mains ph. Loss		Out of Speed Range
15	00008000	32768	AMA Not OK		No Motor		OVC Active
16	00010000	65536	Live Zero Error		Live Zero Error		AC Brake
17	00020000	131072	Internal Fault	KTY error	10V Low	KTY Warn	Password Timelock
18	00040000	262144	Brake Overload	Fans error	Brake Overload	Fans Warn	Password Protection
19	00080000	524288	U phase Loss	ECB error	Brake Resistor	ECB Warn	
20	00100000	1048576	V phase Loss		Brake IGBT		
21	00200000	2097152	W phase Loss		Speed Limit		
22	00400000	4194304	Fieldbus Fault		Fieldbus Fault		Unused
23	00800000	8388608	24 V Supply Low		24V Supply Low		Unused
24	01000000	16777216	Mains Failure		Mains Failure		Unused
25	02000000	33554432	1.8V Supply Low		Current Limit		Unused
26	04000000	67108864	Brake Resistor		Low Temp		Unused
27	08000000	134217728	Brake IGBT		Voltage Limit		Unused
28	10000000	268435456	Option Change		Encoder loss		Unused
29	20000000	536870912	Drive Initialized		Output freq. lim.		Unused
30	40000000	1073741824	Safe Stop (A68)	PTC 1 Safe Stop (A71)	Safe Stop (W68)	PTC 1 Safe Stop (W71)	Unused
31	80000000	2147483648	Mech. brake low	Dangerous Failure (A72)	Extended Status Word		Unused

Table 3.3: Description of Alarm Word, Warning Word and extended Status Word

The alarm words, warning words and extended status words can be read out via serial bus or optional fieldbus for diagnose. See also par. 16-90 - 16-94.

**WARNING 1, 10 Volts low:**

The 10 V voltage from terminal 50 on the control card is below 10 V. Remove some of the load from terminal 50, as the 10 V supply is overloaded. Max. 15 mA or minimum 590 Ω.

**WARNING/ALARM 2, Live zero error:**

The signal on terminal 53 or 54 is less than 50% of the value set in par. 6-10, 6-12, 6-20, or 6-22 respectively.

**WARNING/ALARM 3, No motor:**

No motor has been connected to the output of the frequency converter.

**WARNING/ALARM 4, Mains phase loss:**

A phase is missing on the supply side, or the mains voltage imbalance is too high.

This message also appears in case of a fault in the input rectifier on the frequency converter.

Check the supply voltage and supply currents to the frequency converter.

**WARNING 5, DC link voltage high:**

The intermediate circuit voltage (DC) is higher than the overvoltage limit of the control system. The frequency converter is still active.

**WARNING 6, DC link voltage low**

The intermediate circuit voltage (DC) is below the undervoltage limit of the control system. The frequency converter is still active.

**WARNING/ALARM 7, DC over voltage:**

If the intermediate circuit voltage exceeds the limit, the frequency converter trips after a time.

**Possible corrections:**

- Connect a brake resistor
- Extend the ramp time
- Activate functions in par. 2-10
- Increase par. 14-26

Alarm/warning limits:			
	3 x 200 - 240 V	3 x 380 - 500 V	3 x 525 - 600 V
	[VDC]	[VDC]	[VDC]
Undervoltage	185	373	532
Voltage warning low	205	410	585
Voltage warning high (w/o brake - w/brake)	390/405	810/840	943/965
Overvoltage	410	855	975

The voltages stated are the intermediate circuit voltage of the frequency converter with a tolerance of ± 5 %. The corresponding mains voltage is the intermediate circuit voltage (DC-link) divided by 1.35

**WARNING/ALARM 8, DC under voltage:**

If the intermediate circuit voltage (DC) drops below the "voltage warning low" limit (see table above), the frequency converter checks if 24 V back-up supply is connected.

If no 24 V backup supply is connected, the frequency converter trips after a given time depending on the unit.

To check whether the supply voltage matches the frequency converter, see *General Specifications*.

**WARNING/ALARM 9, Inverter overloaded:**

The frequency converter is about to cut out because of an overload (too high current for too long). The counter for electronic, thermal inverter protection gives a warning at 98% and trips at 100%, while giving an alarm. You cannot reset the frequency converter until the counter is below 90%.

The fault is that the frequency converter is overloaded by more than 100% for too long.

**WARNING/ALARM 10, Motor ETR over temperature:**

According to the electronic thermal protection (ETR), the motor is too hot. You can choose if you want the frequency converter to give a warning or an alarm when the counter reaches 100% in par. 1-90. The fault is that the motor is overloaded by more than 100% for too long. Check that the motor par. 1-24 is set correctly.

**WARNING/ALARM 11, Motor thermistor over temp:**

The thermistor or the thermistor connection is disconnected. You can choose if you want the frequency converter to give a warning or an alarm when the counter reaches 100% in par. 1-90. Check that the thermistor is connected correctly between terminal 53 or 54 (analog voltage input) and terminal 50 (+ 10 V supply), or between terminal 18 or 19 (digital input PNP only) and terminal 50. If aKTY sensor is used, check for correct connection between terminal 54 and 55.

**WARNING/ALARM 12, Torque limit:**

The torque is higher than the value in par. 4-16 (in motor operation) or the torque is higher than the value in par. 4-17 (in regenerative operation).

**WARNING/ALARM 13, Over Current:**

The inverter peak current limit (approx. 200% of the rated current) is exceeded. The warning will last approx. 8-12 sec., then the frequency converter trips and issues an alarm. Turn off the frequency converter and check if the motor shaft can be turned and if the motor size matches the frequency converter.

If extended mechanical brake control is selected, trip can be reset externally.

**ALARM 14, Earth fault:**

There is a discharge from the output phases to earth, either in the cable between the frequency converter and the motor or in the motor itself.

Turn off the frequency converter and remove the earth fault.

**ALARM 15, Incomplete hardware:**

A fitted option is not handled by the present control board (hardware or software).

**ALARM 16, Short-circuit**

There is short-circuiting in the motor or on the motor terminals.

Turn off the frequency converter and remove the short-circuit.

**WARNING/ALARM 17, Control word timeout:**

There is no communication to the frequency converter.

The warning will only be active when par. 8-04 is NOT set to *OFF*.

If par. 8-04 is set to *Stop* and *Trip*, a warning appears and the frequency converter ramps down until it trips, while giving an alarm.

par. 8-03 *Control word Timeout Time* could possibly be increased.

**WARNING 23, Internal fan fault:**

The fan warning function is an extra protection function that checks if the fan is running / mounted. The fan warning can be disabled in *Fan Monitor*, par. 14-53, (set to [0] Disabled).

**WARNING 24, External fan fault:**

The fan warning function is an extra protection function that checks if the fan is running / mounted. The fan warning can be disabled in *Fan Monitor*, par. 14-53, (set to [0] Disabled).

**WARNING 25, Brake resistor short-circuited:**

The brake resistor is monitored during operation. If it short-circuits, the brake function is disconnected and the warning appears. The frequency converter still works, but without the brake function. Turn off the frequency converter and replace the brake resistor (see par. 2-15 *Brake Check*).

**ALARM/WARNING 26, Brake resistor power limit:**

The power transmitted to the brake resistor is calculated as a percentage, as a mean value over the last 120 s, on the basis of the resistance value of the brake resistor (par. 2-11) and the intermediate circuit voltage. The warning is active when the dissipated braking power is higher than 90%. If *Trip* [2] has been selected in par. 2-13, the frequency converter cuts out and issues this alarm, when the dissipated braking power is higher than 100%.

**ALARM/ WARNING 27, Brake chopper fault:**

The brake transistor is monitored during operation and if it short-circuits, the brake function disconnects and the warning comes up. The frequency converter is still able to run, but since the brake transistor has short-circuited, substantial power is transmitted to the brake resistor, even if it is inactive.

Turn off the frequency converter and remove the brake resistor.

This alarm/ warning could also occur should the brake resistor overheat. Terminal 104 to 106 are available as brake resistor. Klixon inputs, see section Brake Resistor Temperature Switch.

Warning: There is a risk of substantial power being transmitted to the brake resistor if the brake transistor is short-circuited.

**ALARM/WARNING 28, Brake check failed:**

Brake resistor fault: the brake resistor is not connected/working.

**ALARM 29, Drive over temperature:**

If the enclosure is IP 20 or IP 21/Type 1, the cut-out temperature of the heat-sink is 95 °C ±5 °C. The temperature fault cannot be reset, until the temperature of the heatsink is below 70 °C ±5 °C.

**The fault could be:**

- Ambient temperature too high
- Too long motor cable

**ALARM 30, Motor phase U missing:**

Motor phase U between the frequency converter and the the motor is missing.

Turn off the frequency converter and check motor phase U.

**ALARM 31, Motor phase V missing:**

Motor phase V between the frequency converter and the motor is missing.

Turn off the frequency converter and check motor phase V.

**ALARM 32, Motor phase W missing:**

Motor phase W between the frequency converter and the motor is missing.

Turn off the frequency converter and check motor phase W.

**ALARM 33, Inrush fault:**

Too many powerups have occurred within a short time period. See the chapter *General Specifications* for the allowed number of powerups within one minute.

**WARNING/ALARM 34, Fieldbus communication fault:**

The fieldbus on the communication option card is not working.

**WARNING/ALARM 36, Mains failure:**

This warning/alarm is only active if the supply voltage to the frequency converter is lost and parameter 14-10 is NOT set to OFF. Possible correction: check the fuses to the frequency converter

**ALARM 38, Internal fault:**

By this alarm it may be necessary to contact your Danfoss supplier. Some typical alarm messages:

0	The serial port cannot be initialized. Serious hardware failure
256	The power EEPROM data is defect or too old
512	The control board EEPROM data is defect or too old
513	Communication time out Reading EEPROM data
514	Communication time out Reading EEPROM data
515	The Application Orientated Control cannot recognize the EEPROM data
516	Cannot write write to the EEPROM because a write command is on progress
517	The write command is under time out
518	Failure in the EEPROM
519	Missing or invalid BarCode data in EEPROM 1024 – 1279 CAN telegram cannot be sent. (1027 indicate a possible hardware failure)
1281	Digital Signal Processor flash time-out
1282	Power micro software version mismatch
1283	Power EEPROM data version mismatch
1284	Cannot read Digital Signal Processor software version
1299	Option SW in slot A is too old
1300	Option SW in slot B is too old
1311	Option SW in slot C0 is too old
1312	Option SW in slot C1 is too old
1315	Option SW in slot A is not supported (not allowed)
1316	Option SW in slot B is not supported (not allowed)
1317	Option SW in slot C0 is not supported (not allowed)
1318	Option SW in slot C1 is not supported (not allowed)
1536	An exception in the Application Orientated Control is registered. Debug information written in LCP
1792	DSP watchdog is active. Debugging of power part data Motor Orientated Control data not transferred correctly
2049	Power data restarted
2315	Missing SW version from power unit
2816	Stack overflow Control board module
2817	Scheduler slow tasks
2818	Fast tasks
2819	Parameter thread
2820	LCP stack overflow
2821	Serial port overflow

2822	USB port overflow
3072-512 2	Parameter value is outside its limits. Perform a initialization. Parameter number causing the alarm: Subtract the code from 3072. Ex Error code 3238: $3238-3072 = 166$ is outside the limit
5123	Option in slot A: Hardware incompatible with Control board hardware
5124	Option in slot B: Hardware incompatible with Control board hardware
5125	Option in slot C0: Hardware incompatible with Control board hardware
5126	Option in slot C1: Hardware incompatible with Control board hardware
5376-623 1	Out of memory

**WARNING 40, Overload of Digital Output Terminal 27**

Check the load connected to terminal 27 or remove short-circuit connection. Check parameters 5-00 and 5-01.

**WARNING 41, Overload of Digital Output Terminal 29:**

Check the load connected to terminal 29 or remove short-circuit connection. Check parameters 5-00 and 5-02.

**WARNING 42, Overload of Digital Output On X30/6 :**

Check the load connected to X30/6 or remove short-circuit connection. Check parameter 5-32.

**WARNING 42, Overload of Digital Output On X30/7 :**

Check the load connected to X30/7 or remove short-circuit connection. Check parameter 5-33.

**WARNING 47, 24 V supply low:**

The external 24 V DC backup power supply may be overloaded, otherwise Contact your Danfoss supplier.

**WARNING 48, 1.8 V supply low:**

Contact your Danfoss supplier.

**WARNING 49, Speed limit:**

The speed is not within the specified range in par. 4-11 and par. 4-13.

**ALARM 50, AMA calibration failed:**

Contact your Danfoss supplier.

**ALARM 51, AMA check Unom and Inom:**

The setting of motor voltage, motor current, and motor power is presumably wrong. Check the settings.

**ALARM 52, AMA low Inom:**

The motor current is too low. Check the settings.

**ALARM 53, AMA motor too big:**

The motor is too big for the AMA to be carried out.

**ALARM 54, AMA motor too small:**

The motor is too big for the AMA to be carried out.

**ALARM 55, AMA par. out of range:**

The par. values found from the motor are outside acceptable range.

**ALARM 56, AMA interrupted by user:**

The AMA has been interrupted by the user.

**ALARM 57, AMA timeout:**

Try to start the AMA again a number of times, until the AMA is carried out. Please note that repeated runs may heat the motor to a level where the resistance  $R_s$  and  $R_r$  are increased. In most cases, however, this is not critical.

**ALARM 58, AMA internal fault:**

Contact your Danfoss supplier.

**WARNING 59, Current limit:**

The current is higher than the value in par. 4-18.

**WARNING 61, Tracking Error:**

An error between calculated speed and speed measurement from feedback device. The function Warning/Alarm/Disabling setting is in par 4-30. Accepted error setting in par 4-31 and the allowed time the error occur setting in par 4-32. During a commissioning procedure the function may be effective.

**WARNING 62, Output Frequency at Maximum Limit:**

The output frequency is higher than the value set in par. 4-19

**ALARM 63, Mechanical Brake Low:**

The actual motor current has not exceeded the "release brake" current within the "Start delay" time window.

**WARNING 64, Voltage Limit:**

The load and speed combination demands a motor voltage higher than the actual DC link voltage.

**WARNING/ALARM/TRIP 65, Control Card Over Temperature:**

Control card over temperature: The cut-out temperature of the control card is 80° C.

**WARNING 66, Heatsink Temperature Low:**

The heat sink temperature is measured as 0° C. This could indicate that the temperature sensor is defect and thus the fan speed is increased to the maximum in case the power part or control card is very hot.

**ALARM 67, Option Configuration has Changed:**

One or more options has either been added or removed since the last power-down.

**ALARM 68, Safe Stop:**

Safe Stop has been activated. To resume normal operation, apply 24 V DC to T-37, then send a reset signal (via Bus, Digital I/O, or by pressing [RESET]).

**WARNING 68, Safe Stop:**

Safe Stop has been activated. Normal operation is resumed when Safe Stop is disabled. Warning: Automatic Restart!

**ALARM 70, Illegal FC Configuration:**

Actual combination of control board and power board is illegal.

**ALARM 71, PTC 1 Safe Stop:**

Safe Stop has been activated from the MCB 112 PTC Thermistor Card (motor too warm). Normal operation can be resumed when the MCB 112 applies 24 V DC to T-37 again (when the motor temperature reaches an acceptable level) and when the Digital Input from the MCB 112 is deactivated. When that happens, a reset signal must be is sent (via Bus, Digital I/O, or by pressing [RESET]).

**WARNING 71, PTC 1 Safe Stop:**

Safe Stop has been activated from the MCB 112 PTC Thermistor Card (motor too warm). Normal operation can be resumed when the MCB 112 applies 24 V DC to T-37 again (when the motor temperature reaches an

acceptable level) and when the Digital Input from the MCB 112 is deactivated. Warning: Automatic Restart.

**ALARM 72, Dangerous Failure:**

Safe Stop with Trip Lock. Unexpected signal levels on Safe Stop and Digital Input from the MCB 112 PTC Thermistor Card.

**ALARM 80, Drive Initialised to Default Value:**

Parameter settings are initialised to default setting after a manual (three-finger) reset.

**ALARM 90, Encoder loss:**

Check the connection to encoder option and eventually replace the MCB 102 or MCB 103.

**ALARM 91, Analogue Input 54 Wrong Settings:**

Switch S202 has to be set in position OFF (voltage input) when a KTY sensor is connected to analogue input terminal 54.

**ALARM 250, New Spare Part:**

The power or Switch Mode Power Supply has been exchanged. The frequency converter type code must be restored in the EEPROM. Select the correct type code in Par 14-23 according to the label on unit. Remember to select 'Save to EEPROM' to complete.

**ALARM 251, New Type Code:**

The Frequency Converter has got a new type code.

## Index

### [

[hand On] Key On Lcp, 0-40	36
----------------------------	----

### 2

24 V Encoder	39
--------------	----

### A

Abbreviations	4
Access To Quick Menu W/o Password	38
Active Set-up	27
Actual Typecode String, 15-45	155
Alarm Log, 15-3*	154
Alarm Log: Time, 15-32	154
Alarm Log: Value, 15-31	154
Alarm Messages	193
Alarm Word	107
Alarm Word, 16-90	163
Alarm Word, 16-91	163
Analog Inputs	5
Analog Inputs	6
Automatic Motor Adaptation (ama)	42
Automatic Restart Time, 14-21	145

### B

Back Emf At 1000 Rpm	44
Baud Rate	24
Brake Check	57
Brake Control	196
Brake Current	59
Brake Power	6
Brake Power	57
Brake Power	56
Brake Power Monitoring	57
Brake Resistor (ohm) 2-11	56
Brakeenergy /s, 16-32	159
Break-away Torque	5
Bus Controlled	93
Bus Jog 2 Speed	110
Bus Password Access	38

### C

Catch Up	83
Catch Up/slow Down Value	63
Changed Parameters, 9-90 (1)	118
Changed Parameters, 9-91 (2)	119
Changed Parameters, 9-92 (3)	119
Changed Parameters, 9-94 (5)	119
Changing A Data Value	21
Changing A Group Of Numeric Data Values	20
Changing A Text Value	20
Changing Data	19
Clockwise	48, 49
Clockwise	74, 93, 166
Coasting	4, 13
Coasting Select, 8-50	108
Communication Option	197
Configurable Status Word Stw, 8-13	107
Configuration Mode	39
Control Site, 8-01	105
Control Word Timeout Function	105
Cooling	51
Counter Clockwise	74



Current Lim Cont, 14-30	147
Current Lim Contr, Int. Time, 14-31	147
<b>D</b>	
Data Log Settings, 15-1*	151
D-axis Inductance (Id)	44
Dc Brake	55
Dc Brake Select, 8-52	109
Dc Braking Time	56
Dc Hold	48, 50
Dc Hold	55
Dc Link	196
Dc Link Voltage	159
Default Settings	167
Default Settings	24
Defined Parameters, 15-92	156
Definitions	4
Devicenet	120
Devicenet And Can Fieldbus	119
Devicenet F Parameters 10-39	126
Digital Input, 16-60	160
Display Line 2 Large	33
Display Line 3 Large, 0-24	33
Display Mode	14
Display Mode - Selection Of Read-outs	14
Drive Identification, 15-4*	155
Drive Information	150
Drive Ordering Number, 15-46	155
Drive Serial No, 15-51	156
<b>E</b>	
Electronic Terminal Relay	53
Encoder Positive Direction	166
Encoder Pulses	92
Encoder Signal Monitoring	166
End-of-timeout Function, 8-05	106
Environment, 14-5*	148
Etr	51, 158, 196
Ext. Status Word	163
External Reference	160
<b>F</b>	
Fan Monitor, 14-53	148
Fault Log: Error Code	154
Flying Start	49
Freeze Output	4
Freq. Input #33 [hz]	161
Function At Stop	50
<b>G</b>	
General Warning	3
Graphical Display	11
<b>H</b>	
Heatsink Temp.	159
Hist. Log: Time, 15-22	154
Hist. Log: Value, 15-21	154
Historic Log, 15-2*	153
Historic Log: Event, 15-20	154
<b>I</b>	
Incremental Encoder	160
Indexed Parameters	21
Indicator Lights	12

Infinitely Variable Change Of Numeric Data Value .....	21
Initialisation .....	24
Intermediate Circuit .....	196
Inverter Switching, 14-0* .....	142
Iron Loss Resistance (rfe) .....	44
 <b>J</b>	
Jog .....	4
Jog Ramp Time .....	71
Jog Speed .....	63, 66
 <b>K</b>	
Kty Sensor .....	196
Kwh Counter, 15-02 .....	150
 <b>L</b>	
Language .....	26
Language Package 1 .....	26
Language Package 2 .....	26
Language Package 3 .....	26
Language Package 4 .....	26
Lcp .....	4, 6, 11, 14, 22
Lcp 102 .....	11
Lcp Copy .....	37
Lcp Id No .....	155
Lcp Id No, 15-48 .....	155
Lcp Keypad, 0-4* .....	36
Leds .....	11
Live Zero Timeout Time, 6-00 .....	94
Load Type .....	48
Local Control Keys .....	23
Local Reference .....	27
Logging Interval, 15-11 .....	152
Logging Mode, 15-13 .....	153
 <b>M</b>	
Main Actual Value [%], 16-05 .....	157
Main Menu .....	16
Main Menu Mode .....	12
Main Menu Mode .....	19
Main Reactance .....	42
Main Reactance (xh) .....	43
Mains Failure .....	142
Mains Supply .....	7
Mains Voltage At Mains Fault, 14-11 .....	144
Max Output Frequency .....	75
Maximum Inertia .....	48
Maximum Limit .....	73
Maximum Reference .....	62
Min. Frequency For Function At Stop, 1-81 .....	50
Min. Speed For Function At Stop [hz], 1-82 .....	50
Minimum Ae0 Frequency, 14-42 .....	147
Minimum Inertia .....	48
Minimum Limit .....	73
Minimum Magnetisation, 14-41 .....	147
Missing Motor Phase Function, 4-58 .....	78
Modified Parameters, 15-93 .....	156
Motor Angle Offset .....	44
Motor Cont. Rated Torque .....	41
Motor Current .....	41
Motor Current, 16-14 .....	158
Motor External Fan, 1-91 .....	53
Motor Feedback .....	39
Motor Frequency .....	41, 158
Motor Magnetizing At Zero Speed, 1-50 .....	44

Motor Nominal Speed	41
Motor Poles	44
Motor Power	41
Motor Power [hp]	41
Motor Protection	51
Motor Speed High Limit [hz], 4-14	74
Motor Speed Unit	26
Motor Status	157
Motor Thermal Protection	51
Motor Voltage	41, 158

## N

Net Control 10-15	124
Net Reference 10-14	124
Normal Torque	40
Numerical Local Control Panel	22

## O

Off Delay, Relay, 5-42	89
On Delay, Relay, 5-41	88
Operating Hours, 15-00	150
Operating Mode	27
Operating State At Power-up (hand)	27
Operation Mode	145
Option Ident. 15-6*	156
Option Mounted, 15-60	156
Option Ordering No, 15-62	156
Option Serial No, 15-63	156
Option Sw Version, 15-61	156
Ordered Type Code String, 15-44	155
Output Filter, 14-55	148
Output Speed	49
Over Temps, 15-04	150
Over Volts, 15-05	150
Over-voltage Control	58

## P

Parameter Access	125
Parameter Info, 15-9*	156
Parameter Selection	19
Parameter Set-up	16
Passive Load	48
Power Card Ordering No, 15-47	155
Power Card Serial No, 15-53	156
Power Hp, 16-11	158
Power Restore	73
Power Ups, 15-03	150
Precise Stop	50
Precise Stop Counter	162
Precise Stop Function	50
Pre-magnetizing	50
Preset Reference	63
Preset Reference Select, 8-56	110
Process Control, 9-28	115
Profibus Warning Word	115
Proportionalgain	101
Protection Mode	8
Pulse Filter Time Constant #33, 5-59	90
Pulse Input 29, 16-67	161
Pulse Output Maximum Frequency #29, 5-65	91
Pulse Output Maximum Frequency #x30/6, 5-68	92
Pulse Reference	160
Pwm Random, 14-04	142

## Q

Quick Menu	12, 16
Quick Menu Mode	12, 16
Quick Menu Password	37
Quick Stop Ramp Time	71
Quick Stop Select	108
Quick Transfer Of Parameter Settings Between Multiple Frequency Converters	14

## R

Ramp 1 Ramp Down Time	67
Ramp 1 Ramp Up Time	67
Ramp 1 Type	66
Ramp 2 Ramp Down Time	68
Ramp 3 Ramp Down Time	69
Ramp 3 Ramp Up Time	69
Ramp 4 Ramp Down Time	70
Ramp Delay	73
Ramp Time	72
Rated Motor Speed	5
Rcd	6
Reference %, 16-02	157
Reference Source 1	64
Regional Settings	27
Relative Scaling Reference Source	65
Relay Outputs	85
Reset	13
Reset Control Word Timeout	106
Reset Kwh Counter, 15-06	150
Reset Mode, 14-20	144
Reset] Key On Lcp	36
Rfi, 14-50	148
Rotor Leakage Reactance (x2)	43
Rotor Resistance (rr)	43
Running Hours, 15-01	150

## S

Safety Precautions	7
Serial Communication	5
SI Controller Mode, 13-00	126
Special Functions	142
Speed Pid Feed Forward Factor	102
Speed Pid Lowpass Filter Time	102
Start Delay	48
Start Delay	48
Start Function	48
Start Function	48
Start Select, 8-53	109
Start Speed [hz]	49
Start Speed [rpm]	49
Stator Leakage Reactance	42
Stator Leakage Reactance (x1)	43
Stator Resistance (rs)	43
Status	12
Status Messages	11
Step Size	72
Step-by-step	21
Store Always 10-33	126
Store Data Values 10-31	125
Sw Id Control Card, 15-49	155
Sw Id Power Card, 15-50	156
Sw Version, 15-43	155
Switching Frequency	142

## T

Term 32/33 Encoder Direction	93
Term. 29 Low Frequency	89
Term. 33 Low Frequency, 5-55	90
Term. X30/12 Low Ref./feedb. Value, 6-44	97
Terminal 33 High Frequency, 5-56	90
Terminal 33 Low Ref./feedb. Value, 5-57	90
Terminal 42 Output Min Scale, 6-51	98
Terminal 53 High Current	95
Terminal 53 High Voltage, 6-11	95
Terminal 53 Low Current	95
Terminal 53 Switch Setting, 16-61	160
Terminal 54 High Current	96
Terminal 54 Low Current	96
Terminal 54 Switch Setting, 16-63	161
Terminal X30/6 Pulse Output Variable, 5-66	92
Thermal Load	45, 158
Thermistor	51
Thermistor	7
Thermistor Source, 1-93	53
Torque Limit Generator Mode	75
Trip Delay At Torque Limit	146
Trip Reset, 14-2*	144

## V

Variable Torque	40
Vt Level, 14-40	147
Vvcplus	7, 39

## W

Warning Word 2	163
Warning Word, 16-92	163
Warnings	193